


Robotic System for Autonomous Plant Inspection

EX ROVR

Operation Manual



Contents

| | |
|---|------------|
| Chapter 1 EX ROVR Overview | 1-1 |
| 1.1 Introducing EX ROVR..... | 1-1 |
| 1.2 System Components and Their Functions..... | 1-3 |
| 1.3 Inspection Targets..... | 1-4 |
| 1.4 ASCENT Driving Performance..... | 1-6 |
| 1.4.1 Driving route conditions..... | 1-8 |
| 1.5 Introduction Sequence and Manual Composition..... | 1-10 |
| 1.5.1 Intended user..... | 1-11 |
| Chapter 2 Safety Precautions | 2-1 |
| 2.1 Warning Labels..... | 2-6 |
| Chapter 3 Part Names and Functions | 3-1 |
| 3.1 ASCENT..... | 3-1 |
| 3.2 Charging Station..... | 3-5 |
| 3.3 Teleop Terminal..... | 3-8 |
| 3.4 Bundled Accessories and Options..... | 3-10 |
| 3.4.1 Bundled accessories..... | 3-10 |
| 3.4.2 Options..... | 3-11 |
| 3.4.3 Consumables..... | 3-11 |
| Chapter 4 Operation Overview | 4-1 |
| 4.1 Driving and Inspection Flow..... | 4-1 |
| 4.1.1 What is a scenario?..... | 4-2 |
| 4.1.2 Software Used..... | 4-3 |
| 4.2 ASCENT Teleoperator And Attendants..... | 4-4 |
| 4.2.1 Attendants' tasks and precautions..... | 4-5 |
| 4.2.2 Appropriate distance between attendants and ASCENT..... | 4-6 |
| 4.2.3 Teleoperating ASCENT without attendants..... | 4-7 |
| Chapter 5 Planning and Maintenance | 5-1 |
| 5.1 Planning..... | 5-1 |
| 5.1.1 Specification of inspection targets..... | 5-2 |
| 5.1.2 Patrol route considerations..... | 5-3 |
| 5.1.3 Dealing with stairs and steps on the patrol route..... | 5-3 |
| 5.1.4 Floor maintenance..... | 5-4 |
| 5.1.5 Stair/step measurement..... | 5-4 |
| 5.1.6 Marker installation..... | 5-5 |
| 5.1.7 Plan adjustment..... | 5-6 |
| 5.2 Floor Maintenance..... | 5-7 |
| 5.2.1 Floor maintenance..... | 5-7 |
| 5.2.2 Stairs maintenance..... | 5-8 |
| 5.3 Stairs and Steps Measurement..... | 5-11 |
| 5.3.1 Stairs measurement..... | 5-11 |
| 5.3.2 Step measurement..... | 5-14 |
| 5.4 Stair Marker Installation..... | 5-15 |
| 5.4.1 Number of markers required..... | 5-16 |
| 5.4.2 How to install markers..... | 5-18 |

| | | |
|------------------|--|------------|
| Chapter 6 | Teleop Terminals | 6-1 |
| 6.1 | Equipment Configuration..... | 6-1 |
| 6.2 | Teleop Terminal Preparation..... | 6-2 |
| 6.2.1 | Lamp | 6-5 |
| 6.3 | Application Startup And End | 6-6 |
| 6.3.1 | Launching..... | 6-6 |
| 6.3.2 | Teleop screen configuration | 6-8 |
| 6.3.3 | Ending..... | 6-9 |
| Chapter 7 | Creating a Simple Scenario | 7-1 |
| 7.1 | Starting the Teleop Terminal..... | 7-4 |
| 7.2 | Creating a Map | 7-7 |
| 7.2.1 | Exit the Charging Station | 7-8 |
| 7.2.2 | Creating a map..... | 7-10 |
| 7.2.3 | Entering the Charging Station (docking) | 7-17 |
| 7.3 | Registering Objects..... | 7-19 |
| 7.3.1 | Registering the Charging Station | 7-19 |
| 7.3.2 | Registering a target..... | 7-20 |
| 7.3.3 | Step registration | 7-21 |
| 7.4 | Defining Motions..... | 7-23 |
| 7.4.1 | Defining an undocking (Exit) motion | 7-24 |
| 7.4.2 | Defining a map-loading motion | 7-25 |
| 7.4.3 | Defining the motion from the Charging Station to the step | 7-27 |
| 7.4.4 | Defining motion over a step | 7-33 |
| 7.4.5 | Defining the movement to the target..... | 7-36 |
| 7.4.6 | Define a motion to change the attitude of the manipulator..... | 7-37 |
| 7.4.7 | Defining a still image capture motion | 7-43 |
| 7.4.8 | Defining a motion to recover (stow) the manipulator..... | 7-48 |
| 7.4.9 | Defining a motion to return to the Charging Station and dock | 7-50 |
| 7.4.10 | Completed scenario | 7-54 |
| 7.5 | Saving a Scenario..... | 7-55 |
| 7.6 | Opening a Saved Scenario | 7-56 |
| 7.7 | Test Run the Scenario | 7-57 |
| 7.8 | Registering a Schedule | 7-59 |
| 7.9 | Checking Inspection Results..... | 7-62 |
| 7.10 | Particular Cases..... | 7-64 |
| 7.11 | Adding Stairs..... | 7-65 |
| 7.11.1 | Install markers | 7-65 |
| 7.11.2 | Measure the stairs..... | 7-65 |
| 7.11.3 | Open the created scenario | 7-66 |
| 7.11.4 | Create a map of the 2nd floor..... | 7-66 |
| 7.11.5 | Registering a stairs object | 7-68 |
| 7.11.6 | Defining motions..... | 7-73 |
| 7.11.7 | Test run the scenario | 7-85 |
| 7.12 | Measuring the Pinpoint Temperature of a Heat Source Object..... | 7-86 |
| 7.12.1 | Considering where to capture an image of the heat source object..... | 7-88 |
| 7.12.2 | Start creating the scenario | 7-90 |
| 7.12.3 | Define a motion to move to the heat source imaging position | 7-91 |

| | | |
|------------------|--|--------------|
| 7.12.4 | Register (teach) the heat source object | 7-92 |
| 7.12.5 | Defining motions | 7-102 |
| 7.12.6 | Test run the scenario | 7-103 |
| 7.13 | Scenario Creation Example for Areas Separated By Stairs/Steps | 7-104 |
| 7.13.1 | For areas separated by stairs | 7-104 |
| 7.13.2 | When a floor is completely bisected by a step | 7-106 |
| 7.13.3 | When there is a ramp between areas | 7-108 |
| Chapter 8 | Creating a Map | 8-1 |
| 8.1 | Scenario Maker Screen Configuration..... | 8-1 |
| 8.2 | Basic Procedure for Creating Maps/Scenarios..... | 8-4 |
| 8.3 | Creating a Map | 8-5 |
| 8.4 | Key Points for Mapping Large Areas | 8-6 |
| 8.5 | Registering Objects | 8-9 |
| 8.5.1 | Basic object registration procedure..... | 8-10 |
| 8.5.2 | Charging Station placement..... | 8-11 |
| 8.5.3 | Target placement..... | 8-11 |
| 8.5.4 | Heat source object placement..... | 8-11 |
| 8.5.5 | Stairs registration | 8-12 |
| 8.5.6 | Step registration | 8-17 |
| Chapter 9 | Creating a Scenario | 9-1 |
| 9.1 | Scenario Creation Overview | 9-1 |
| 9.1.1 | Motion list..... | 9-2 |
| 9.2 | Start Creating a Scenario..... | 9-3 |
| 9.2.1 | Creating a new scenario | 9-3 |
| 9.2.2 | Re-use an existing scenario..... | 9-3 |
| 9.2.3 | Opening the map..... | 9-4 |
| 9.2.4 | Expert settings | 9-5 |
| 9.3 | Basic Motion Operations | 9-6 |
| 9.3.1 | [Scenario] tab screen configuration..... | 9-6 |
| 9.3.2 | Add a motion | 9-7 |
| 9.3.3 | Motion grouping | 9-9 |
| 9.4 | Add a Motion | 9-12 |
| 9.4.1 | Entry/Exit..... | 9-12 |
| 9.4.2 | Loading a map | 9-13 |
| 9.4.3 | Move to a target | 9-15 |
| 9.4.4 | Adjusting ASCENT's heading..... | 9-19 |
| 9.4.5 | Editing a path | 9-22 |
| 9.4.6 | Manipulator operation | 9-26 |
| 9.4.7 | Opening and closing the manipulator hand..... | 9-31 |
| 9.4.8 | Target imaging..... | 9-32 |
| 9.4.9 | Pinpoint temperature measurement..... | 9-34 |
| 9.4.10 | Gas concentration measurement..... | 9-35 |
| 9.4.11 | Target audio recording..... | 9-36 |
| 9.4.12 | LED lighting..... | 9-37 |
| 9.4.13 | Ascending and descending stairs..... | 9-38 |
| 9.4.14 | Crossing over a step | 9-39 |
| 9.4.15 | Change the sub track angle | 9-40 |

- 9.4.16 Audio output 9-41
- 9.4.17 Timing adjustment 9-42
- 9.4.18 About asynchronous execution 9-43
- 9.5 Saving a Scenario 9-44**
- 9.6 Executing a Scenario 9-45**
- Chapter 10 Registering a Schedule 10-1**
 - 10.1 To Add a New Schedule 10-1
 - 10.2 To Change a Schedule..... 10-3
 - 10.3 To Delete a Schedule 10-4
 - 10.4 To View a Schedule (general users)..... 10-5
 - 10.5 [Schedule List] Screen 10-6
- Chapter 11 Auto Patrol 11-1**
 - 11.1 Scheduled Auto Patrol..... 11-1
 - 11.2 Real-Time Monitoring on the Dashboard..... 11-2
- Chapter 12 Checking Inspection Results 12-1**
 - 12.1 Checking Scenario Execution Results (Inspection Summary) 12-1
 - 12.1.1 Check execution results on the [Inspection Summary] screen 12-1
 - 12.1.2 [Inspection Summaries] screen..... 12-3
 - 12.2 Checking Inspection Results of Each Target (Inspection History) 12-4
 - 12.2.1 Check the inspection results on the [Inspection History] screen..... 12-4
 - 12.2.2 [Inspection History] screen..... 12-5
 - 12.2.3 Display inspection history from the target list..... 12-7
- Chapter 13 Cloud Management 13-1**
 - 13.1 Logging Into the Cloud 13-1
 - 13.1.1 Cloud Menu 13-3
 - 13.2 Plant User Management Overview 13-4
 - 13.3 Plant Registration 13-5
 - 13.3.1 Adding a new plant..... 13-5
 - 13.3.2 Editing plant information..... 13-6
 - 13.3.3 [Plants] screen 13-7
 - 13.4 User Registration 13-9
 - 13.4.1 Administrator and general users 13-9
 - 13.4.2 Adding a new user..... 13-9
 - 13.4.3 Changing user information 13-11
 - 13.4.4 [User Management] screen..... 13-12
 - 13.5 Changing ASCENT’s Affiliated Plant..... 13-14
 - 13.5.1 Changing the affiliated plant..... 13-14
 - 13.5.2 [Robots] screen 13-15
 - 13.6 Issuing Alerts 13-17
 - 13.6.1 Setting alerts 13-17
 - 13.6.2 Checking alerts 13-20
 - 13.6.3 [Alerts] screen 13-22
 - 13.7 Other Management Screens 13-24
 - 13.7.1 [Scenarios] screen 13-24
 - 13.7.2 [Contract Information] screen..... 13-25


| | |
|--|-------------|
| 13.7.3 [Teleop Terminals] screen (displayed only for administrator users) | 13-26 |
| 13.7.4 [Charging Stations] screen (displayed only for administrator users) | 13-27 |
| Chapter 14 Basic ASCENT Operation | 14-1 |
| 14.1 Exiting from the Charging Station (Undocking) | 14-2 |
| 14.2 Moving ASCENT | 14-3 |
| 14.3 Checking Camera Images | 14-4 |
| 14.4 Entering the Charging Station (Docking) | 14-5 |
| 14.5 Crossing a Step | 14-7 |
| 14.5.1 To Raise and lower the sub tracks | 14-7 |
| 14.5.2 Driving over a step | 14-7 |
| 14.6 Ascending and Descending Stairs | 14-12 |
| 14.6.1 Climbing stairs | 14-13 |
| 14.6.2 Descend the stairs | 14-16 |
| 14.7 Changing Sub Track Angles | 14-19 |
| 14.8 Manipulator Operation | 14-21 |
| 14.8.1 Extending the manipulator | 14-21 |
| 14.8.2 Adjusting manipulator orientation | 14-23 |
| 14.8.3 Adjusting the angle of each axis | 14-24 |
| 14.8.4 Manipulating the hand | 14-25 |
| 14.8.5 Returning to the stowed attitude (moving attitude) | 14-25 |
| 14.9 Other Operations | 14-26 |
| 14.9.1 Speaker output of audio data | 14-26 |
| 14.10 Displaying the Gamepad Operation Guide | 14-27 |
| Chapter 15 Troubleshooting | 15-1 |
| 15.1 Troubles During Teleoperation | 15-1 |
| 15.2 Troubles Using Scenario Maker | 15-3 |
| 15.2.1 Scenario errors | 15-3 |
| 15.3 Troubles During Auto Patrol | 15-4 |
| 15.4 Specific Cases | 15-5 |
| 15.4.1 During scenario execution | 15-5 |
| 15.4.2 During teleoperation | 15-5 |
| 15.4.3 When docking (Entry) and undocking (Exit) | 15-7 |
| 15.5 Error List | 15-8 |
| 15.5.1 Error code list | 15-8 |
| Chapter 16 Appendix | 16-1 |
| 16.1 Cloud Screen Transition Diagram | 16-1 |

MEMO

Chapter 1 EX ROVR Overview

1.1 Introducing EX ROVR

The EX ROVR Robotic System for Autonomous Plant Inspection is designed to monitor the interior of plants and factories where there is a risk of fire due to handling of flammable materials, such as in oil and gas plants. Inspections are performed by the ASCENT autonomous patrol robot, and the resulting data is stored in a cloud system for viewing.



EX ROVR is designed to comply with Japanese guidelines for explosion protection and ATEX/IECEX, the explosion protection certification widely adopted in Europe and other parts of the world.

- The system can be used in Zone 1 and Zone 2 hazardous areas where there may be an atmosphere of explosive gas or vapor. It cannot be used in Zone 0 hazardous areas.
- It cannot be used in areas where there may be an explosive atmosphere of combustible or explosive dust (e.g., mines).
- It cannot be used in Group II C explosive gas atmospheres, except for hydrogen gas.
- In places where radiation levels are extremely high (e.g., disaster sites), there is a risk of malfunction or operational failure.

Also, the system is not intended for use in the following locations.


- Public places where people gather, such as stores, lodging facilities, and parks
- Hospitals and other medical facilities
- Residences
- On board ships or aircraft

Reference: Classification of Hazardous Areas

| Category | Description |
|----------|---|
| Zone 0 | Places of normal use where a hazardous atmosphere is continuously present, present for long periods of time, or frequently present. Applicable locations include places where flammable gases are constantly present, such as inside a flammable liquid container or above a flammable liquid surface. |
| Zone 1 | Places where a hazardous atmosphere may occur under normal conditions of use. This indicates places where flammable gases are not constantly present, but are released under certain conditions. This includes places such as the openings of flammable liquid containers, where flammable gases are released only during inspection or other work. |
| Zone 2 | Places where hazardous atmospheres are unlikely to be generated under normal conditions of use or, if generated, are present for only a short period of time, or where explosive atmospheres are only generated under abnormal conditions due to malfunction. |


1.2 System Components and Their Functions

■ ASCENT patrol robot




Robot that autonomously patrols inside a factory or plant to collect internal information. The system provides explosion-proof performance so that it cannot cause ignition in factories and plants where ignition is a hazard.

■ Charging Station



Purges, pressurizes and recharges ASCENT. As with ASCENT, it provides explosion-proof performance, and can be installed together with ASCENT inside factories and plants.

■ Teleop terminal



Terminal used to operate ASCENT. Does not have explosion-proof construction, and should be used in a non-hazardous area separate from the hazardous area where the ASCENT and Charging Station are installed. The terminal provides the following applications.

Teleop software: Used to operate ASCENT remotely.
Scenario Maker: Used to prepare scenarios that define patrol routes and inspection actions.

■ Web application



This application is used to access a cloud system from a web browser on a PC or tablet (not included with EX ROVR).



Management application: Allows system users to make ASCENT autonomous patrol schedules and view inspection data.
Dashboard: Used for checking the current position and status of ASCENT.

1.3 Inspection Targets

ASCENT is equipped with multiple optical and thermal imaging cameras, microphones, and gas detectors.

The following information can be obtained from each device

| Target | Device | Information obtained |
|--|-----------------------------|--|
| Instruments, etc. | Optical surveillance camera | Video (displays images captured by the camera during teleoperation) Still images (acquired manually or by scenario) |
| Entire area to be inspected (360°) | 360° optical camera | Video (displays images captured by the camera during teleoperation) Still images (acquired manually or by scenario) |
| Any heat source | Thermal imaging camera | Video (displays images captured by the camera during teleoperation) Still images (acquired manually or by scenario) |
| Sounds | Microphone | Audio (acquired manually or by scenario) |
| Gases of the following types in the vicinity of ASCENT: Combustible gases (carbon monoxide), hydrogen sulfide, oxygen | Gas detector | Measured gas concentrations (always displayed on the teleop screen of the teleop terminal) |



■ Notes on the on-board gas detection function

ASCENT detects four types of gases: oxygen (O₂), combustible gas (COMB), hydrogen sulfide (H₂S), and carbon monoxide (CO).

- Gas detection results do not guarantee safety within the patrol area.
- Gases other than those targeted and solvent vapor may also be detected, so please take the measurement environment into account.
- Avoid using the system in the vicinity of silicone sealants, etc., or in a silicone gas atmosphere, as this may impair the performance of the equipment.
- Detection of high concentrations of sulfur dioxide, chlorine, or other gases may shorten sensor life and increase errors.
- Prolonged detection of hydrogen sulfide may shorten sensor life or reduce sensitivity.
- In locations where variance from the standard atmospheric pressure is great (for example, at elevations greater than 1000 m above sea level), gas detector's oxygen sensor may become unable to display accurate values.
- Because it is calibrated with isobutane, there is reduced sensitivity with respect to other combustible gases.
- Since the gas detector automatically performs AIR adjustment (zero adjustment) upon ASCENT startup, the concentration displayed may be incorrect if ASCENT is started up in the presence of combustible gas.

1.4 ASCENT Driving Performance

Driving speed: Max. 1.2 km/h during horizontal travel

Driving time: 1 to 2 hours when fully charged (varies according to operation)

Time required for full charge: 2 hours

■ Driving performance on slopes, steps, stairs and ditches




WARNING


- **Do not drive on steps or slopes that exceed its performance limits.**
Accident or damage may result due to tipping or slipping and falling.

| | During autonomous patrol | During teleoperation |
|---------------------|---|--|
| Slope | Depends on the nature of the inclination (such as the coefficient of friction) | |
| Slope | See A on the next page | Inclination of 46° or less |
| Bank | Water runoff slope or less (slope 1/50 to 1/100, or 0.57° to 1.15° in angular terms) | Slope for running without tipping over is 20° or less. |
| Stairs | Step height: 130 to 220 mm Step depth: 210 to 310 mm Step width: 900 mm or greater For slope, see B on the next page. | Step height: 130 to 220 mm Step depth: 210 to 310 mm Step width: 900 mm or greater Inclination of 46° or less |
| Landing | Capable of navigating landings of the following shapes and dimensions. U-shaped: Minimum dimensions of 1800 mm (W) x 1000 mm (D) L-shaped: Minimum dimensions of 1000 mm (W) x 1000 mm (D) I-shaped: Minimum dimensions of 900 mm (W) x 900 mm (D) | |
| Difference in level | Height: 20 cm or less (must have a rectangular cross section) | Height: 40 cm or less (depending on form) |
| Ditches | Width: Within 15 cm | Width: Within 30 cm (depending on form) |

A: Slope that can be navigated during automatic patrol



B: Inclination of stairway that can be navigated during automatic patrol




■ Places where driving is not possible

Driving is not possible on ice, sand, fine gravel (less than 5 mm in diameter).


In addition, puddles (2 cm or more deep), snow, weeds that were not present at time of map or route setting, and heavy rain or snowfall may make determination of position difficult, although driving is possible.

1.4.1 Driving route conditions

ASCENT cannot travel through aisles that are narrower than its own external dimensions. Allow enough space around ASCENT for a person to stand (approx. 900 mm).



When turning in an aisle, available area must exceed the total length of ASCENT. Allow approximately 900 mm of space as shown in the figure on the right.





Also, be aware of the range of motion of the manipulator. When moving the manipulator, be careful not to hit nearby people or objects.

CAUTION


- **Do not move ASCENT with the manipulator extended.**
There is a risk of causing injury to people or damage to objects by hitting them.
Also, vibration may cause the manipulator to malfunction.

Unit: mm



1.5 Introduction Sequence and Manual Composition

The EX ROVR introduction sequence is as follows. Refer to the appropriate manuals for tasks and operations required for introduction.




1.5.1 Intended user

This product has been designed and developed for use by personnel who possess knowledge of explosion protection; that is, the knowledge required to work properly in Zone 1 hazardous areas. Work should be carried out under the supervision of a safety administrator with whom work details have been discussed in advance.

The individual operations and tasks described in the manuals for this product should be undertaken by the following users.


■ Installation and Setup Manual



- Electrical engineers or workers trained in safety who are familiar with the rules, regulations, and standards of the place of installation and IEC 60079-17*, if applicable.
- Workers who have knowledge of explosion protection and are qualified to work properly in Zone 1 hazardous areas.

* One of the standards set by the International Electrotechnical Commission, an international standardization organization that prepares international standards in the fields of electrical and electronic technology. Sets forth the requirements for maintenance and inspection of explosion-proof electrical equipment.

■ Operation Manual




Users of ASCENT teleoperation and cloud systems:

- Workers who can perform basic computer operations.
- Workers who manage the company network.

On-site workers:

- Electrical engineers or safety-trained operators who are familiar with rules, regulations, and standards of the installation site and IEC 60079-17, if applicable.
- Workers who have knowledge of explosion protection and are qualified to work properly in Zone 1 hazardous areas.

■ Maintenance Manual






- Electrical engineers or safety-trained operators who are familiar with rules, regulations, and standards of the installation site and IEC 60079-17, if applicable.
- Workers who have knowledge of explosion protection and are qualified to work properly in Zone 1 hazardous areas.

MEMO

Chapter 2 Safety Precautions


The precautions presented here are intended to ensure safe and correct use of the equipment and to prevent injury to people and damage to property.

These precautions are marked “DANGER”, “WARNING”, “CAUTION”, or “NOTE”, and must be observed.


| | |
|--|--|
|  DANGER | Indicates a hazardous situation which, if handled improperly, presents immediate risk of death or serious injury. |
|  WARNING | Indicates a potentially hazardous situation which, if handled improperly, could result in death or serious injury. |
|  CAUTION | Indicates a potentially hazardous situation which, if handled improperly, could result in injury. |
| NOTE | Indicates a situation which, if handled improperly, could result in equipment failure or property damage. |


Icon examples

The following symbols are used to denote content that requires your attention (including warnings).


 Indicates cautionary information regarding safety.

The following symbols indicate prohibited actions.


 Indicates a prohibited action.

 Indicates that disassembly is prohibited.

The following symbol indicates a required action.

 Indicates a required action.

 **WARNING**

 **Wear protective equipment while doing work near ASCENT or Charging Station, such as installation, preparation, and maintenance.**


- Helmet
- Appropriate clothing that fits your body
- Safety shoes
- Non-slip gloves
- Protective goggles/glasses (for example, when purging ASCENT or accompanying it)

 **Do not modify or make repairs yourself.**

Failure to maintain safety may lead to accidents.
If repairs are required, contact the manufacturer or a maintenance partner.
This company will not be responsible for any malfunction, damage, or accident caused by modification of the software.

 **Use where ambient temperature is in the range of 0 to 40°C.**

Extremely high temperatures may cause the battery to overheat and malfunction. Furthermore, battery performance may deteriorate at temperatures below 0 °C.

 **Do not use replacement parts or accessories other than those recommended by Mitsubishi Heavy Industries, Ltd.**

Doing so may result in accidents or malfunctions.

 **Those who use a pacemaker or defibrillator should note the following.**

- **Do not allow body parts containing implanted devices to come within 15 cm from the ASCENT radio module or teleop terminal.**
- **Keep body parts containing implanted devices at least 30 cm away from the contactless charging unit while charging is in progress.**
- **Keep body parts containing implanted devices away from the magnet-operated power switch key.**


Radio waves and magnets may adversely affect the operation of electronic medical devices.

 **In situations where condensation is expected, stop use until it dries out.**








Condensation may occur in locations that are subject to rapid changes in temperature, possibly causing ASCENT or its Charging Station to malfunction or run out of control. It can also cause gas detectors and cameras to malfunction.

■ Regarding ASCENT



DANGER

-  **When ASCENT is traversing stairs, stay away from the bottom of the stairs.**
If ASCENT slips and hits you, there is a danger of serious injury, such as broken bones.

WARNING

-  **Do not disassemble ASCENT.**
ASCENT has a pressurized explosion-proof structure. Disassembly or opening of covers may compromise the explosion-proof rating, resulting in ignition of flammable gases.
-  **Do not drive ASCENT in areas or during times when there are people or vehicles are being operated.**
Collision may result in injury or damage.
When creation of a map or scenario is required, have someone accompany ASCENT.
-  **Do not ride ASCENT.**
There is a risk of injury from falling or getting your limbs trapped. It may also result in malfunctions.
-  **Do not insert fingers or foreign objects (especially conductive foreign objects or flammable foreign objects such as oil) in the crevices of ASCENT (for example, at the base of manipulator).**
Doing so may result in malfunction or fire.
-  **If you discover that control over ASCENT has been interrupted (if the status LED is flashing red), immediately stop and retrieve ASCENT.**
If the 3D-LiDAR malfunctions or a software error occurs, control over ASCENT may be lost, causing it to go astray.
If a software error is the cause, you may not be able to stop ASCENT from the teleop terminal. In this case, taking care with regard to safety, press the emergency stop button on ASCENT.
-  **When transporting ASCENT in the presence of combustible gases without purging (when internal pressure is not maintained), lift the tracks so that they do not rotate.**
The track generates electricity when turning which may cause a spark and ignite flammable gases.
-  **Do not perform the following operations in hazardous areas.**
 - Do not power on ASCENT before purging (when internal pressure is not maintained).
 - Do not turn on the power in maintenance mode.
 - When ASCENT is stopped outside the Charging Station (e.g., by pressing the emergency stop button), do not power on ASCENT on the spot.
 Flammable gases may ignite.

CAUTION

-  **When ASCENT is powered on (with the status LED lit or flashing), do not touch or approach it (except for the purpose of executing an emergency stop).**
When the status LED is lit or flashing, there is a possibility that the unit may start moving suddenly even though it is stopped. There is risk of injury from being hit or getting one's hands caught in moving parts of the manipulator.
-  **Do not look directly at the laser beam emitted by the 3D-LiDAR and rear obstacle proximity sensor or magnify it by a lens or other means.**


NOTE

- ⊘ Avoid exposing the optical surveillance camera or the truck camera to direct sunlight for an extended period of time.**
Such exposure may cause damage to the photoreceptors.
- ⊘ Keep electrical devices away from the area of ASCENT’s antenna.**
There is a risk of electromagnetic interference.

■ Regarding the Charging Station

⚠ WARNING






- ⊘ Do not disassemble the Charging Station.**
If disassembled, the explosion-proof rating may not be maintained, and flammable gases may ignite.
- ! Make sure that the flanged flameproof joint plane surface between the Charging Station’s control panel lid and the enclosure is not subjected to impact or insertion of foreign matter.**
The contact area of the joint surface between the lid and the enclosure is an integral part that ensures the performance of the explosion-proof structure. If foreign matter gets inside or the joint surface is damaged or distorted, do not operate the system.




- ! Make sure to shut off power at the source before opening the control panel lid.**
If the lid is opened, explosion-proof performance cannot be maintained, and there is a risk of igniting flammable gases if the unit is powered on.
When closing the lid, follow the instructions in “Chapter 5 Charging Station Installation” of “Installation and Setup Manual”
- ⊘ Do not touch the Charging Station if it becomes submerged.**
There is a risk of electric shock. Turn off the source of electrical supply before touching.
- ⊘ Do not apply excessive force, pull or step on, or excessively bend the power cable.**
Doing so may result in damage, heat generation, or fire.
- ! When stepping inside the Charging Station, be careful of the rollers.**
There is a risk of injury from falling.
- ⊘ The control panel contains intrinsically safe circuits, so the wiring should not be replaced or removed.**
Explosion-proof performance may be impaired, possibly leading to ignition of combustible gases. For information on the explosion-proof construction of the Charging Station, see “Installation and Setup Manual”.

■ About the teleop terminal

WARNING



-  **Do not carry the teleop terminal into hazardous areas.**
The teleop terminal is not explosion-proof. Carrying it into a hazardous area would present a risk of ignition of flammable gases.
-  **Do not disassemble the teleop terminal.**
Doing so may result in fire, electric shock, or malfunction.
The notebook computer cannot be removed from the case and used for other purposes.
-  **Do not place containers of water or other liquids or metal objects on the teleop terminal.**
If liquid or foreign matter gets inside, turn off the power and unplug the power plug from the outlet.
-  **Do not expose the device to high temperature for a long period of time.**
Prolonged exposure to extremely high temperature, such as near a fire or under the hot sun, may cause deformation, malfunction or deterioration of internal parts. Using the device in that condition may result in a short circuit or insulation failure, which could lead to fire or electric shock.
-  **Do not place the device in any location where there is a lot of water, moisture, steam, dust, or oily smoke.**
Doing so may result in fire or electric shock.

NOTE

-  **Keep electrical devices away from the area of the teleop terminal's antenna.**
There is a risk of electromagnetic interference.

■ Regarding the internal batteries of ASCENT and the teleop terminal


WARNING

-  **Do not remove the battery except for disposal.**
Removing the battery in the presence of flammable gases may result in ignition. Further, improper battery installation may result in loss of explosion proofing.
-  **If the battery requires replacement, please contact the seller of the product.**
Replacing the battery by yourself or using anything other than the designated battery may result in malfunction or accident.


2.1 Warning Labels



Warning labels are attached to the following parts of the system to indicate hazards or warnings.

Charging Station



ASCENT




| Warning labels | Description |
|---|--|
|  | <p>This symbol indicates that there is a burn hazard due to high-temperature parts. Be sure to confirm that all parts are at a safe temperature.</p> |
|  | <p>This symbol indicates electrical danger, such as risk of electrical shock or burns. The power supply must be disconnected.</p> |

MEMO


Chapter 3 Part Names and Functions

3.1 ASCENT


■ Top left front view (with sub track lowered)



■ Top left front view (with sub track raised)



■ Top right rear view




■ Status LED indications and their meanings

| Status LED color | Status LED state | Description |
|------------------|------------------|---|
| Red | Lit | ASCENT powered on in one of the following states. <ul style="list-style-type: none"> • Standby mode • Self-check in progress • Preparing for power shut-down |
| | Flashing | An anomaly has occurred, and one of the following conditions is present. <ul style="list-style-type: none"> • Uncontrolled state (fatal anomaly) • Standby (not controlled) |
| Green | Flashing | Operating under control of teleop terminal. |
| Blue | Flashing | Scenario running. |
| Yellow | Flashing | Charging. |
| | Lit | Charging stopped (fully charged). Or, entering/exiting Charging Station. |
| Extinguished | | ASCENT power is off. |


■ Explosion-proof structure of ASCENT

ASCENT has explosion-proof construction in its main body and individual parts. For details on explosion proofing, see “Installation and Setup Manual”.



■ Information regarding ASCENT's Class 1 laser

Lasers are emitted from ASCENT's 3D-LiDAR and rear obstacle proximity sensor.




The laser complies with 21CFR1040.10 and 1040.11 and IEC 60825-1.


Caution: Use of the product in any manner other than that described in the instruction manual or repair or disassembly by yourself may result in exposure to hazardous laser radiation.

3.2 Charging Station

■ View from front upper right



■ View from front upper left




■ Lamp indications and their meanings

| Lamp | State | Description |
|-------------------|---|--|
| CHARGING lamp | Flashing (0.5 sec. lit, 0.5 sec. off) | Charging |
| | Lit | Charging completed |
| | Rapid flashing (0.2 sec. lit, 0.2 sec. off) | Charging error |
| PRESSURIZING lamp | Flashing (0.5 sec. lit, 0.5 sec. off) | Pressurizing |
| | Lit | Pressurization completed |
| | Rapid flashing (0.2 sec. lit, 0.2 sec. off) | Pressurization error |
| PURGING lamp | Flashing (0.5 sec. lit, 0.5 sec. off) | Purging in progress in purging mode |
| | Lit | Standby with purging completed |
| | Rapid flashing (0.2 sec. lit, 0.2 sec. off) | Standing by for purging initiation (error) |
| | Slow flashing (1 sec. lit, 1 sec. off) | Purging completed |
| RUNNING lamp | Lit | Normal |
| | Rapid flashing (0.2 sec. lit, 0.2 sec. off) | Cylinder positioning error |


■ Explosion-proof structure of the Charging Station

The Charging Station has explosion-proof construction in its main body and individual parts. For details on explosion proofing, see “Installation and Setup Manual”.



3.3 Teleop Terminal

The teleop terminal is housed in a dedicated case.



■ Case

The pockets on the cover of the case can be used for storage of a mouse and cables.

Remove the cover from the case when using the teleop terminal. See page 6-2 for details.



■ External monitor (optional)

The following cables are provided when the optional external monitor is included at the time of purchase.

- HDMI cable: Connects to the notebook PC.
- USB cable: Used as a power cable for the external monitor.

■ Items contained in the case

The following items are contained in the case. These can all be used without removing them from the case.

- AC adapter for notebook computer
- LTE router
- AC adapter for LTE router

3.4 Bundled Accessories and Options

3.4.1 Bundled accessories


- Magnet-operated power switch key (1)




- Mode selector key (2)



- Positioning marker (10)



- Heat source teaching marker (1)




- Tool for checking internal pressure monitoring interlock (1)
- 2S-V socket (1)
- Installation and Setup Manual (1)
- Operation Manual (This Manual) (1)
- Maintenance Manual (1)

WARNING

- **Do not carry the magnet-operated power switch key or place it near electrical equipment.**
Its magnetic field may cause malfunction or failure of electrical equipment. When not in use, be sure to return it to its stowage position.
- **The mode selector keys should be properly stored by the administrator so that they cannot be taken without permission.**
Improper key management can result in unavailability of the keys at the time they are needed and may lead to accidents.

When not in use, the magnet-operated power switch key can be mounted on the side of the Charging Station in the position shown below.



3.4.2 Options

The following are available as options. Please contact your distributor for information on obtaining or installing these after purchase.

- Marker
- Teleop terminal external monitor

3.4.3 Consumables

Please contact your distributor for information on obtaining or installing these.

| Target | Consumables |
|------------------|-------------------------|
| Charging Station | Grease for auto oiler |
| | Element for air filter |
| ASCENT | Battery |
| | Filter for gas detector |


MEMO

Chapter 4 Operation Overview

4.1 Driving and Inspection Flow


With ASCENT in standby state, it can be ready to run for factory/plant inspection.

A map is first created by ASCENT, to which inspection targets and a driving route are then added to create a “scenario”. Once an execution schedule is set for the scenario, ASCENT automatically patrols the factory/plant and checks the inspection targets.



4.1.1 What is a scenario?

Based on the map of the inside the factory/plant created by ASCENT under teleoperation using its on-board 3D LiDAR, inspection targets, stairs, and steps are registered, and the patrol route and inspection operations are specified while the ASCENT is teleoperated in the same way as when creating the map.




4.1.2 Software Used


■ When creating a scenario

Run Scenario Maker installed on the teleop terminal. The Teleop screen for manually operating ASCENT is launched at the same time.

Teleop terminal



Scenario Maker



Scenario Maker

Teleop screen


■ When viewing inspection data

Access the cloud using a Web browser.


PC or tablet Web browser



Management application



Dashboard



4.2 ASCENT Teleoperator And Attendants

ASCENT teleoperation requires personnel in the following roles:

- One person (teleoperator) to manually control ASCENT using the Teleop terminal
- Persons (attendants) who accompany ASCENT at the site during teleoperation

When creating the map of the patrol area with ASCENT and registering the patrol route in the scenario, the teleoperator manually controls ASCENT using the Teleop terminal, while attendants continually accompany ASCENT during teleoperation. The attendants have the role of informing the teleoperator of ASCENT's situation at the site and stopping ASCENT in the event of an emergency or potential emergency.

In accordance with the national industrial safety and health regulations of each country, the employer should give appropriate instructions and training to personnel (teleoperators and attendants).

ASCENT should always be accompanied by an attendant when creating the map of the patrol area and when registering the patrol route in the scenario.

Attendants should stay away from ASCENT as much as possible. When necessary to work near ASCENT, establish and comply with work rules to avoid danger from unexpected or erroneous operation of ASCENT. These work rules should include the following items:

- ASCENT operating methods and procedures (personnel identification, suspension of obstacle detection functions, and etc.)
- Operating ASCENT and manipulator speed
- How to signal when starting operations with multiple personnel (attendants and teleoperator, etc.)
- Abnormality countermeasures
- ASCENT restarting measures after stopping due to an abnormality
- Measures to prevent danger due to erroneous operation

4.2.1 Attendants' tasks and precautions

WARNING

- **Attendants accompanying ASCENT shall wear protective equipment (helmet, safety shoes, non-slip gloves, protective goggles, etc.).**
Injury could result if ASCENT is bumped and tips over, or if fingers are caught in moving parts. Also be aware of the range of motion of the manipulator.
- **Attendants should not wear reflective clothing or other reflective materials.**
ASCENT may falsely detect them as stairs or obstacles.

■ **Points to be confirmed by an on-site attendant**

An attendant confirms the situation of ASCENT and the site while paying attention to the following points, and informs the teleoperator of the situation.

- When driving ASCENT on floor grating, do the grousers on the main tracks or sub tracks get caught in the grating?
- Is slippage occurring while going up and down stairs, and is motion perpendicular to the stairs (or going up or down diagonally)?
- Driving floor condition
- The presence or absence of driving route obstructions, if any, and their shapes
- Stair conditions (not slippery, unstable, etc.)
- Manipulator's position when moving the ASCENT manipulator.

■ **Emergencies and emergency attendant response**

Depending on the site situation, ASCENT operation may need to be stopped immediately, in which case an attendant must press the emergency stop button (or torque off button) on the rear of ASCENT to stop its operation on the spot.

■ **Number of attendants**

As a general rule, at least one attendant must be present.

Whenever work requires an attendant to enter ASCENT's manipulator range of motion, two attendants should be present. One attendant immediately stops ASCENT if the other is struck by the manipulator.

4.2.2 Appropriate distance between attendants and ASCENT

⚠ WARNING


- **Attendants accompanying ASCENT should keep a constant distance from it and not touch it except to press the emergency stop button or torque off button.**
Injury could result if ASCENT is bumped and tips over, or if fingers are caught in moving parts. Also be aware of the range of motion of the manipulator.

■ Driving ASCENT on a level surface

An attendant should stand directly or diagonally behind ASCENT so as not to interfere with driving. From this position one can press the emergency stop button (or torque off button) on the back of ASCENT to stop it immediately when an emergency occurs.


Be careful to avoid standing in front of ASCENT while creating the map. An attendant standing in front of ASCENT while creating a map will be scanned by 3D-LiDAR as part of the map data, preventing an accurate map. Note that if an attendant stands diagonally forward of ASCENT’s center, they may come within the laser scanning area when ASCENT turns while driving.

Also consider cases where the manipulator may be moved by teleoperation, and be careful that attendants avoid entering the manipulator’s range of motion. For manipulator range of motion, see “1.4 ASCENT Driving Performance” (page 1-6).



■ ASCENT climbing and descending stairs

If ASCENT approaches stairs at an angle, it may tip over and fall while ascending or descending the stairs (see page 14-13). An attendant should closely monitor ASCENT when ascending and descending stairs.



When ASCENT is ascending stairs, do not stand below the stairs or behind ASCENT. Conversely, when ASCENT is descending stairs, stand behind and above it. Do not stand below the stairs or in front of ASCENT. In either case, ASCENT could slip down, collide and cause a serious accident.

When testing a scenario, an attendant should monitor ASCENT at a distance or in a hidden position so that they are not improperly detected by the 3D-LiDAR.

Since the 3D-LiDAR does not misdetect during teleoperation, the attendant may monitor from the top of the stairs (in front of ASCENT). When climbing a railed staircase, ASCENT can be monitored from the side through the railing.

4.2.3 Teleoperating ASCENT without attendants

In some cases, ASCENT may need to be teleoperated unattended because of a dangerous atmosphere at the site when there is no scheduled automatic patrol scenario, or when manual operation is required to monitor the site for some reason outside of the normal schedule. In this case, teleoperation should be performed by an operator who is experienced with teleoperating ASCENT.

MEMO

Chapter 5 Planning and Maintenance


This chapter describes the planning of ASCENT patrols in a factory/plant.

In planning, the person in charge actually walks the factory, identifies inspection targets, and considers the patrol area and route. An estimate of the patrol time is determined.

Maintenance procedures are also described to protect the floor and allow ASCENT to patrol without problems.

5.1 Planning

The factory/plant patrol planning process determines how to proceed using the following example areas.




5.1.1 Specification of inspection targets

ASCENT can perform the following operations on an inspection target.

- Still image capture
- Temperature measurement using a thermal imaging camera
- Audio recording
- Gas concentration measurement (continuously during automatic patrol)

Use these features to determine how to inspect the various inspection targets on the factory/plant floor. For example, the following inspections are possible.


- Capture a still image of an instrument to check the meter needle indication at that time.
- Capture still images of pipes and cables to check for damage.
- Measure gas concentrations in a specific area.
- For equipment that emits heat, such as a boiler, temperature is measured with a thermal imaging camera.
- Record audio where abnormal noise may occur.



5.1.2 Patrol route considerations

Consider the order of inspection based on the positional relationship of the inspection targets to determine the patrol route.


When deciding on a route, make sure that there is enough space for ASCENT to pass. Refer to “1.4 ASCENT Driving Performance” (page 1-6) to select a route with adequate margins.



5.1.3 Dealing with stairs and steps on the patrol route

If there are stairs or steps on the patrol route, determine whether ASCENT can drive on them. Refer to “1.4 ASCENT Driving Performance” (page 1-6) to determine whether ASCENT can drive on them. If not possible, consider a route that avoids the steps or stairs.


To drive ASCENT on stairs or steps, perform the maintenance procedures described later in “5.1.4 Floor maintenance” (page 5-4).



5.1.4 Floor maintenance

Maintenance must be performed on the patrol route where ASCENT cannot run smoothly. See “5.2 Floor Maintenance” (page 5-7) for details.

Slip prevention on each stair step
Rope or perforated metal fencing to prevent slipping into handrail gaps




Slip prevention on slippery floors (recommended)

5.1.5 Stair/step measurement

Where there are stairs or steps on the patrol route, measure the height and depth of the steps. See “5.3 Stairs and Steps Measurement” (page 5-11) for details. These measurement results will be entered into Scenario Maker later.


Measure the height and depth of the first, middle and last steps
Measure the step width



Measure the height (up/down) and depth of the step

5.1.6 Marker installation

Where there are stairs on the patrol route, install markers to indicate the location of the stairs to ASCENT. See “5.4 Stair Marker Installation” (page 5-15) for details.



When capturing a thermal image of a heat source, it is necessary to install markers in two places, which will be installed when creating a scenario. See “7.12 Measuring the Pinpoint Temperature of a Heat Source Object” (page 7-86) for details.

5.1.7 Plan adjustment

Create an automatic patrol scenario based on the results of planning obtained so far. After creating the scenario, perform a test run, and according to the results, repeat the planning flow and reconsider the automatic patrol plan.

■ Estimated patrol time

ASCENT runs for 1 to 2 hours when the battery is fully charged. To determine whether patrol route travel and inspections are possible within this time, the patrol time is estimated based on the distance between each inspection target, stairs/steps, and the patrol route; and the time required for each operation.

A guide to the time required for each inspection operation is shown below. The table below shows the estimated time of each operation (in units of one quarter (0.25) minute). The actual time required for an inspection operation depends on the inspection target.

Estimated inspection time

| Operation | Time required |
|---|---------------------------------------|
| Still image capture for inspection | 0.75 minutes |
| Heat source image capture | 0.25 minutes |
| Stair climbing (3-m height, with one landing) | 2.5 minutes |
| Audio recording | 0.25 minutes |
| Traversing steps | 0.75 minutes |
| Station departure | 3 minutes |
| Station docking | 3 minutes |
| Traversing level floor (at 1.2 km/h) | 1 minute for 20 m (3 seconds for 1 m) |

If a created patrol route scenario would take more than two hours to complete, it must be edited to fit within two hours by removing some inspection operations or editing the route so that the patrol can be completed more quickly. Although a scenario must fit within two hours, it's better to keep the patrol time within one hour, considering that the battery life will decrease over time.

5.2 Floor Maintenance

The patrol route must be maintained so that ASCENT can run without problems and avoid damage from collision with surrounding objects due to erroneous operation or self-position estimation errors. Important equipment along the patrol route on the floor or stairs should be protected with cushioning material.

Consult with factory/plant management and supervision to obtain the necessary maintenance items (non-slip boards, fall prevention rope, perforated metal fencing, and cushioning material).

5.2.1 Floor maintenance


If the floor has a grating, grousers (non-slip protrusions) on the main tracks may get caught. Grousers are most likely to catch in areas where a sharp turn is made on the grating. It is recommended to lay a non-slip board or material on such floors. By laying non-slip material, ASCENT should be able to run stably. In this case, secure the board or non-slip material so that it does not move.

5.2.2 Stairs maintenance

■ Gaps in the railing

Tie a rope or affix fencing material such as a perforated metal sheet to the railing. This prevents ASCENT from getting stuck in or falling through the gaps in the stair railings.

Tie a rope on the railing



Attach perforated metal fencing to the railing



■ **Each stair step**

Attach a non-slip nosing material so that ASCENT can climb and descend stairs in a stable manner.

Non-slip nosing strip (tape)



Non-slip metal stair nosing




Reference: Types and characteristics of non-slip nosing materials


| Type | Advantages | Disadvantages |
|------------------------------|--|---|
| Non-slip nosing strip (tape) | High anti-slip effect and less likely to skid. | Requires regular maintenance (replacement). |
| Non-slip metal stair nosing | Excellent durability and does not need to be replaced regularly. | Prone to skidding (especially when exposed to rain or water). |

■ Maintenance for descending stairs

If the floor of the upstairs landing is made of a grating material, use a flat non-slip plate to prevent the main and sub track grousers from getting stuck in the grooves. Prepare a non-slip plate that is large enough to fit ASCENT when the sub tracks are stowed (approximately 1 m square).



To descend the stairs, lay a 1 m square plate on the floor just above the stairs.



5.3 Stairs and Steps Measurement

ASCENT can go up and down stairs and climb over steps on the patrol route. Measure the width and depth of stairs and steps in advance.

| Ascend/ Descend target | Type | Things to measure | Note |
|---------------------------|-------------------------|--|---|
| Stairs | Two to four steps | <ul style="list-style-type: none"> Stair width | – |
| | Five or more steps | <ul style="list-style-type: none"> Height and depth of each step, number of steps Landing width and depth (only if there is a landing) | A marker must be installed at the end of the stairs. On stairs with a landing, a marker is installed at the landing as well. See page 5-15 for details. |
| Difference in level | Barrier (Straddle step) | <ul style="list-style-type: none"> Depth, and heights of the front and back of the step | – |
| | Ordinary step | <ul style="list-style-type: none"> Step height | |

5.3.1 Stairs measurement

Measure the width, height, and depth of the stairs that ASCENT will go up and down.


For stairs with a mid landing, measure the stairs to the mid landing and the stairs from the mid landing to the next floor separately.

Also measure the width and depth of the landing.

The measured values are used by Scenario Maker when creating the automatic patrol scenario. See “8.5.5 Stairs registration” (page 8-12) for details.

■ Step width measurement


Measuring the step width (inner dimension, a in the figure) with a tape measure.



■ Step height and depth measurement

Measure the height and depth in the first, middle, and last step. Take the case of the stairs shown below as an example. Count the number of steps.

Stairs with no protrusions (noses) on the steps Stairs with protrusions (noses) on the steps



| Measurement target | Corresponding dimension in the above figure |
|-----------------------------|---|
| Initial Step Height | b |
| Initial Step Depth | c |
| Height (middle step height) | d |
| Depth (Middle step height) | e |
| Final Step Height | f |
| Final Step Depth | g |
| Number of Steps | 7 |

The depth of each step is measured as the distance from the front edge of that step to the front edge of the next step. If there is a protruding part (step nose) on each step, the depth (kick) of the step nose is not included in the measurement.

Since the height of the middle steps is generally constant, enter the height and depth of the middle steps by measuring the dimensions of any step other than the first or last step. Note that ASCENT cannot go up and down stairs where the height and depth of the middle steps (those between the first step and the last step) is not uniform.

If there are only two steps in the stairs, there is no middle step, so only the first step and the last step are measured.

We recommend measuring the height of the steps as accurately as possible using two metal rulers (straight edges) as shown in the photo below.

Step height measurement




Step depth measurement



■ Landing measurement

If there is a landing on the stairs, measure the width and depth of the landing.




5.3.2 Step measurement

Measure the height and depth of steps that ASCENT must climb over. In the case of a straddle step such as a barrier, measure the depth, and heights of the step on the front and back sides with respect to the direction of travel. In the case of an ordinary step that is not a straddle step, only the height is measured.

We recommend measuring the height of the step as accurately as possible using two metal rulers (straight edges) as shown in the photo below.



Barrier (Straddle step)



Ordinary step



The measured values are used by Scenario Maker when creating the automatic patrol scenario. See “8.5.6 Step registration” (page 8-17) for details.

5.4 Stair Marker Installation

WARNING

- **Use only the provided markers.**


Markers other than those provided may not be recognized by ASCENT and may result in malfunctions, causing collisions, tipping over, or slipping.

If more markers are needed, contact the manufacturer or distributor.

- **If a marker-like reflector or other marker is near a stairs marker, it will need to be removed.**

When another marker or reflector is nearby, ASCENT may incorrectly detect its marker and collide, fall, or slip.

Markers are used to indicate the location of stairs and landings to ASCENT during automatic patrol. ASCENT detects the markers to determine the position and shape of stairs and landings in order to climb and descend stairs accurately.



Marker size: 100 mm width x 600 mm length x 0.3 mm thick

Three reflectors in the center of an aluminum plate (50 mm width x 160 mm length)

Includes stainless steel bands for attachment (4.3 mm width x 300 mm length)

Markers need to be installed when ASCENT climbs stairs with five or more steps. Markers are not needed on stairs with two to four steps.

5.4.1 Number of markers required


One marker at the end of the stairs (final step).

On stairs with a landing, a marker is installed at the landing as well. The installation location depends on the shape of the landing.

■ U-shaped landing

Install markers at four locations on the landing. Install two markers 1000 mm apart in the direction of travel as ASCENT climbs the stairs. If not possible to install 1000 mm apart, install at a distance farther than 1000 mm, and record the distance.


Also install one marker on the final step of the stairs.



■ L-shaped landing

Install markers at three locations in the outer corners of the landing.


Also install one marker on the final step of the stairs.



■ I-shaped landing

Install markers at the four corners of the landing.

Also install one marker on the final step of the stairs.






5.4.2 How to install markers

WARNING

- **Be careful not to remove, allow to fall, or obscure installed markers.**
If ASCENT fails to recognize a marker, it may malfunction, causing a collision, tipping over, or slipping.

Install markers with straight vertical orientation. Do not install sideways. Markers are installed parallel to ASCENT's direction of travel. Install reflectors facing the center of the passage so that the running ASCENT 3D-LiDAR can catch the markers' reflectors. Install markers with the bottom edge as close as possible to the floor (or landing). Pass the provided stainless steel band (or commercially available cable tie) through the holes in the marker periphery and around the support, or attach to the wall with double-sided tape. Make sure that the markers cannot move from where they are installed.



Chapter 6 Teleop Terminals

The Teleop terminal provides LTE communication with ASCENT, to remotely control ASCENT when creating maps and scenarios.

The Teleop terminal's case includes storage space for necessary equipment such as the PC and gamepad.

WARNING

- **Avoid teleoperation where radio connections are difficult or unstable.**
ASCENT may behave unexpectedly or be unable to stop by teleoperation.
- **Avoid teleoperation when visibility is poor.**
There is risk of collision or slipping.
If visibility is poor due to insufficient light, such as in the rain, turn on surrounding lights so that the surroundings are clearly visible before teleoperating.

6.1 Equipment Configuration

The Teleop Terminal consists of the following devices.

- Notebook computer
- Gamepad
- Wireless mouse
- LTE antenna: For communication between the Teleop terminal and ASCENT.
- LTE router: Stored in the case.
- Expansion monitor (optional)
- USB cable (Type-C) (optional)
- HDMI cable (optional)


The following two software applications are installed on the notebook PC.

- Teleop screen: Remotely controls ASCENT.
- Scenario Maker: Creates scenarios and maps.



6.2 Teleop Terminal Preparation

This section describes the steps required to operate the Teleop terminal.




- 1** Place the case on a stable surface.
- 2** Slide the knobs as shown by the arrows to release the lid, then lift and remove it.



- 3** Remove the gamepad.


4 Raise the LTE antenna.



5 When using an optional expansion monitor, connect its USB terminal to the USB terminal on the case with a USB cable.

Connect the HDMI terminal of the expansion monitor to the HDMI terminal on the PC with an HDMI cable.

6 Connect the AC terminal on the case to an outlet with the power cable.



7 Turn on the case.

8 Turn on the wireless mouse.


9 Turn on the PC.

Turn on the power switch on the front of the PC.

■ Gamepad confirmation items

Ensure that the changeover switch on the back of the gamepad is set to the X side.

If it is on the D side, switch it to the X side. Always use with the changeover switch on the X side.




WARNING

- When the switch is set to the D side, the behavior differs from that described in the instruction manual.

Do not press the MODE button on the gamepad during operation.

When you press the MODE button, the indicator lights up. Press the MODE button again to turn it off.




WARNING

- If you teleoperate while the indicator is lit, the behavior differs from that described in the instruction manual.

6.2.1 Lamp

The case of the Teleop terminal has the following lamps, which indicate the operating status of the router inside the case.



| Lamp | Color | Function |
|---|-------|--|
| RUN | Green | Flashing fast: The router is powered on and the system is initializing. Flashing slowly: The router is running. Off: The router is turned off. |
| PPP | Green | Lit: The link is established. Off: The link has not been established. |
| USR | Green | Flashing: A backup SIM card is being used. Off: The main SIM card is being used. |
|  | Green | Three lit: The signal strength is strong (21-31). Two lit: The signal strength is medium (11-20). One lit: The signal strength is weak (1-10). Off: No radio signal received. Flashing: Unable to connect to the network. The flashing pattern of the lamps indicates the error. See the table below for errors. |

Router error list

| Flashing lamp(s) | | | Error |
|------------------|----------|----------|--------------------------|
| — | — | Flashing | AT command failed. |
| — | Flashing | — | No SIM card detected. |
| — | Flashing | Flashing | Enter your PIN code. |
| Flashing | — | — | Enter your PUK code. |
| Flashing | — | Flashing | Registration failed. |
| Flashing | Flashing | — | Module error. |
| Flashing | Flashing | Flashing | Module is not supported. |

6.3 Application Startup And End

Launch Scenario Maker and the Teleop Screen application.

6.3.1 Launching


1 Double-click the Scenario Maker icon.

The Startup screen appears.

2 Enter your user ID and password.

Both administrator users and general users can log in.

See “13.4 User Registration” (page 13-9) for user IDs and passwords.



3 Click the [Login & Robot Info Acquisition] button.

Upon login, ASCENT information is acquired and displayed.


The status can be as follows.

- Online
- Locked
- Offline

4 Select the ASCENT to use.

5 Click the [Launch] button.


The Scenario Maker screen and Teleop screen appear.



Scenario Maker is used when creating maps and scenarios. For more information, see “Chapter 8 Creating a Map” (page 8-1) “Chapter 9 Creating a Scenario” (page 9-1). The Teleop screen is used when operating ASCENT.

6.3.2 Teleop screen configuration

This section describes the Teleop screen configuration.



■ ASCENT status

Shows the operating status of ASCENT. This appears in the same color as the ASCENT status LED.

■ Error message

Displays the most critical error when errors occur in ASCENT.

■ Pause button

Suspends entry or exit to or from the Charging Station, manipulator attitude change, and sub track attitude change. Resume the operation by clicking the button again.

■ Stop button

Click to stop the executing operation of ASCENT. The operation cannot be resumed.

While the operation will stop, control of ASCENT will continue. ASCENT maintains its position when stopped on stairs or slopes. The sub tracks stop at the set angle. The manipulator stops braking when ASCENT is stopped.

Clicking the Stop button puts ASCENT into standby mode.

To cancel the stop, check the situation, then click the [Error Clear] button. ASCENT returns to the state where teleoperation is possible.

When using the gamepad, you can also stop by pushing the left and right joysticks at the same time.

■ Tab

The screen switches according to the operation.

- Blue when communicating, red when not.

■ Images from truck cameras

Images are displayed from the truck cameras mounted on the front and back of ASCENT. Used to see the status before and after a teleoperation.

■ ASCENT attitude

The current attitude of ASCENT and the angles of the sub tracks and manipulator are displayed in CG. The sub track angles are also displayed numerically.

6.3.3 Ending

When exiting the software, terminate Scenario Maker and the Teleop software separately.

Scenario Maker:

Select [End] on the [Project] tab.

Teleop software:

Click the [x] button at the top right of the screen.


MEMO

Chapter 7 Creating a Simple Scenario

This section describes how to create a basic scenario. Learn the basics of scenario creation by following the instructions to create a scenario.

In this basic scenario, the following inspection contents are assumed.

- One inspection target
- Capture a still image for inspection
- Climb over one step
- Exit the Charging Station → Climb over the step → Move to the inspection target → Extend the manipulator and capture a still image → Return to the Charging Station → Enter the Charging Station



To create this scenario, perform the following procedures:

- Map creation
- Object registration
- Motion definition

In addition to the basic scenario, we also describe how to drive on stairs and capture a thermal image.

The instructions in this chapter assume that the user already understands how to teleoperate ASCENT. To understand teleoperation, first read “Chapter 14 Basic ASCENT Operation” (page 14-1).

 **WARNING**

- **When creating a map/scenario, be sure that an attendant accompanies ASCENT and maintains contact with the teleoperator.**

The attendant should confirm the precautions noted in “4.2 ASCENT Teleoperator And Attendants” (page 4-4) while accompanying ASCENT.

The Obstacle Detection function is disabled during teleoperation, so be attentive to the situation around ASCENT.



- **Avoid teleoperation where radio connections are difficult or unstable.**

ASCENT may behave unexpectedly or be unable to stop by teleoperation.

- **Avoid teleoperation when visibility is poor.**

There is risk of collision or slipping.

If visibility is poor due to insufficient light, such as in the rain, turn on surrounding lights so that the surroundings are clearly visible before teleoperating.


■ Creating and executing scenarios

Scenarios are created by teleoperating ASCENT.

The created scenarios are saved in the cloud.

To edit a scenario, download it from the cloud to the Teleop Terminal.


According to the schedule, the scenario is downloaded from the cloud to ASCENT for execution.



7.1 Starting the Teleop Terminal

The Teleop Terminal is used to create scenarios and maps. Follow the procedure below to start the Teleop Terminal.

- 1 Turn on the Teleop Terminal PC.**
- 2 Double-click the Scenario Maker icon.**
The Startup screen appears.
- 3 Enter your user ID and password.**
Both administrator users and general users can log in. See “13.4 User Registration” (page 13-9) for user IDs and passwords.



- 4 Click the [Login & Robot Info Acquisition] button.**
The robot information is displayed.
- 5 Select the robot name to use.**


6 Click the [Launch] button.

The Scenario Maker screen and Teleop screen appear.

Arrange the Scenario Maker and Teleop screens so they are easy to see.

With only a notebook PC screen, we recommend displaying the Scenario Maker and Teleop screens side by side.


Single Screen Case



With a notebook PC and an external monitor, we recommend displaying Scenario Maker on one screen and the Teleop screen on the other.


Dual Screen Case

Scenario Maker screen



Notebook computer

Teleop screen



Expansion monitor


7.2 Creating a Map

Maps are created using the Teleop Terminal's Teleop screen and Scenario Maker.

Note

Before moving ASCENT, check its battery level and internal pressure.

On the Teleop screen, [Battery] shows the remaining battery level, and [Differential Pressure] shows the internal pressure.



Battery level checking

| Color | Value | State |
|--------|-------------|---|
| Blue | 29V or more | Sufficient battery power remains for normal operation. |
| Yellow | 27 to 29V | The battery is running low. It should be charged before exiting the Charging Station. If away from the Charging Station, consider returning. |
| Red | Below 27V | The battery is low. Be sure to charge the battery before exiting the Charging Station. If away from the Charging Station, return immediately to recharge. |


Differential pressure checking

| Value | State |
|------------------|---|
| Less than -6 kPa | Sufficient for normal operation. |
| -6 kPa or more | Do not exit the Charging Station until pressure is restored. (To restore sufficient pressure, refer to the installation preparation section.) |

7.2.1 Exit the Charging Station

First move (undock) ASCENT from the Charging Station. Have an attendant stand near ASCENT to check its status.

- 1 They should confirm that ASCENT is in the Charging Station and the status LED is lit or flashing yellow.
- 2 Open the [Predefined Motions (Navi)] tab on the Teleop screen.



- 3 Select [Exit Charging Station] on the [Predefined Motions] panel.

4 Click [Execute].


5 Click [Yes] when the message is displayed.

The exit (undocking) process starts.

ASCENT starts working after performing initial processing such as self-checking.


ASCENT stops when it exits the Charging Station, and the status LED flashes green (teleoperation mode).

The attendant should confirm ASCENT's status LED.



Start creating a map with Scenario Maker.

1 Open the [Project] tab in Scenario Maker.




2 Click [Create New Scenario].

3 Select [Clear Scenario] and click [OK].

Scenario creation starts.

4 Click [Create New Map].

The Map Creation Mode screen appears.




Left-Click: Rotate. Middle-Click: Move X/Y. Right-Click: Move Z. Shift: More options.

ASCENT is now operated from the Teleop screen.


5 Open the [Truck] tab on the Teleop screen.

4




6 Use the gamepad to drive ASCENT.

To move ASCENT, press and hold the A button (or X or Y button) while operating the left joystick. The button determines the speed, and the left joystick determines the direction of movement.




ASCENT stops when you release either the button or the joystick.

Drive completely around the patrol area as shown in the example below.




As ASCENT moves, the map is created on the Scenario Maker screen.



Map creation points

While creating the map, along with the camera images on the Teleop screen, you can easily determine the position and status of ASCENT by watching the map screen being created in Scenario Maker.

On the Scenario Maker map screen, ASCENT's position is displayed in the map being created, and locations irradiated by the laser are indicated as series' of white dots. These white dots indicate the locations of walls and obstacles, so you can observe ASCENT and the white dots on the map to confirm the distances between them while driving.



When a step is present


Although ASCENT may need to climb over a step in the scenario, when creating the map, drive on both sides of the step without climbing over. If it is difficult to create a map without crossing a step, adjust the angles of the sub tracks so that the front sub tracks do not come into the LiDAR field of view, then drive ASCENT.

7 After driving around the patrol area completely, stop ASCENT in front of the Charging Station.


If the walls around the area are clearly delineated on the map, map creation has succeeded. Proceed to the next step to save the map.

If walls appear on the map as multiple or distorted lines, map creation has failed. Click [Clear Map] and try creating the map again.

Successful map example



Failed map example



* The above screens are images of created maps opened with Scenario Maker.

8 Click [Store Map].

9 Enter the name of the map and click the [Save] button.


Store Map

Map Name

The map is saved in the Teleop Terminal.

10 Click [OK] when the message is displayed.

11 Click [End] on the map creation screen.



12 Click [Yes] when the message is displayed.

The Map Creation Mode ends.

If you specify the same name as an already saved map, the saved map will be overwritten.


7.2.3 Entering the Charging Station (docking)

Use the Teleop screen to dock ASCENT in the Charging Station.

NOTE

- **Enter along the dotted line of the guide plate.**
If the entry angle is incorrect, ASCENT may crash into the Charging Station.

- 1** Open the [Truck] tab on the Teleop screen.
- 2** Move ASCENT to the front of the Charging Station, aiming at the dotted line on the Charging Station's docking/undocking (entry/exit) guide plate. (Figure A)
- 3** Continue to advance, and stop when ASCENT is entirely over the guide plate. (Figure B)
- 4** Rotate ASCENT 180° to face away from the Charging Station. (Figure C)
To turn, hold down the A button on the gamepad and tilt the left joystick to the left or right. When stopped in the correct position, ASCENT's laser is reflected in the Charging Station's reflector.
An attendant should make sure that ASCENT is stopped centered over the dotted line on the guide plate.



- 5** Open the [Predefined Motions (Navi)] tab on the Teleop screen.


6 Select [Enter Charging Station] on the [Predefined Motions] panel, and click [Execute].

7 Click [Yes] when the message is displayed.

ASCENT will automatically enter the Charging Station.

Soon after docking, the status changes to battery charging mode.

Confirm that the Teleop screen status indicates [Battery charging mode].



7.3 Registering Objects

This procedure registers the locations of objects such as the Charging Station and targets on the map. To register an object, place an object icon from the [Object] tab in Scenario Maker onto the map. An object icon on the map is a guide to the location of the object, so it is not necessary to specify the exact position.

7.3.1 Registering the Charging Station

Specify the location of the Charging Station on the map.

1 Open the previously created map.


- ① Open the [Project] tab in Scenario Maker.
- ② Click [Open Map].
- ③ Select the previously created map from the [Add Map] screen, and click the [OK] button.

The map is displayed.

2 Open the [Object] tab.

3 Click [Charging Station].

4 Click the location of the Charging Station on the map.



The Charging Station icon is placed at the clicked location.

There are no setting items for the Charging Station, so registration is complete.

7.3.2 Registering a target


Place the target icon on the map and enter the name of the target.

Note

- It doesn't matter if the target icon is placed in the exact location.
- You can change the location and name of the target later.
- To see the target information later, right-click the target icon and select "edit".

1 In the [Object] tab, click [Target].


2 Click the target location on the map.



A target icon is placed at the clicked location.

3 Right-click the target icon on the map and select [edit].
The [Target Setting] screen appears.

4 Select [New Registration] in the [Target Name] list and enter a name in the text box below.



5 Click the [OK] button.

6 Click [Yes] when the message is displayed.

A Target ID is assigned, and the target information is saved in the cloud.

7.3.3 Step registration

Register a step as an object, and specify the height and depth of the step. Also read “8.5.6 Step registration” (page 8-17) for details about step registration.


Note

When registering a step, consider ASCENT’s direction of travel. If the front and back heights are different, the side ASCENT will climb must be specified when registering.


To cross the step in the opposite direction to that registered, you can swap the heights when defining the motion.

1 Measure the heights and depth of the step.

Measure the height on the front side in the direction of travel (①), depth (②), and the height (③) on the back side in the direction of travel.

**2 In the [Object] tab of Scenario Maker, click [Steps].**

3 Click the location of a step on the map.




A step icon is placed at the clicked location.

4 Right-click the step icon on the map and select [edit].

The [Step Setting] screen appears.

5 Enter the measured values for [Height A], [Height B], and [Depth].

[Height A] is the height of the front side in the direction of travel, and [Height B] is the height of the back side.



6 Click the [OK] button.

7.4 Defining Motions

Create a scenario based on the created map.

Like a map, a scenario is created using the Teleop Terminal's Teleop screen and Scenario Maker.

A scenario defines the order of movements and inspection behavior of ASCENT in terms of "motions". Here, we will create the following scenario.

| Line No. | Motion | ASCENT behavior |
|----------|------------------|------------------------------|
| 1 | charging-station | Exit the Charging Station |
| 2 | load-map | Load a map |
| 3 | path | Move to a step |
| 4 | rotate-to-point | Face the step |
| 5 | obstacle | Drive over a step |
| 6 | path | Move to a target |
| 7 | arm-joint | Extend the manipulator |
| 8 | record-image | Capture a still image |
| 9 | arm-joint | Restore the manipulator |
| 10 | path | Move to the Charging Station |
| 11 | rotate-to-point | Turn around for docking |
| 12 | charging-station | Dock in the Charging Station |


Motions are defined on the [Scenario] tab of Scenario Maker.

Also read "9.3 Basic Motion Operations" (page 9-6) for details about how to work with motion definitions.

7.4.1 Defining an undocking (Exit) motion

Charging Station undocking (Exit) and docking (Entry) are predefined charging-station motions. They are predefined for use whenever a new scenario is created.

■ When creating a new scenario




A newly created scenario contains two motions: charging-station undocking (Exit) and docking (Entry). All other motions will be defined between these two charging-station motions.

7.4.2 Defining a map-loading motion


A floor map must be loaded before traveling on a floor.
Map loading is defined by the load-map motion.

- 1 Click the **[+]** button below the first charging-station motion.




A new motion is added.

- 2 Click **▼** to display the list of motions, and select “load-map”.



The load-map motion’s property screen appears.

3 Select the map to load from the [Map Name] list.




The list shows the currently open maps.


4 Specify the initial position and attitude (heading) of ASCENT for the load-map motion.

ASCENT's initial position and attitude are indicated by an arrow on the map.

ASCENT's initial position and attitude



Arrow's heading on the map



- ① Click the [Select from Map] button for [Initial Position Attitude].
- ② Move the mouse to the front of the Charging Station icon on the map (the location of ASCENT).
- ③ Click the mouse button and drag the mouse on the spot.
An arrow is displayed on the map, and the heading of the arrow changes as you drag the mouse. Move the arrow so that its heading matches ASCENT's heading, then release the mouse button.



Releasing the mouse button enters the [Initial Position Attitude] motion values.

If the arrow operation does not work, click the [Select from Map] button again and retry the operation.

- 5 Click the [OK] button.

7.4.3 Defining the motion from the Charging Station to the step

Create a motion to move to the step after loading the map. Movement is defined by a “path” motion. Here, you actually drive ASCENT to the step by teleoperation, then save the traversed path.

Before defining the motion, direct ASCENT to exit the Charging Station.

Read “7.2.1 Exit the Charging Station” (page 7-8) for details about exiting the Charging Station.

- 1 Open the [Predefined Motions (Navi)] tab on the Teleop screen.
- 2 Select [Exit Charging Station] on the [Predefined Motions] panel.
- 3 Click [Execute].
- 4 Click [Yes] when the message is displayed.



- This operation involves actually moving ASCENT.


ASCENT exits the Charging Station. After exiting, confirm that the ASCENT status LED is flashing green.

Next load the scenario into ASCENT.

1 Click [Scenario Load] on the [Execute] tab of Scenario Maker.

2 Click [Yes] when the message is displayed.

Confirm that the scenario status has changed from [Waiting for scenario to load] to [Waiting for start].



3 Place ASCENT on the map.

① Click [Robot Positions].


② Move the mouse to the ASCENT location on the map.

③ Click the mouse button and drag the mouse on the spot.

An arrow is displayed on the map, and the heading of the arrow changes as you drag the mouse. Move the arrow so that its heading matches ASCENT's heading, then release the mouse button.



Next, drive ASCENT to create a path from the Charging Station to the step. Starting from the front of the Charging Station, stop at a position about 50 cm in front of and facing the step. In order to climb over a step safely, ASCENT must be facing the step.




Drive ASCENT to the step by teleoperation while recording the path.

Note

When creating a path, all ASCENT motion is recorded. Note that any overshooting of the intended path and returning to or correcting direction is all recorded as it occurs.

1 Click [Begin/end path recording].



2 Open the [Truck] tab on the Teleop screen.

3 Use the gamepad to drive ASCENT to the step.

Press the A, X and Y buttons on the gamepad while moving the left joystick as when creating a map.


Stop when ASCENT reaches the front of the step. At this point, ASCENT does not have to be facing the step.

4 Click [Begin/end path recording] again.

5 When the path name entry dialog box appears, enter a path name and click the [Save] button.

Note


Provide a descriptive name that clearly indicates the path destination.



If you need to reroute the path, click [Abort] in the above dialog. Use the gamepad to return ASCENT to the beginning of the path, click [Begin/end path recording], and record again.

Next, define the route just recorded as a “path” motion.

1 On the [Scenario] tab, click the [+] button below the load-map motion to add the new motion.



2 Select “path” from the list of motions.

The Path Settings screen appears.

Only the main path motion settings are described here. For details on path motions, see “path motion properties” (page 9-17).

3 Select the name of the path saved earlier in [Reference Path].

The screenshot shows the 'Path Settings' dialog box with the following fields and values:

- Reference Path: path001 (with an 'Edit' button highlighted by an orange circle and line pointing to '3')
- Speed: 0.2 m/sec
- Start: 0 m (with 'Reset' and 'select from map' buttons)
- End: 0 m (with 'Reset' and 'select from map' buttons)
- Goal Discrimination Distance: 0.1 m
- Obstacle Detection: Valid, Invalid
- Stopped Heading: m (with a 'select from map' button highlighted by an orange circle and line pointing to '4')
- Turning Speed: 20 deg/sec
- Offset: 0 deg


Buttons at the bottom: Cancel, OK.

In order to climb over a step safely, ASCENT must be facing the step. To do this, use [Stopped Heading] to specify ASCENT's heading when stopped.

4 Specify the stopped heading at which ASCENT faces the step

- ① Under [Stopped Heading], click the [select from map] button.
- ② Move the mouse to the ASCENT location on the map.
- ③ Click the mouse button and drag the mouse on the spot.


An arrow is displayed on the map, and the heading of the arrow changes as you drag the mouse. Drag the arrow so that its heading is perpendicular to the step.



As a result, when the scenario executes, ASCENT will move, rotate and stop with the specified heading.

5 Click the [OK] button.


The new path motion is added. Also, by specifying the [Stopped Heading], a rotate-to-point motion is inserted below the path motion. For details on the rotate-to-point motion, see “rotate-to-point motion” (page 9-19).



7.4.4 Defining motion over a step

An “obstacle” motion is created to drive over a step.

1 Add the motion after the rotate-to-point motion.




2 Select “obstacle” from the list.


The motion property screen appears.

3 Click the [Object Selection] button, then click the step icon on the map.

The measured value of [Height A] of the step object is entered as the [Mounted Height], and the measured value of [Height B] is entered as the [Lowered Height].



If the [Mounted Height] and [Lowered Height] values are opposite to ASCENT's actual direction of travel, click the [Swap] button.



4 Click the [OK] button.

■ Execute the motions to climb over the step

Next, execute the rotate-to-point and obstacle motions just created to have ASCENT actually climb over the step.

1 Click [Scenario Load] on the [Execute] tab of Scenario Maker.

2 Click [Yes] when the message is displayed.

Confirm that the scenario status has changed to [Waiting for start].

3 Select the rotate-to-point line on the [Scenario] tab.


4 Click [Executed selected lines] on the [Execute] tab.

5 Click [Yes] when the message is displayed.



CAUTION

- This operation involves actually moving ASCENT.



The rotate-to-point motion is executed and ASCENT turns to the specified heading.

- 6** Confirm that the obstacle motion is now selected, and click [Executed selected lines].
- 7** Click [Yes] when the message is displayed.

⚠ CAUTION

- This operation involves actually moving ASCENT.

ASCENT climbs over step according to the defined motions.

■ To interrupt scenario creation

To interrupt the scenario creation process, save the scenario to the cloud (even while it is being created). To save, click [Save Scenario] on the [Project] tab of Scenario Maker. (See “7.5 Saving a Scenario” (page 7-55))

■ To resume creating an interrupted scenario

- 1** Click [Open Scenario] on the [Project] tab to open the saved scenario.
(See “7.6 Opening a Saved Scenario” (page 7-56))
- 2** Click [Scenario Load] on the [Execute] tab.
- 3** On the [Scenario] tab, select the load-map motion and click [Executed selected lines].
- 4** Remotely drive ASCENT to the location where you want to resume creation.
- 5** On the [Scenario] tab, resume creating the scenario.

7.4.5 Defining the movement to the target


Next, define the movement to the inspection target as a path motion in the scenario. Perform the same operation as in “7.4.3 Defining the motion from the Charging Station to the step” (page 7-27).

1 Remotely drive to the target and save the path.

- ① Click [Begin/end path recording].
- ② Open the [Truck] tab on the Teleop screen, and remotely drive ASCENT to the target. Press the A, X and Y buttons on the gamepad while moving the left joystick as when creating a map. Stop ASCENT when close to the target.
- ③ Click [Begin/end path recording] again.
- ④ When the path name entry dialog box appears, enter a path name and click the [Save] button.

Next, define the path just recorded as a motion.

2 Click the [+] button under the obstacle motion on the [Scenario] tab to add a motion.



3 Select “path” from the list of motions.


The Path Settings screen appears.

4 Select the name of the path saved earlier in [Reference Path].


5 Click the [OK] button.

7.4.6 Define a motion to change the attitude of the manipulator

Create a motion to point the manipulator toward the location to be inspected. Manipulator attitude changes are defined by arm-joint motions.




- 1 Open the [Predefined Motions (Navi)] tab on the Teleop screen.
- 2 Click the [Video] button under [Surveillance Camera] on the [Predefined Motions] panel.



The surveillance camera image appears on the Teleop screen.

- 3 Open the [Manip.] tab on the Teleop screen.

4 Click [Attitude Change] on the [ManiInfo] panel.




5 Click [[B] Confirm].

The Attitude Change screen appears.

6 Click one of the attitudes on the Attitude Change screen so that the manipulator faces the target location.

Note

When you select an attitude, the target attitude is displayed in red, so you can confirm it.




- 7 Click **[B]** Confirm.
- 8 Click **[Yes]** when the message is displayed.

⚠ CAUTION

- This operation involves actually moving ASCENT.


The manipulator moves and the angle changes.

Check whether the target is in the camera's field of view by looking at the surveillance camera image on the [Manip.] tab.




If out of view, use the gamepad to adjust the manipulator angle as follows:

- 9 Select **[Gamepad Operation]** on the **[ManipInfo]** panel, and click **[B]** Confirm.



Note

Press the gamepad's help button to display the Gamepad Operation Guide.



10 Adjust the angle of the manipulator with the gamepad.

⚠ CAUTION

- **This operation involves actually moving ASCENT.**

The main operations of the manipulator are shown below. For details on manipulator operation, see “14.8 Manipulator Operation” (page 14-21).


| Manipulator movement | Gamepad operation |
|---|--|
| Move the tip back and forth, and left and right | A button (position manipulation) + left joystick front, back, left, and right |
| Move the tip up and down | A button (position manipulation) + R2 button (up) or R1 button (down) |
| Point the tip to the left or right | Y button (attitude manipulation) + left joystick left and right |
| Point the tip up or down | Y button (attitude manipulation) + left joystick up and down |
| Rotate the tip | Y button (attitude manipulation) + L2 button (left rotation) or R2 button (right rotation) |

Once the manipulator’s surveillance camera captures the target, register the motion with the current angle.

Note

The final angle of the manipulator joint is recorded in the motion. Other movements while operating the gamepad are not recorded. When you execute the motion, the manipulator moves to the recorded joint angle.

11 Click the [+] button on Scenario Maker’s [Scenario] tab to add the motion.




12 Select “arm-joint” from the list of motions.

The property screen appears.


13 Click the [Acquiring Current Angle] button.

The angle of the current manipulator is registered with the motion.



14 Click the [OK] button.

The arm-joint motion is added.



7.4.7 Defining a still image capture motion

Create a motion to capture a still image with the manipulator's camera. Still image capture is defined as a record-image motion.

- 1 Click the **[+]** button below the arm-joint motion to add the motion.

| | |
|-------------------------|---|
| map0530 | + |
| 3 path | - |
| path001 | + |
| map0530 | + |
| 4 rotate-to-point | - |
| map: [4.555, -0.304] | + |
| map0530 | + |
| 5 obstacle | - |
| 0.015 _ 0.015 _ 0.015 | + |
| map0530 | + |
| 6 path | - |
| path002 | + |
| map0530 | + |
| 7 arm-joint | - |
| Ref: 1 | + |
| map0530 | + |
| 8 | - |
| | + |
| map0530 | + |
| 9 charging-station | - |
| | + |

- 2 From the list of motions, add “record-image”.
The property screen appears.

record-image property

Target ID Object Selection

Target Name

Camera Surveillance Camera

Image Format JPEG

Surveillance Camera Settings

Imaging Normal Dark area Bright area Auto Exposure

Lighting ON Get Area

u1 u2
v1 v2

× Cancel OK

3 Click the [Object Selection] button, then click the target’s icon on the map.

The ID of the selected target is set as the Target ID and the target name is displayed.

Note

The captured image can be confirmed by its target ID in the cloud. For more details, see “12.2 Checking Inspection Results of Each Target (Inspection History)” (page 12-4).


4 Select the camera and image format to use for shooting.

| Item | Description |
|----------------|--|
| [Camera] | To use the manipulator camera, select [Surveillance Camera]. Otherwise, [360° Optical Camera], [Right Thermal Imaging Camera], or [Left Thermal Imaging Camera] can be selected. |
| [Image Format] | Select [JPEG] or [BMP]. |

[Surveillance Camera Settings] can be confirmed by taking a test shot.

5 Capture a test shot on the Teleop screen.


- ① Open the [Predefined Motions (Navi)] tab on the Teleop screen.



- ② Select [Surveillance Camera Information] on the [Predefined Motions] panel, and click [Execute].


The surveillance camera setting screen appears.

- ③ For [Mode], select an exposure setting.



| Item | Description |
|----------------------------|---|
| Auto | Shoot with the auto exposure setting. |
| Dark Area Setting | Shoot with the exposure setting for dark areas. |
| Bright Area Setting | Shoot with the exposure setting for bright areas. |
| Auto Exposure Zone Setting | Measure and shoot within the area specified by [Auto Exposure Zone Setting]. |
| Area setting | Specify the metering area when [Auto Exposure Zone Setting] is selected. When [Auto Exposure Zone Setting] is selected, a rectangle indicating the metering range appears in the surveillance camera image. Use the D-pad keys on the gamepad to move the rectangle to the location you want to measure, and change the values of u1, u2, v1, and v2 to resize the rectangle. |

- ④ Click [Settings].
- ⑤ Click the [x] button at the top right of the setting screen to close it.
- ⑥ Click the [Still Image] button under [Surveillance Camera] on the [Predefined Motions] panel to capture a test shot.



The exposure settings selected in step ③ are applied to capture the image, which is displayed on the Teleop terminal.



The displayed image can be closed by clicking the [x] button at the top right. If the captured image is too dark or too light, follow the steps below to change the settings and try again.

- ⑦ Select [Surveillance Camera Information] and click [Execute].
- ⑧ Change the [Mode] setting on the setting screen and click the [Settings] button.
- ⑨ As in step ⑥, click the [Still Image] button under [Surveillance Camera] to capture another test shot.

Change the settings and shoot again as needed to determine the appropriate settings. Note the settings determined here, and apply them to the record-image motion settings.

6 Return to Scenario Maker's record-image property screen, and set the shooting mode that you determined from the test shot in [Surveillance Camera Settings].

If you specified a metering range for the test shot, click the [Get Area] button to set that metering range.

record-image property

Target ID: 227 Object Selection

Target Name: target001

Camera: Surveillance Camera

Image Format: JPEG

Surveillance Camera Settings

Imaging Normal Dark area Bright area Auto Exposure

Lighting ON Get Area

u1: 530 u2: 1150

v1: 390 v2: 710

Cancel OK

7 Click the [OK] button.

The record-image motion is added.

| | | |
|---|---------------------------|-----|
| | path001 | + |
| | map0530 | + |
| 4 | rotate-to-point | ... |
| | map: [4.555, -0.304] | + |
| | map0530 | + |
| 5 | obstacle | ... |
| | 0.015 _ 0.015 _ 0.015 | + |
| | map0530 | + |
| 6 | path | ... |
| | path002 | + |
| | map0530 | + |
| 7 | arm-joint | ... |
| | Ref: 1 | + |
| 8 | record-image | ... |
| | 227 (Surveillance Camera) | + |
| | map0530 | + |
| 9 | charging-station | ... |
| | Entry | + |

7.4.8 Defining a motion to recover (stow) the manipulator


After capturing a still image and before moving to the next target, define a motion to retract the manipulator to its stowed attitude.

An arm-joint motion is again used to define the manipulator’s attitude.

⚠ CAUTION

- **Do not move ASCENT with the manipulator extended.**
There is a risk of causing injury to people or damage to objects by hitting them. Also, vibration may cause the manipulator to malfunction.

1 Click the **[+]** button below the record-image motion to add another motion.



2 Select “arm-joint” from the list of motions.
The property screen appears.

3 Click the [Stowed Attitude] button.

The screenshot shows the 'arm-joint property' dialog box. At the top, there is a 'Reference number' dropdown set to '2 (New)'. Below it is an 'Acquiring Current Angle' button. Two buttons, 'Stowed Attitude' and 'Attitude 1', are visible; 'Stowed Attitude' is highlighted with a red rectangular box. Below these are several input fields: 'Speed' (set to 'Auto'), 'S1 Axis Angle' (0), 'S2 Axis Angle' (-86), 'E1 Axis Angle' (176), 'E2 Axis Angle' (0), 'W1 Axis Angle' (0), and 'W2 Axis Angle' (0). At the bottom, there are two checkboxes: 'Transiting Standby Attitude' (checked) and 'Run Asynchronously' (unchecked). 'Cancel' and 'OK' buttons are at the very bottom.

4 Click the [OK] button.

The arm-joint motion is added.

5 Retract the actual manipulator on the Teleop screen.

ASCENT's manipulator is in an extended state, so retract it before creating the next motion.

CAUTION

- This operation involves actually moving ASCENT.

- ① Open the [Manip.] tab on the Teleop screen.
- ② Click [Attitude Change] on the [ManiInfo] panel, and click [[B] Confirm].
- ③ Select Stowed Attitude on the Attitude Change screen, and click [[B] Confirm].
- ④ Click [Yes] when the message is displayed.

The manipulator returns to its stowed position.

7.4.9 Defining a motion to return to the Charging Station and dock


At the end of the scenario, return to the Charging Station for docking.
 Drive to the Charging Station and save the path as a path motion, just like driving to a target.

1 Drive to the Charging Station by teleoperation and save the path.

- ① Click [Begin/end path recording].
- ② Click the [Truck] tab on the Teleop screen, and teleoperate ASCENT to drive to the Charging Station.
- ③ Move ASCENT to the front of the Charging Station, aiming at the dotted line on the Charging Station’s docking/undocking (entry/exit) guide plate.
- ④ Continue to advance, and stop when ASCENT is entirely over the guide plate.
- ⑤ Click [Begin/end path recording] again.
- ⑥ When the path name entry dialog box appears, enter a path name and click the [Save] button.

Next, define the recorded path as a motion. In addition, since ASCENT must enter the Charging Station backwards when docking, add another motion to change its heading when stopped.


2 Click the [+] button under the arm-joint motion on the [Scenario] tab to add the motion.



3 Select “path” from the list of motions.

The Path Settings screen appears.

4 Select the name of the path saved earlier in [Reference Path].




Note

The path selected in [Reference Path] changes color and flashes.


5 Specify the Stopped Heading so that ASCENT can enter the Charging Station.

The following illustrations show ASCENT's heading and the corresponding heading of the arrow on the map.

ASCENT's heading when docked




Arrow's heading on the map



- ① Under [Stopped Heading], click the [select from map] button.
- ② Move the mouse to the ASCENT location on the map.
- ③ Click the mouse button and drag the mouse on the spot.
An arrow is displayed on the map, and the heading of the arrow changes as you drag the mouse. Move the arrow so that it heads in the correct direction, and then release the mouse button.

6 Click the [OK] button.

For the Stopped Heading setting, a rotate-to-point motion is automatically added under the path motion.




The scenario ends with a charging-station entry (docking) motion. The charging-station entry motion was automatically registered when the scenario was created, so it does not need to be added here.

■ Charging Station entry (docking)

As ASCENT has not yet been docked, it must be docked by teleoperation.

For details of the docking (Entry) operation, see “7.2.3 Entering the Charging Station (docking)” (page 7-17).

- 1** Open the [Truck] tab on the Teleop screen, and turn ASCENT so that it is headed as follows.



- 2** Open the [Predefined Motions (Navi)] tab.
- 3** On the [Predefined Motions] panel, select [Enter Charging Station] and click [Execute].
ASCENT will move and automatically enter the Charging Station.

7.4.10 Completed scenario

The following scenarios can be made from the work so far.


| Line No. | Motion | Major parameter settings |
|----------|------------------|---|
| 1 | charging-station | Exit |
| 2 | load-map | Map Name X, Y, Yaw |
| 3 | path | Reference Path Speed Stopped Heading |
| 4 | rotate-to-point | |
| 5 | obstacle | Mounted Height Lowered Height Depth |
| 6 | path | Reference Path Speed Stopped Heading |
| 7 | arm-joint | Reference Number S1 axis angle, S2 axis angle, E1 axis angle, E2 axis angle, W1 axis angle, W2 axis angle |
| 8 | record-image | Target ID Camera: Surveillance Camera Image Format Surveillance Camera Settings |
| 9 | arm-joint | Reference Number S1 axis angle, S2 axis angle, E1 axis angle, E2 axis angle, W1 axis angle, W2 axis angle |
| 10 | path | Reference Path Speed Stopped Heading |
| 11 | rotate-to-point | |
| 12 | charging-station | Entry |

7.5 Saving a Scenario

Save the created scenario in the cloud.

The scenario is saved in association with the plant name. Scenarios are not saved in the Teleop Terminal.

- 1** Click [Save Scenario] on the [Project] tab.
- 2** Select [Overwrite Scenario] or [Register as New Scenario] and click the [OK] button.
- 3** Click [Yes] when the message is displayed.
- 4** If creating a new scenario, enter its name and click the [OK] button.



The screenshot shows a dialog box titled "Scenario Upload". Inside the dialog, there is a text input field labeled "Scenario Name" containing the text "new_scenario". Above this field, the text "Enter the scenario name" is displayed. To the left of the input field, the text "Scenario ID 173" is shown. At the bottom of the dialog, there are two buttons: "Cancel" and "OK".

7.6 Opening a Saved Scenario

To edit a saved scenario, follow the steps below to open it.

- 1 Click [Open Scenario] on the [Project] tab.
- 2 For [Plant Name], select the plant for which the scenario was saved.

The screenshot shows the 'Open Scenario' dialog box. It features a title bar 'Open Scenario'. Inside, there is a checkbox labeled 'Download scenario data from Robot.' which is currently unchecked. Below this is a 'Plant Name' dropdown menu set to 'Building DE'. A 'Select Scenario' list box contains the following items: demo001, eneos0216, fuji scenario_138, new_scenario (highlighted in blue), p_scenario_0316, p_scenario_0316-2, scenario_104, scenario_107, scenario_112, scenario_126, scenario_127, scenario_137, scenario_140, scenario_153, scenario_172, and scenario_stairs. Below the list is a 'Comment' text area and a 'Delete Scenario' button. At the bottom, there is a 'Scenario Name' text field containing 'new_scenario' and a 'Change' button. At the very bottom are 'Cancel' and 'OK' buttons.

- 3 Select the scenario in [Select Scenario] and click the [OK] button.
- 4 When the download confirmation message appears, click [Yes].
The scenario will be downloaded from the cloud.

7.7 Test Run the Scenario

Execute the scenario to see if it was created correctly.
After creating a scenario, test it to ensure that it works.


WARNING

- When testing a scenario, be sure that an attendant accompanies ASCENT to monitor its status.

Start with ASCENT docked. If ASCENT has not been docked, have it do so first. For the docking (Entry) operation, see “7.2.3 Entering the Charging Station (docking)” (page 7-17).

1 Open the [Execute] tab in Scenario Maker.

Make sure that the scenario status on the toolbar is [Waiting for scenario to load].




2 Click [Scenario Load].

3 Click [Yes] when the message is displayed.

The scenario is loaded into ASCENT.

The scenario status changes from [Waiting for scenario to load] to [Waiting for start].

4 Select the first line of the scenario.



5 Click [Execute to end].

6 Click [Yes] when the message is displayed.

 **CAUTION**

- **This operation involves actually moving ASCENT.**

ASCENT patrols according to the scenario.

If the scenario doesn't execute correctly or stops in the middle, check for the offending motion and modify it. If ASCENT does not move to the proper position, modify the path motion settings and path. To modify the path, see "9.4.5 Editing a path" (page 9-22). The obstacle detection function may stop ASCENT while moving. In that case, open the path motion properties screen and disable the obstacle detection option.


7.8 Registering a Schedule

To execute the scenario automatically, register an execution date and time for the scenario in the cloud.

Here, specify a time close to the current time to ensure that the scenario executes on schedule.

- 1 Enter the URL of the cloud (<https://ex-rovr.com>) in your PC's Web browser (Chrome recommended).**

The login screen appears.




- 2 Enter your User ID (email address) and password.**

For user ID and password details, see “13.1 Logging Into the Cloud” (page 13-1).


- 3 Click the [Sign In] button.**

The cloud management screen appears.




| Name | AL... | Last inspection | Num. schedules | Num. targets | Num. scenarios | |
|--------------|-------|-----------------|----------------|--------------|----------------|------|
| ▼ MHI | ● | None | 0 | 0 | 0 | Edit |
| ▶ Kobe | ● | None | 0 | 0 | 0 | Edit |
| Futami | ● | None | 0 | 2 | 0 | Edit |
| Takasago | ● | None | 0 | 1 | 0 | Edit |
| NM | ● | None | 0 | 0 | 1 | Edit |
| MM | ● | None | 0 | 1 | 0 | Edit |
| KS | ● | 2021/05/25 | 1 | 3 | 3 | Edit |
| Musashino | ● | None | 0 | 0 | 0 | Edit |
| UMAD | ● | None | 0 | 5 | 2 | Edit |
| crestec-test | ● | None | 0 | 1 | 0 | Edit |

4 Select [Schedules] from the menu on the left.



5 Click the [Add] button.
The [Schedule Registration] screen appears.



6 Select the plant name for execution in [Plant].
A list of scenarios registered for the selected plant is displayed on the right side of the screen.

7 Enter the schedule name.

The screenshot shows the 'Schedule Registration' dialog box with the following fields and callouts:

- 6** Plant: Building DE
- 7** Schedule Name: test_schedule
- 9** Robot: ER20GY-00A
- Scenario: test_scenario
- 10** Start Date: 2022/07/01
- 11** Cycle: Month
- 12** Expiration: No Expiration

Additional options include: Time Zone (Plant, UTC), Execution Count (0), and Expiration Date.

8 Select the scenario for execution in [Scenario].

Click on the scenario name column to pop up its map and patrol route.

9 Select ASCENT as the [Robot] to execute the scenario.

10 Set the [Start Date].

Click the [Start Date] and [Start Time] fields, and specify the execution starting date and time.

11 Set the [Cycle].

Select the unit (year, month, week, day, hour) in the first list.

- [Year], [Week], [Day], [Time]: Enter the cycle (frequency) numerically.
- [Month]: In addition to specifying a numerical value for once every few months, you can also specify the 10th of every month, the third Friday of every month, and the like.
- [Week]: Specify the execution day of the week.

12 Specify when to end the scheduled executions with [End].

- [No Expiration]: No expiration date is set.
- [Expiration Date]: The schedule will not be executed after the specified date.
- [Execution Count]: The schedule will no longer execute after the specified number of executions.

13 Click the [OK] button.

The schedule is registered.

■ Start the scenario

At the scheduled operation start time, ASCENT will automatically start patrol.


At the start time, ASCENT first reboots its devices and loads the scenario. Therefore, it takes about five minutes for ASCENT to actually start moving.

7.9 Checking Inspection Results


Check the results of an automatic patrol.

Whenever automatic patrol executes, the execution results and captured images are uploaded to the cloud. Check the results on the management screen.

- 1 Log in to the cloud.
- 2 Select [Inspection Summaries] from the menu.
The [Inspection Summaries] screen appears.



- 3 Select the plant from the [Plant] list.
- 4 Select the name of the scenario you want to check in [Scenario], and click the [Search] button.
The patrol results that match the search conditions are displayed in order from the most recent.





- 5** Click the [Detail] button in the row of the patrol results you want to display. Patrol results are displayed as a form.

☰ Inspection Summary

[Print](#)

| | | | |
|----------|---------|---------------------------|------------------|
| Plant | DE | Start | 2022/02/16 10:57 |
| Schedule | | Completed | 2022/02/16 11:04 |
| Scenario | demo001 | Inspection Duration (min) | 7 |
| Robot | Rovr A | Num. Anomaly | 0 / 1 |



| Image / Audio | Target | Acquired Time | Anomaly |
|---|---------|------------------|---------|
|  | demo001 | 2022/02/16 11:02 | None |

A map is displayed on the right side of the screen, with the patrol route and shooting locations displayed on the map.

Acquired images are displayed at the bottom of the screen. Click an image to enlarge it.

In the cloud, you can also check past inspection results for each target in [Inspection History].

7.10 Particular Cases

- **Narrow passages**

The obstacle detection function may stop ASCENT from passing through narrow spaces on a path motion route.

In that case, open the path motion properties screen and disable the obstacle detection option.

The screenshot shows a 'Path Settings' dialog box with the following fields and controls:

- Reference Path: path002 (dropdown), Edit button
- Speed: 0.2 (dropdown), m/sec
- Start: Reset button, select from map button, 0 m
- End: Reset button, select from map button, 0 m
- Goal Discrimination Distance: 0.1 (text input), m
- Obstacle Detection: Valid, Invalid (highlighted with an orange box)
- Stopped Heading: Reset button, select from map button, m
- Turning Speed: 20 (dropdown), deg/sec
- Offset: 0 (text input), deg
- Buttons: × Cancel, OK

- **Ascending and descending slopes**

Differences in elevation up to 100 cm and inclinations of up to about 15 degrees can be traversed on one map as if on a flat surface.

7.11 Adding Stairs

Add stair ascending and descending to the basic scenario. Climb stairs to a 2nd floor, drive on the 2nd floor, measure the gas concentration in one place, and add a motion to return to the 1st floor.

7.11.1 Install markers

Install markers to drive on stairs.

For details, see “5.4 Stair Marker Installation” (page 5-15).

7.11.2 Measure the stairs

Measure the height and width of the stairs that ASCENT will travel on. If there is a landing, measure its size in mm.

Measure the following dimensions.

- Stair width
- First step height and depth
- Last step height and depth
- Middle step height and depth

If there is a landing, measure the above items for the stairs to the landing and again for the stairs after the landing. Also measure the following landing dimensions.

- Landing width
- Landing depth

Also note the shape of the staircase (I-type, L-type, U-type) and the direction of a turn (left or right).



7.11.3 Open the created scenario

Open the basic scenario you have created. Add stair ascending and descending to this scenario.

- 1 Open the [Project] tab in Scenario Maker.
- 2 Click [Open Scenario].
- 3 Select the previously created basic scenario and click the [OK] button.

7.11.4 Create a map of the 2nd floor


To travel on multiple floors, a map of each floor is necessary.

Drive ASCENT to the 2nd floor to create a map there. Create a map by teleoperating ASCENT in the same way as “7.2 Creating a Map” (page 7-7).

See “Chapter 14 Basic ASCENT Operation” (page 14-1) for instructions on how to climb stairs by teleoperation.

Start creating a map with Scenario Maker.


- 1 Position ASCENT at the point immediately after climbing the stairs.
- 2 Open the [Project] tab in Scenario Maker.
- 3 Click [Create New Map].




The Map Creation Mode screen appears.

- 4 Open the [Truck] tab on the Teleop screen.

- 5 Use the gamepad to drive ASCENT.
- 6 Drive all around the 2nd floor, return to the previous staircase position, and stop ASCENT.



- 7 Click [Store Map].
- 8 Enter the name of the map and click the [Save] button.



The map is saved in the Teleop Terminal.


- 9 Click [End] to exit the Map Creation Mode.

7.11.5 Registering a stairs object

Register the stairs (staircase) object on the map.


1 Open the 2nd floor map.

Open the [Layer] tab and make sure both 1st and 2nd floor maps are open.



2 Display the 1st floor map and open the [Object] tab.


- 3 Click [Stairs], then click the location of the stairs on the map.
A Stairs icon appears.



- 4 Right-click on the Stairs icon and select [edit].
The Stairs Settings screen appears.

5 Select the presence or absence of a landing and the shape of the stairs in [Landing].

6 Enter the measured stair dimensions on the setting screen.




7 Enter a name in [Name] and click the [OK] button.

The Stairs settings are saved in the cloud.

Next, display the 2nd floor map and make the Stairs Settings for the 2nd floor as well.

8 On the [Layer] tab, right-click the 2nd floor map and select [Set to Current Map].

The 2nd floor map is displayed.

9 On the [Object] tab, click [Stairs], then click the location of the stairs on the map.**10** Right-click on the Stairs icon and select [edit].

The Stairs Settings screen appears.

Since the stairs settings have already been entered on the 1st floor map, all you have to do is bring up the stair settings on the 2nd floor.

11 Select the name of the stairs you entered earlier in [Select Stairs].

12 **11**

Stairs Settings

Select Stairs: U_shaped
 Name: U_shaped
 Copy

Landing: None I-shaped L-shaped U-shaped
 Left turn Right turn

Affiliated Plant Name: DE棟

X Coordinate (m): 0.427
 Y Coordinate (m): 2.043
 Angle (deg): 0.000

Connect to lower stairs
 Same as at left

| Dimensions [mm] | Stair 1 | Stair 2 |
|-----------------------|---------|---------|
| a Step Width | 900 | 900 |
| b Initial Step Height | 222 | 195 |
| c Initial Step Depth | 233 | 230 |
| d Height | 200 | 194 |
| e Depth | 230 | 230 |
| f Final Step Height | 191 | 208 |
| g Final Step Depth | 233 | 329 |
| Number of Steps | 0 | 0 |

Landing Dimensions [mm]
 h Width: 1860
 i Depth: 1000

× Cancel OK

12 Uncheck [Copy].

13 Click the [OK] button.
 Stairs settings are finished.

7.11.6 Defining motions

Add motions to ascend and descend the stairs based on the basic scenario.


Highlighted lines indicate added or changed motions.

| Line No. | Motion | ASCENT behavior |
|----------|------------------|------------------------------|
| 1 | charging-station | Exit the Charging Station |
| 2 | load-map | Load a map |
| 3 | path | Move to a target |
| 4 | rotate-to-point | Face the step |
| 5 | obstacle | Drive over a step |
| 6 | path | Move to a target |
| 7 | arm-joint | Extend the manipulator |
| 8 | record-image | Capture a still image |
| 9 | arm-joint | Restore the manipulator |
| 10 | path | Go to the stairs |
| 11 | align | Face the stairs |
| 12 | stairs | Climb the stairs |
| 13 | load-map | Load the 2nd floor map |
| 14 | path | Move to a target |
| 15 | record-audio | Record surrounding sounds |
| 16 | path | Move to the stairs |
| 17 | rotate-to-point | Face the stairs |
| 18 | stairs | Descend the stairs |
| 19 | load-map | Load the 1st floor map |
| 20 | path | Move to the Charging Station |
| 21 | rotate-to-point | Turn around for docking |
| 22 | charging-station | Dock in the Charging Station |


■ Define the motion to move to the stairs

In line 10 of the original scenario, the path motion to return to the Charging Station will be changed to a path motion that moves to the bottom of the stairs.

- 1** Execute [Scenario Load] on the [Execute] tab of Scenario Maker.
- 2** Teleoperate ASCENT to move it to the target position on the 8th line (record-image) of the scenario.
- 3** Use Scenario Maker to start path recording from that position.
For details on path recording operations, see “7.4.3 Defining the motion from the Charging Station to the step” (page 7-27).
- 4** Teleoperate ASCENT to move it to the bottom of the stairs.
- 5** Stop path recording and save the path.
- 6** Click on [...] for the path motion in the 10th line of the scenario.



The motion property screen appears.

7 Replace [Reference Path] with the path saved in step 5.

The image shows a 'Path Settings' dialog box with the following fields and controls:

| Field | Value | Unit | Control |
|------------------------------|----------------|---------|------------------------|
| Reference Path | path004 | | Edit |
| Speed | 0.2 | m/sec | |
| Start | | 0 m | Reset, select from map |
| End | | 0 m | Reset, select from map |
| Goal Discrimination Distance | 0.1 | m | |
| Obstacle Detection | Valid | | Valid, Invalid |
| Stopped Heading | [1.178, -0.37] | m | Reset |
| Turning Speed | 20 | deg/sec | |
| Offset | 0 | deg | |

Buttons: × Cancel, OK

8 Click the [OK] button.

■ Defining a motion to ascend stairs


Use Stairs motions to ascend and descend stairs.

To move safely on the stairs, use an “align” motion to turn ASCENT to face the stairs.

WARNING

- **ASCENT must be aligned to face the stairs.**
If ASCENT attempts to climb stairs diagonally, it may lose its balance and topple over.
- **If a marker-like reflector or other marker is near a stairs marker, it will need to be removed.**
When another marker or reflector is nearby, ASCENT may incorrectly detect its marker and collide, fall, or slip.

1 Add the motion after the path motion on the 10th line.




2 Select “align” from the list.

The motion property screen appears.

3 Select [line] for [Facing Target].

Select [line] to automatically detect linear structures such as a stair step, and rotate ASCENT to face it.



- 4 Click the [OK] button.
- 5 Add another motion after the align motion.
- 6 Select “stairs” from the list.
The motion property screen appears.
- 7 Click the [Object Selection] button, then click the stairs icon on the map.

stairs property

Object Selection

Stairs Name stair006 ...

Direction Climb Descend

× Cancel OK

- 8 Select [Climb].
- 9 Click the [OK] button.

| | | |
|----|---------------------------|---|
| | map0530 | + |
| 7 | arm-joint | - |
| | Ref: 1 | + |
| | map0530 | + |
| 8 | record-image | - |
| | 227 (Surveillance Camera) | + |
| | map0530 | + |
| 9 | arm-joint | - |
| | Ref: 2 | + |
| | map0530 | + |
| 10 | path | - |
| | path004 | + |
| | map0530 | + |
| 11 | align | - |
| | line | + |
| 12 | stairs | - |
| | U_shaped: up | + |
| | map0530 | + |

■ Defining a motion to load the 2nd floor map

A floor map must be loaded whenever moving between floors.


After climbing to the 2nd floor, use the load-map motion to load the 2nd floor map.

1 Add this motion after the stairs motion.



2 Select “load-map” from the list.

3 Select the 2nd floor map from the list of map names.



4 Click [Select from Map] to set ASCENT’s initial position and attitude.

5 Click the [OK] button.**■ Add the 2nd floor movement and audio recording motion**

On the 2nd floor, create a path motion to move to the target, a motion to record the sound around the target, then another return to the stairs.

First register the target where the audio is to be recorded, then add the motions in the following order.

- path
- record-audio
- path
- rotate-to-point


First register the target where the surrounding sound is to be recorded.

1 Open the 2nd floor map with Scenario Maker.

On the [Layer] tab, right-click the 2nd floor map and select [Set to Current Map].

2 On the [Object] tab, click [Target], then click where you want to record the audio.**3 Right-click on the target icon and select [edit].**


4 Enter the Target Name and click the [OK] button.



Next, create motions for the path and audio recording.

5 Record the path from the stairs to the target.

6 Add a new motion after the load-map motion and select “path” from the list.



7 Select the path recorded according to the steps in 5.

8 Add another new motion after the path motion and select “record-audio” from the list.

- 9** Click the [Object Selection] button, then click the target icon on the map.

- 10** Specify the recording time and volume, and click the [OK] button.
- 11** Record the path from the target to the stairs.
- 12** Add a new motion after the record-audio motion and select “path” from the list.
- 13** Select the path recorded according to the steps in11.
- 14** Click the [select from map] button for [Stopped Heading] and point the arrow at the stairs.
- 15** Click the [OK] button.

 **WARNING**

- **ASCENT must be aligned to face the stairs.**
If ASCENT attempts to climb stairs diagonally, it may lose its balance and topple over.

■ Define a motion to descend the stairs

The motion to descend the stairs is defined just like that for ascending the stairs.


No align motion is available when descending stairs.

WARNING

- **If a marker-like reflector or other marker is near a stairs marker, it will need to be removed.**

When another marker or reflector is nearby, ASCENT may incorrectly detect its marker and collide, fall, or slip.


1 Add the motion after the rotate-to-point motion.



2 Select “stairs” from the list.

The motion property screen appears.

3 Click the [Object Selection] button, then click the stairs icon on the map.



4 Select [Descend].

5 Click the [OK] button.


■ Define motions to load the 1st floor map and move to the Charging Station

Drive ASCENT to the 1st floor and define the motions after descending the stairs.

First define a load-map motion to load the 1st floor map.

Then define the path motion from the stairs to the Charging Station.

1 Add a load-map motion after the descending stairs motion.



2 Select the 1st floor map in the motion properties.


3 Record the path from the stairs to the Charging Station.

4 Add a new motion after the load-map motion and select "path" from the list.

5 Select the path recorded in Procedure 3.

6 Click the [select from map] button for [Stopped Heading] and set the arrow to point at the correct heading to enter the Charging Station.

7 Click the [OK] button.



Make sure the scenario you created is the same as the one shown in page 7-73.

7.11.7 Test run the scenario

After creating a scenario, test it to ensure that it works.

See “7.7 Test Run the Scenario” (page 7-57) for details on how to execute the scenario.

DANGER

- **When ASCENT is traversing stairs, stay away from the bottom of the stairs.**
If ASCENT slips and hits you, there is a danger of serious injury, such as broken bones.


WARNING

- **When testing a scenario, be sure that an attendant accompanies ASCENT to monitor its status.**
- **When ASCENT is being driven on stairs, an attendant must ensure that ASCENT moves straight along the stairs.**
If ASCENT enters stairs diagonally, it may lose its balance and fall or slip.

7.12 Measuring the Pinpoint Temperature of a Heat Source Object

Measure the temperature at a pin-point target location.


In order to measure the temperature at a heat source correctly, the precise position of the heat source must be indicated by markers.




Two types of markers are used to register a heat source object.

- Positioning markers (2)
These markers accurately indicate the position of the heat source (temperature measurement target) so that it can be correctly imaged with the thermal imaging camera during automatic patrol. These are located within about two meters in front of ASCENT.
- Heat source teaching marker (1)
This marker indicates the precise position of the heat source when registering the heat source object. It can be removed after registering the object.

Positioning marker



Heat source teaching marker




7.12.1 Considering where to capture an image of the heat source object

ASCENT has a thermal imaging camera on each side. When shooting with a thermal imaging camera, ASCENT should face sideways to the heat source.


To image a heat source object, consider where to stop ASCENT and whether to use the left or right thermal imaging camera.

Also, since positioning markers are required to accurately measure the position of the heat source object, confirm there is room for the markers to be placed in front of the imaging position. Check for other markers or reflectors near the positioning markers. If there are other markers or reflectors, ASCENT may misdetect the markers and be unable to make correct measurements.

Using the right-side thermal imaging camera



Using the left-side thermal imaging camera



■ About distances from the heat source and markers

Distance from heat source


The distance of the thermal imaging camera from the heat source should be about 2 to 3 m. At distances less than or greater than that, measurement can still be performed as long as the heat source is visible on the thermal imaging camera, but measurement accuracy will be lower if the heat source is farther away.

Distance to the markers

As a guide, the distance from the center of ASCENT to the markers should be about 2 m. If they cannot be installed at a distance of 2 m, install them within the range of 1 to 3 m.

Distance between markers

As a guide, the distance between the two markers should be about 0.5 m. If there are no other markers in the vicinity, the space may be wider. If there is another marker in the vicinity, it may be mistakenly recognized. When there are multiple markers, they will be detected in order starting with the nearest.



7.12.2 Start creating the scenario


Modify the existing scenario to create a scenario similar to the following. Add a motion to measure pinpoint temperature near the end of the existing scenario (from line 18 onwards).

| Line No. | Motion | ASCENT behavior |
|----------|------------------|--|
| 1 | charging-station | Exit the Charging Station |
| 2 | load-map | Load a map |
| 3 | path | Move to a target |
| 4 | rotate-to-point | Face the step |
| 5 | obstacle | Drive over a step |
| 6 | path | Move to a target |
| 7 | arm-joint | Extend the manipulator |
| 8 | record-image | Capture a still image |
| 9 | arm-joint | Restore the manipulator |
| 10 | path | Go to the stairs |
| 11 | align | Face the stairs |
| 12 | stairs | Climb the stairs |
| 13 | load-map | Load the 2nd floor map |
| 14 | path | Move to a target |
| 15 | record-gas | Measure gas concentration |
| 16 | path | Move to the stairs |
| 17 | rotate-to-point | Face the stairs |
| 18 | stairs | Descend the stairs |
| 19 | load-map | Load the 1st floor map |
| 20 | path | Move to the heat source imaging position |
| 21 | record-thermal | Measure the pinpoint temperature |
| 22 | path | Move to the Charging Station |
| 23 | rotate-to-point | Turn around for docking |
| 24 | charging-station | Dock in the Charging Station |

- 1** Open the [Project] tab in Scenario Maker.
- 2** Click [Open Scenario].
- 3** Select the scenario you created in “7.11 Adding Stairs” (page 7-65), and click the [OK] button.

7.12.3 Define a motion to move to the heat source imaging position

- 1 Execute [Scenario Load] on the [Execute] tab of Scenario Maker.
- 2 Teleoperate ASCENT to drive it to the bottom of the stairs (the position where the stairs motion of the existing scenario ends).
- 3 Start path recording with Scenario Maker.
- 4 Teleoperate ASCENT to drive it to the heat source object imaging position.
- 5 Stop path recording and save the path.
- 6 Click on [...] for the path motion in the 20th line of the scenario.



The motion property screen appears.

- 7 Change the reference path to the path saved in step 5.

7.12.4 Register (teach) the heat source object

- 1 Open the [Predefined Motions (Navi)] tab on the Teleop screen.
- 2 Click the [Video] button under [360° optical camera] in the [Predefined Motions] panel.
The image of the 360° optical camera appears. The frames appearing in this image represent the fields of view of the thermal imaging cameras. Adjust the position of ASCENT so that the heat source is within a field of view.




- 3 Select [Thermal Image Teaching] in the [Predefined Motions] panel and click [Execute].



The [Thermal Image Teaching] screen appears.

- 4** In [Heat source camera select], choose [Left] or [Right] according to the location of the heat source.



- 5** Select [360° Image] in [Distribution].

The 360° optical camera image on the side with the heat source is displayed. The frames appearing in this image represent the fields of view of the thermal imaging cameras.




Thermal imaging camera field of view

Next determine the position of ASCENT when imaging.

6 Install two positioning markers.

The two markers are installed in front of ASCENT, where 3D LiDAR can catch them. Install the two markers as near as possible to 50 cm apart. Read “About distances from the heat source and markers” (page 7-89) for details about the installation position of the markers.



Temporarily place the markers, then confirm that each positioning marker appears as ① or ② in [Marker Information] on the [Thermal Image Teaching] screen, and if so, affix the markers.

10

Thermal Image Teaching

Teaching Operation

Distribution 360° Image Thermal Image

Heat source camera select Left Right

Sub track right front

Thermal Image Normalization
(Average + Standard Deviation)

Normalization u1 u2

Range v1 v2

Standard Deviation Multiple [%]

8 Distance between Camera and Temperature Measurement Point [m]

Temperature measurement point coordinates Manual setting

Center of normalization range

Manual

u v

Marker Information

Acquisition Stop Acquiring Acquisition Start

1m 2m 3m

Teaching Result

LiDAR Marker Coordinate X[m]


Temperature Measurement Point Position Y[m]

Z[m]

12 **12**

If a marker number does appear on the [Thermal Image Teaching] screen, reposition the marker while checking the screen.

- 7** Measure the distance between the thermal imaging camera and the heat source with a tape measure.



- 8** Enter the distance measured in [Distance between Camera and Temperature Measurement Point] on the [Thermal Image Teaching] screen.
Next, teach the temperature measurement point.

- 9** Place the thermal image teaching marker in front of the heat source.



Teaching marker


10 Select [Thermal Image] in [Distribution].

The image from the 360° optical camera displayed in the [Predefined Motions (Navi)] tab changes to that from the thermal imaging camera. A green square appears at the center of the image.



Depending on the attitude of the sub tracks, one may obstruct the view of the thermal imaging camera, and the heat source may not be visible or the image may be distorted. In that case, click the [Down (5°)] button to lower the sub tracks on the thermal imaging camera side.


11 While watching the thermal camera image on the Teleop screen, press the D-pad keys on the gamepad to move the green frame on the screen to the position of the teaching marker.



12 Click the [Teaching Settings] button.

The teaching settings are processed and the still images captured by the thermal imaging camera and the 360° optical camera are displayed. If teaching succeeded, a red cross will appear in the center of the teaching marker on the still image of the thermal imaging camera.

Also, XYZ coordinates appear for the [Teaching Result] on the [Thermal Image Teaching] screen.





If the message “Teaching failed” appears

Change the size and position of the green frame and retry with the new teaching settings.

If you examine the teaching marker in the thermal image, the border appears dark with a slightly brighter inside area. When teaching, the teaching position settings are determined by the border and the brightness inside the border. If anything inside the green frame appears brighter than the area inside of the border, it may interfere and prevent correct detection. Therefore, if anything bright is in the green frame, reposition or reduce the size of the frame to exclude it.


The whole teaching marker does not need to be included in the green frame.

| Failure Example | Success Example |
|--|--|
|  <p data-bbox="197 987 751 1093">An object (human hand) appears brighter than the teaching marker in the green frame, so the teaching frame cannot be identified.</p> |  <p data-bbox="804 987 1382 1131">Reduce the size of the green frame to exclude bright objects. Although part of the teaching marker is outside of the green frame, there is no problem with teaching.</p> |

Moving and resizing the green frame

Move the green frame using the D-pad keys on the gamepad.

Resize the green frame by changing the [Normalization Range] values on the [Thermal Image Teaching] screen. The [Normalization Range] specifies the coordinates of the upper left (U1, V1) and lower right (U2, V2) of the green frame. Change the values as needed and click the [Change Image] button. The position and size of the green frame will change.




For manual setting case

If teaching still fails after the above procedure, use the following procedure to manually specify the temperature measurement point.

- 1** Check [Temperature measurement point coordinates Manual setting].
- 2** Move the green frame with the D-pad keys on the gamepad so that the temperature measurement point is centered in the frame.
- 3** Click the [Teaching Settings] button.

■ Propagating teaching results to the heat source object


- 1 Open the Scenario Maker's [Object] tab.
- 2 Click [Heat Source], move the mouse over the map, and place the icon on the heat source object.



- 3 Right-click on the heat source icon and select [edit].
The Heat Source Setting screen appears.

4 Click [Teaching Result Acquisition].

The teaching results for the heat source object are acquired from the Teleop screen.



The image shows a dialog box titled "Heat Source Setting" with a close button (X) in the top right corner. The dialog contains the following fields and values:

| | | |
|---------------------------|-----------------------------|-----|
| Target Name | New Registration | ... |
| | Flir002 | |
| X Coordinate (m) | 6.660 | |
| Y Coordinate (m) | 0.273 | |
| Angle (deg) | 0.000 | |
| Teaching Data | Teaching Result Acquisition | |
| Camera Used | Right | |
| Marker 1 Coordinate X (m) | 1.098 | |
| Marker 1 Coordinate Y (m) | 0.004 | |
| Marker 2 Coordinate X (m) | 1.062 | |
| Marker 2 Coordinate Y (m) | -1.356 | |
| Target Distance (m) | 2.5 | |
| Target Coordinate U | 252 | |
| Target Coordinate V | 171 | |

At the bottom of the dialog, there are two buttons: "Cancel" and "OK".

5 Select [New Registration] in the [Target Name] list and enter a name in the text box below.**6 Click the [OK] button.**

A Target ID is assigned, and the target information is saved in the cloud.

7.12.5 Defining motions

Add a record-thermal motion to the scenario and extend the scenario to return to and enter the Charging Station.


1 Add a new motion after the path motion (line 20).



2 Select “record-thermal” from the list of motions.

The motion property screen appears.

3 Click the [Object Selection] button, then click the Heat Source icon on the map.



4 Click the [OK] button.

- 5** Record the path from the heat source object image capture location to the Charging Station.
- 6** Add a new motion after the record-thermal motion, and select “path” from the list.
- 7** Select the path recorded in Procedure 4.
- 8** Click the [select from map] button for [Stopped Heading] and set the arrow to point at the correct heading to enter the Charging Station.
- 9** Click the [OK] button.

Make sure the scenario you created is the same as the one shown in page 7-90.

7.12.6 Test run the scenario

After creating a scenario, test it to ensure that it works.

See “7.7 Test Run the Scenario” (page 7-57) for details on how to execute the scenario.



WARNING


- **When testing a scenario, be sure that an attendant accompanies ASCENT to monitor its status.**

7.13 Scenario Creation Example for Areas Separated By Stairs/Steps

7.13.1 For areas separated by stairs


■ Mapping procedure

This example creates maps for traveling on two floors with stairs in between, as shown in the figure below.



- 1** Create and save a map of 1st floor “a” (1F-a).
- 2** Climb the stairs to the 2nd floor.
- 3** Create and save a map of the 2nd floor (2F).
Rotate in place and measure in all directions.
- 4** Descend the stairs to 1st floor “b” (1F-b).
- 5** Create and save a 1F-b map.

■ Scenario creation example



| Line No. | Motion | Contents |
|----------|-------------------|--------------------------------------|
| 1 | charging-station | Exit |
| 2 | load-map | Load the 1F-a map. |
| 3 | path | Move to the bottom of the stairs (①) |
| 4 | rotate-to-heading | Face the stairs (②) |
| 5 | stairs | Ascend the stairs (③) |
| 6 | load-map | Load the map of the 2nd floor (④) |
| 7 | path | Move to the top of the stairs (⑤) |
| 8 | rotate-to-heading | Face the stairs (⑥) |
| 9 | stairs | Descend the stairs (⑦) |
| 10 | load-map | Load the 1F-b map (⑧) |
| 11 | path | Move on the 1F-b path (⑨) |

Note


- A load-map motion must precede the path motion. If a path motion is executed without a preceding load-map motion, a scenario execution error occurs. (“15.2.1 Scenario errors” (page 15-3))
- If the stairs are narrow and do not need to be driven, the path motion of line 7 is unnecessary. The load-map motion on the 6th line and the rotate-to-heading motion on the 8th line are still required.

7.13.2 When a floor is completely bisected by a step

■ Mapping procedure


In the following case, create a map of each area (left and right) with the step in between.

If possible to make a single map by driving around without crossing the step, its unnecessary to create maps for the two areas.



- 1** Create and save a map of 1F-a.
- 2** Cross the step to move to 1F-b.
- 3** Create and save a map of 1F-b.


■ Scenario creation example




| Line No. | Motion | Contents |
|----------|-------------------|-----------------------------------|
| 1 | charging-station | Exit |
| 2 | load-map | Load the 1F-a map. |
| 3 | path | Move to the front of the step (①) |
| 4 | rotate-to-heading | Face the step (②) |
| 5 | obstacle | Cross the step (③) |
| 6 | load-map | Load the map of 1F-b (④) |
| 7 | path | Move along the path of 1F-b (⑤) |

7.13.3 When there is a ramp between areas

This example creates a scenario when there is a ramp between areas.
 The maximum allowable height of the ramp is about one meter (depending on the environment).



■ Scenario creation example



| Line No. | Motion | Contents |
|----------|------------------|---|
| 1 | charging-station | Exit |
| 2 | load-map | Load the map of the 1st floor |
| 3 | path | Move to the bottom of the ramp (①) |
| 4 | subtrack | Set the sub track angles to 33 degrees in front and -33 degrees in back (②) |
| 5 | path | Move onto the ramp (③) • Set the end of the path to the end of the ramp • Turn off Obstacle Detection |
| 6 | subtrack | Set the front and back sub track angles to 110 degrees (④) |
| 7 | load-map | Load the 2nd floor map |
| 8 | path | Move on the 2nd floor path |

Chapter 8 Creating a Map

This section describes the procedures for creating maps and registering objects using Scenario Maker.

Before creating a map, consider the inspection target locations and the patrol route.


To create a map, drive ASCENT around the patrol area.

The person operating Scenario Maker and the Teleop Terminal needs to work together with an attendant accompanying ASCENT around the patrol area. Maintain contact by mobile phone to confirm the situation around ASCENT.

8.1 Scenario Maker Screen Configuration

This section describes the screen configuration of Scenario Maker.

When launching Scenario Maker, the following screen appears.



■ Scenario status

The execution status of a scenario is displayed when the scenario is executed by Scenario Maker.

| Status | Description and Action |
|----------------------------------|---|
| Waiting for scenario to load | No scenario is loaded in ASCENT. To execute a scenario in ASCENT, click the [Scenario Load] button to load the scenario. |
| Sending scenario | The scenario is being sent to ASCENT. |
| Loading scenario | ASCENT is loading the scenario. |
| Waiting for start | After loading the scenario, ASCENT is ready to execute it. |
| Scenario running | ASCENT is executing the scenario. |
| Scenario paused | The scenario is paused in ASCENT. |
| Another scenario is running | ASCENT is running another scenario. |
| Robot communication not possible | Cannot communicate with ASCENT. Check the communication status. |
| Scenario data error | There is an error in the scenario data sent to ASCENT. Hover the mouse over the scenario status to see the scenario error. For details, see “15.2 Troubles Using Scenario Maker” (page 15-3). |
| Scenario ZIP error | There is an error in the scenario ZIP data sent to ASCENT. |
| Error occurred | An anomaly occurred while running the scenario. |
| Unknown error | An unknown error occurred. |

■ [Viewpoint Reset] button

Switches the map perspective to directly overhead.

■ [Project] tab

Use to start creating a scenario or map, or to open an existing scenario or map. These tabs display menu buttons, maps, and scenario information.

Menu buttons

| Button | Description |
|---------------------|--|
| Create New Scenario | Starts creating a new scenario. |
| Open Scenario | Opens an existing scenario. |
| Create New Map | Starts creating a new map. |
| Open Map | Opens a created map. |
| Save Scenario | Saves the scenario being editing. |
| Options | Sets whether to allow expert settings. It also displays the name of the connected robot and the version of Scenario Maker. |
| End | Closes Scenario Maker. |

■ [Execute] tab

Use when creating a scenario. For details on the operating method, see “Chapter 9 Creating a Scenario” (page 9-1).

■ [Object] tab

Use to register an object on a map. For details on the operating method, see “8.5 Registering Objects” (page 8-9).

■ [Layer] tab

Displays a map of each floor used in a scenario.
Click the [+] button to open a map.

■ [Scenario] tab

Specify the motions to execute in the scenario, their order of execution, and the behavior of each motion.

■ Map area

Displays the map being used in the scenario and indicates the location of ASCENT.

8.2 Basic Procedure for Creating Maps/Scenarios

This is the basic procedure for creating a map/scenario. See the referenced chapters for details.

When creating maps and scenarios, ASCENT is controlled by teleoperation. Before operating ASCENT for the first time, read “Chapter 14 Basic ASCENT Operation” (page 14-1).


Also, before creating a map or scenario for the first time, read “Chapter 7 Creating a Simple Scenario” (page 7-1).

- 1 Start Scenario Maker and the teleoperation screen on the Teleop Terminal.**
- 2 Click [Create New Scenario] to start creating a scenario.**
- 3 Click [Create New Map] to start creating a map.**
- 4 Create a map by teleoperating ASCENT. (See “8.3 Creating a Map” (page 8-5))**
- 5 Name and save the map.**
- 6 Click [Open Map] in Scenario Maker to open the created map.**
- 7 Position object icons on the map. (See “8.5 Registering Objects” (page 8-9))**
Position icons for the Charging Station, targets (inspection points), heat source objects, stairs, and steps.
- 8 Define ASCENT’s behavior as a series of motions to be performed. (See “9.4 Add a Motion” (page 9-12))**
Define the motions by teleoperating ASCENT.
- 9 Test executing the created scenario. (See “9.6 Executing a Scenario” (page 9-45))**
If a scenario is not yet complete, you can execute just selected motions.
- 10 Name the scenario and save it to the cloud.**

8.3 Creating a Map

Create a map by teleoperating ASCENT.

- 1 Click **[Create New Map]** on the **[Project]** tab of **Scenario Maker**.
The screen changes to Map Creation Mode.




- 2 Open the **[Truck]** tab on the **Teleop** screen, and drive **ASCENT** around the patrol route.
As **ASCENT** moves, the map is created on the **Scenario Maker** screen.
Drive around the patrol area and return to the **Charging Station**.
Map creation has succeeded if the shapes of the walls surrounding the area are clearly delineated on the map. Proceed to the next step to save the map.
If walls appear on the map as multiple or distorted lines, map creation has failed. Click **[Clear Map]** and try recreating the map.
- 3 Click **[Store Map]** in **Scenario Maker**.
A dialog to enter the name of the map appears.
- 4 Enter the name of the map and click the **[Save]** button.
The map is saved on the **Teleop Terminal**.
- 5 Click **[End]**
Map Creation Mode exits as the previous **Scenario Maker** screen reappears.

To patrol different floors, create a map of each floor.

8.4 Key Points for Mapping Large Areas

This section provides some pointers for creating maps of large areas.

- The starting point for map creation does not necessarily have to be near the Charging Station. It's easiest to create a clear map by starting from a place like a corner with surrounding walls.
- Begin creating a map by driving a peripheral lap route with the largest possible circumference up to about 300 m.




- : This route laps the periphery, then “fills” the central passage (described later)
- △: This route takes a small lap around the left half, then loops around the right half
- ×: This route laps the right half, then fails to complete a full lap around the left half


Note

When mapping a large area, although the map may initially become misaligned during creation, you should continue driving without concern. There is no problem after the deviation is corrected (performed automatically) when map creation is finished (when saved).


- When the area’s periphery is more than 300 meters in circumference, divide it into multiple mapping areas.




- First make a rough map of the entire area, then go into the details to complete the map.





- When creating a map by driving a lap route, include at least some overlap.



- To drive on stairs or climb over a step of 200 mm or more, create separate maps for before and after the stairs or step. Do not drive on stairs or steps when creating a map.
- While creating a map, drive as close as possible (within 5 m) to structures such as walls.




- Mapping success or failure is determined by the presence of double imaging of walls and corners. It is easy to determine if there is a misalignment by temporarily installing a partition screen as shown in the photos below. However, if the screen is too large, autonomous driving may be adversely affected when it is removed, so it should be no larger than 1.5 m³.



One mark or wall appears doubled

Here is a sample map created at a location with about a 300-meter periphery. As mentioned above, the outer periphery was driven first, followed by inner details.



In the satellite image below, the mapped area is in the red frame.








Source: Google Map, Image © 2022 Google, © 2022 Digital Earth Technology, Maxar Technologies, Map Data © 2022

8.5 Registering Objects

Place the Charging Station and targets to be monitored on the map. Objects placed on the map are used to create a scenario.

The types of objects that can be registered are as follows.


| | | |
|--|---------------------|--|
|  | Charging Station | Registers the Charging Station. |
|  | Target | Registers an inspection target. This applies to still image capture, audio recording, and gas concentration measurement. |
|  | Heat Source Object | Registers a location where pinpoint temperature is to be measured using a thermal imaging camera. |
|  | Stairs | Registers stairs that ASCENT will traverse when patrolling. |
|  | Difference in level | Registers a step that ASCENT will traverse when patrolling. |

The location of an icon on the map is merely a guide. The precise position is specified later by actual teleoperation when creating the scenario.

8.5.1 Basic object registration procedure

The procedure common to all objects is shown below.

- 1** Click [Open Map] on the [Project] tab of Scenario Maker.
- 2** Select a map and click [OK].
- 3** Open the [Object] tab.
- 4** Click the object type, move the mouse to the map, and click the desired placement location.



- 5** Right-click the icon of the placed object and select [edit].
- 6** Make appropriate settings in the object's dialog box.
The object's settings are saved in the cloud.

■ To delete an object

Right-click on the icon on the map and select [delete].

8.5.2 Charging Station placement

Click [Charging Station], move the mouse to the map, and click the desired placement location. There are no setting items for the Charging Station, so registration is complete.

8.5.3 Target placement

Register a target location where you want to capture a still image, record audio, or measure gas concentration.

- 1** Click [Target], move the mouse to the map, and click the desired placement location.
- 2** Right-click on the target icon and select [edit].
The [Target Setting] screen appears.
- 3** Select [New Registration] in the [Target Name] list and enter a name in the text box below.

- 4** Click the [OK] button.
A Target ID is assigned, and the target information is saved in the cloud.

■ Setting up a previously registered target

To use a target previously registered in another scenario, perform the following operations on the [Target Settings] screen.

- 1** Click the [...] button for the [Target Name] and select [Targets List Acquisition].
- 2** Select the target name from the [Target Name] list.

8.5.4 Heat source object placement

In order to register a heat source object, markers must be installed and teaching performed in advance.

For detailed instructions, see “7.12 Measuring the Pinpoint Temperature of a Heat Source Object” (page 7-86).

8.5.5 Stairs registration


To have ASCENT drive on stairs, place the stairs object on the map and enter the actual measured dimensions of the stairs.

Measure the width, height and depth of the stairs, and landing dimensions in advance. Also install markers at the stairs. (→“5.3 Stairs and Steps Measurement” (page 5-11), “5.4 Stair Marker Installation” (page 5-15))

For details on ASCENT’s stair requirements, see“1.4 ASCENT Driving Performance” (page 1-6).

■ New registration of stairs

- 1** Click [Stairs], move the mouse to the map, and click the desired placement location.
- 2** Right-click on the Stairs icon and select [edit].
The settings screen appears.
- 3** Enter the registration [Name] for the stairs.
- 4** Select the shape of the stairs in [Landing].



| | |
|----------|--|
| None | Select for stairs without a landing. |
| I-shaped | Select for in-line stairs with a bisecting landing. |
| L-shaped | Select for stairs that turn left or right at the landing. Select [Left turn] or [Right turn] according to the (upwards) direction of the turn. |
| U-shaped | Select for stairs having a U-shaped landing. Select [Left turn] or [Right turn] according to the (upwards) direction of the turn. |

5 Enter stairs dimensions in mm: [Stair 1], [Stair 2], and [Landing Dimensions].

[Stair 1] are for stairs going up to the landing, and [Stair 2] are for those going down from the landing. If there is no landing, enter only [Stair 1].

The dimensions to enter are:

- The width of the stairs
- First step height and depth
- Last step height and depth
- Middle step height and depth
- Number of Steps

Also, enter the width and depth of the landing in [Landing Dimensions].

6 Click the [OK] button.

Stairs information is stored in the cloud.

■ Using previously registered stairs

On the Stairs Settings screen, select the previously registered stairs name in [Select Stairs].

1 Click [Stairs], move the mouse to the map, and click the desired placement location.**2 Right-click on the Stairs icon and select [edit].**

The settings screen appears.

3 Select the name of the previously registered stairs in [Select Stairs].

The dimensions of the selected stairs are entered.

3 Select Stairs ...

4 Copy

Landing None I-shaped L-shaped U-shaped

Left turn Right turn

Affiliated Plant Name Building DE

X Coordinate (m) 0.427
Y Coordinate (m) 2.043
Angle (deg) 0.000

Connect to lower stairs

Same as at left

| Dimensions [mm] | Stair 1 | Stair 2 |
|-----------------------|---------|---------|
| a Step Width | 900 | 900 |
| b Initial Step Height | 222 | 195 |
| c Initial Step Depth | 233 | 230 |
| d Height | 200 | 194 |
| e Depth | 230 | 230 |
| f Final Step Height | 191 | 208 |
| g Final Step Depth | 233 | 329 |
| Number of Steps | 0 | 0 |

Landing Dimensions [mm]
h Width 1860
i Depth 1000

Cancel OK

4 Uncheck [Copy].**5 Click the [OK] button.**

The registered stairs settings are used as is.

■ Create new stairs by reusing previously registered stairs settings

You can modify the settings of previously registered stairs to create new stairs.

- 1** Click [Stairs], move the mouse to the map, and click the desired placement location.
- 2** Right-click on the Stairs icon and select [edit].
The settings screen appears.
- 3** Select the name of the previously registered stairs in [Select Stairs].

3 Select Stairs

4 Name

5 Copy

6

| Dimensions [mm] | Stair 1 | Stair 2 |
|-----------------------|---------|---------|
| a Step Width | 900 | 900 |
| b Initial Step Height | 222 | 195 |
| c Initial Step Depth | 233 | 230 |
| d Height | 200 | 194 |
| e Depth | 230 | 230 |
| f Final Step Height | 191 | 208 |
| g Final Step Depth | 233 | 329 |
| Number of Steps | 0 | 0 |


- 4** Enter a new stairs (staircase) name in [Name].
- 5** Check [Copy].
- 6** Change the values for the stairs and landing as needed.
- 7** Click the [OK] button.

■ Add stairs and landings to previously registered stairs and register as new stairs

If there are more stairs or landings after previously registered stairs, you can add settings to the existing stairs and register them as new stairs.

Here, the original stairs are referred to as “stair_A” and the new stairs are referred to as “stair_B”.


- 1 Click [Stairs], move the mouse to the map, and click the desired placement location.
- 2 Right-click on the Stairs icon and select [edit].
The settings screen appears.
- 3 Select “stair_A” in [Select Stairs].



- 4 Enter “stair_B” in [Name].
- 5 Check [Connect to lower stairs] and select “stair_A” from the list below.
The dimensions of the selected stairs are displayed in [Stair 1]. [Stair 1] cannot be modified.
- 6 Enter the measured values for [Stair 2] and [Landing Dimensions].

7 Click the [OK] button.

A new staircase (stair_B) is registered as a staircase that includes the original staircase (stair_A).



Note

To move from the 1st to the 2nd floor of the figure, select "stair_B" as the stairs motion object. It is not necessary to specify "stair_A".

8.5.6 Step registration

To register a step, measure the height (front and back sides in the direction of travel) and depth of the step in advance.

1 Click [Steps], move the mouse to the map, and click the desired placement location.

2 Right-click on the Step icon and select [edit].

The settings screen appears.

3 Enter the heights and depth.

Height A: Enter the height of the front side in the direction of travel.

Height B: Enter the height of the back side in the direction of travel.

Depth: Enter the depth of the step.

4 Click [OK].

Step information is saved in the cloud.

Note

For a step that only ascends, enter the value of Height A, and 0 for Height B and depth. For a step that only descends, enter the value of Height B, and 0 for Height A and depth.

MEMO

Chapter 9 Creating a Scenario

9.1 Scenario Creation Overview

A scenario is a sequence of instructions that define ASCENT's behavior during automatic patrol. All scenarios begin and end with undocking (Exit) and docking (Entry) from/to the Charging Station. Between those events are defined ASCENT's movements and target inspection actions (still and thermal image capture, sound recording, etc.).

Every action such as undocking/docking, movement, and inspection is defined by a command called a "motion".

The standard scenario flow is as follows.

| ASCENT behavior | Motion |
|----------------------------------|-------------------------------|
| Exit Charging Station | charging-station |
| Load the 1st floor map | load-map |
| Move to a target | path rotate-to-point, etc. |
| Capture the target image | record-image |
| Move to next target | path rotate-to-point, etc. |
| Measure pinpoint temperature | record-thermal |
| Move to stairs | path align etc. |
| Climb the stairs | stairs |
| Load the 2nd floor map | load-map |
| Move to a target | path rotate-to-point, etc. |
| Record target audio | record-audio |
| Move to stairs | path rotate-to-point, etc. |
| Descend the stairs | stairs |
| Load the 1st floor map | load-map |
| Return to Charging Station | path rotate-to-point, etc. |
| Dock at Charging Station (Entry) | charging-station |

9.1.1 Motion list

Each operation such as docking /undocking, movement, and inspection is defined by a “motion” command.

Here are the types of motions:


| Name | Description | Page |
|-------------------|--|------|
| align | Turn ASCENT to face an object (wall, stairs, etc.). | 9-20 |
| arm-delta | Move the manipulator by specifying position or attitude deviation. | 9-29 |
| arm-joint | Change the attitude of the manipulator. | 9-26 |
| charging-station | Undock (Exit) and dock (Entry) from/to the Charging Station. | 9-12 |
| hand | Open and close the manipulator hand. | 9-31 |
| led | Switch the LED lighting on/off. | 9-37 |
| load-map | Load a map. | 9-13 |
| move-to-point | Move in a straight line to a specified point. | 9-18 |
| obstacle | Drive over a step. | 9-39 |
| path | Move on a specified path. | 9-15 |
| play-audio | Play a sound source. | 9-41 |
| record-audio | Record ambient sound. | 9-36 |
| record-gas | Measure gas concentration. | 9-35 |
| record-image | Capture a still image. | 9-32 |
| record-thermal | Measure the pinpoint temperature. | 9-34 |
| rotate-to-heading | Turn to face the specified direction. | 9-20 |
| rotate-to-point | Turn to face the specified point. | 9-19 |
| stairs | Ascend and descend stairs. | 9-38 |
| stop-audio | Stop playing the sound source. | 9-41 |
| subtrack | Change the angles of the sub tracks. | 9-40 |
| wait | Wait for the specified number of seconds. | 9-42 |

9.2 Start Creating a Scenario

9.2.1 Creating a new scenario

To create a new scenario, click [Create New Scenario] on the [Project] tab in Scenario Maker.

To open a saved scenario, select [Open Scenario] on the [Project] tab.



9.2.2 Re-use an existing scenario

You can create a new scenario by re-using an existing scenario.

If you re-use an existing scenario, maps registered in the existing scenario can be used as-is. You can also add new maps.

To create a new scenario from an existing scenario, open the existing scenario with [Open Scenario] on the [Project] tab of Scenario Maker, and save it with a different name using [Save Scenario].


9.2.3 Opening the map

Open the map(s) used in the scenario.

To open a map, select [Open Map] on the [Project] tab.

You can also open it by clicking the [+] button on the [Layer] tab.

[Layer] tab



To move on multiple floors, open the maps for all floors.

9.2.4 Expert settings

Enable expert settings to make the following settings on the [Project] tab:

| Item | Function |
|---|--|
| Self-diagnostics (Perform before patrol/ Perform after patrol) | Set whether to perform self-diagnostics before or after the patrol. |
| Status Output Cycle | Set how often the status is sent to the cloud during scenario execution. |
| Periodic Image Upload | Set the interval for uploading images from the 360° optical camera to the cloud. |
| Angle Deviation Tolerance during Turns | Set the turning angle tolerance. |

To enable expert settings, set [Enable Expert Settings] to [Setting Enabled] under [Option] on the [Project] tab.

9.3 Basic Motion Operations

Create a scenario on the [Scenario] tab. Define the motions that ASCENT will perform in the order of execution.

Two motions, charging-station undocking (Exit) and charging-station docking (Entry), are automatically set for any new scenario. All other motions are added between these.

9.3.1 [Scenario] tab screen configuration

The [Scenario] tab for creating scenarios has the following screen configuration.

The screenshot shows the [Scenario] tab interface with the following elements and annotations:

- Layer** and **Scenario** tabs at the top.
- Line No. 1:** A dropdown menu showing "charging-station" with a plus sign (+) to its right. An annotation points to this dropdown as "Motion name".
- Exit:** Text below the first dropdown with a plus sign (+) to its right. An annotation points to the plus sign as "Select a motion".
- map0530:** Text below "Exit" with a plus sign (+) to its right.
- Line No. 2:** A dropdown menu showing "load-map" with a plus sign (+) to its right and a minus sign (-) to its left. An annotation points to the plus sign as "Display the motion property screen".
- map0530:** Text below "load-map" with a plus sign (+) to its right.
- Line No. 3:** A dropdown menu showing "path" with a plus sign (+) to its right and a minus sign (-) to its left. An annotation points to the plus sign as "Add motion before".
- path001:** Text below "path" with a plus sign (+) to its right. An annotation points to the plus sign as "Delete motion".
- map0530:** Text below "path001" with a plus sign (+) to its right. An annotation points to the plus sign as "Add motion after".
- Map name:** Text "map0530" with a plus sign (+) to its right. An annotation points to the plus sign as "Map name".
- Line No. 4:** A dropdown menu showing "rotate-to-point" with a plus sign (+) to its right and a minus sign (-) to its left. An annotation points to the plus sign as "Motion content".
- Motion content:** Text "map: [3.636, -4.138]" with a plus sign (+) to its right.
- map0530:** Text below "rotate-to-point" with a plus sign (+) to its right.
- Line No. 5:** A dropdown menu showing "charging-station" with a plus sign (+) to its right and a minus sign (-) to its left.
- Entry:** Text below the fifth dropdown with a plus sign (+) to its right.


9.3.2 Add a motion

To add a motion, do the following:


1 Click one of the **[+]** buttons to the right of an existing motion.

Click the **[+]** button above a motion add it before the motion, or click the **[+]** button below a motion to add it after the motion.

Clicking adds a blank motion with no name.



2 Click ▼ and select the desired motion name to be added from the list.



The setting screen for that motion appears.
For motions that do not require any settings, no setting screen appears.

3 Make the motion settings.

For each motion's settings, see "9.4 Add a Motion" (page 9-12).

■ Delete a motion

To delete a motion, click the [-] button at the right side of the motion.
The corresponding motion is deleted, and subsequent motions shift up.

■ Change a motion

To change the execution order of motions, drag and drop them as needed.

Use the ↶ (Undo) and ↷ (Redo) buttons to undo or redo the most recent addition or motion edit.

9.3.3 Motion grouping


You can group a series of motions. For example, you can make long scenarios easier to view by grouping first floor motions and second floor motions.

Grouped motions can be collapsed to show only the group name.

1 Right-click on a motion and select [Create Group].


A group containing only the selected motion will be created, and the group name can be entered.

2 Enter the group name.




3 To add other motions, drag and drop the motions you want to add into the group.

4 Drag and drop all of the motions you want to add into the group as in step 3.



■ Collapse and display groups

Click the group name to collapse the motions in the group and display only the group name. Click the group name again to see all of its motions.



■ Delete a group

1 Right-click on the group name to display the menu.

2 Click [Delete only group] or [Delete group and its contents].

- Delete only group: deletes only the group name and leaves the motions as they are. The execution behavior of the scenario is unchanged.
- Delete group and its contents: deletes the group name and motions within the group.

Groups cannot be moved or copied.

One group cannot be created within another group.

9.4 Add a Motion

This procedure describes how to add a motion to the scenario and define ASCENT's behavior.

When creating a motion, you can test it. For details on how to do this, see “9.6 Executing a Scenario” (page 9-45).

9.4.1 Entry/Exit


Docking (Entry) and undocking (Exit) are predefined charging-station motions. Select either [Entry] or [Exit] in the motion properties.

The procedure for adding a new Entry/Exit motion is shown below.

1 Click the [+] button to add a motion.

2 Select “charging-station” from the list.

The motion property screen appears.



3 Select either [Entry] or [Exit] and click [OK].

Whenever a new scenario is created, undocking (Exit) and docking (Entry) Charging Station motions are automatically added.

9.4.2 Loading a map

Load the floor map before traveling on a floor.

Map loading is defined by the load-map motion. Before a map can be loaded, it must be opened in Scenario Maker.

Load a map immediately after exiting the Charging Station, and after ascending/descending stairs to another floor. To move from one floor to another and back, maps need to be loaded three times: immediately after exiting the Charging Station, and immediately after going up and down stairs.

1 Click the [+] button to add a motion.

2 Select “load-map” from the list.


The motion property screen appears.

3 Select the map to load from [Map Name].

The list shows the names of currently open maps.

4 Set ASCENT’s initial position and attitude when the map is loaded.

Click the [Select from Map] button to move the mouse over the map and drag it to where ASCENT will be when the map is loaded. Move the arrow that appears so that its heading matches ASCENT’s heading, and then release the mouse button.



Numerical values are set for the [Initial Position Attitude].

load-map motion properties

| Item (units) | Description |
|---------------------------|--|
| Map Name | Select the map to load. You can select a map that has been opened in Scenario Maker. |
| Initial Position Attitude | Set ASCENT's position and attitude when the map is loaded. Click the [Select from Map] button to select a location on the map, and the values will be entered automatically. |
| X (m) | Set ASCENT's initial position on the XYZ axes. |
| Y (m) | |
| Z (m) | |
| Roll (deg) | Set ASCENT's initial attitude as roll, pitch, and yaw. |
| Pitch (deg) | |
| Yaw (deg) | |

9.4.3 Move to a target

The motion used to move to a target is described here.


■ Create a path

Specify the path for ASCENT to travel. The path is defined by the path motion.


Drive ASCENT by teleoperation to record the path, and register the recorded path as a motion.

Drive ASCENT as far away from the walls as possible. The obstacle detection function may stop operation when running autonomously.

- 1** Stop ASCENT at the start of the planned path.
- 2** Click [Scenario Load] on Scenario Maker's [Execute] tab to load the scenario you are creating into ASCENT.
- 3** Click [Robot Positions] and move the mouse to ASCENT's location on the map. An arrow appears when you drag the mouse, so you can align the arrow with ASCENT's heading, and release the mouse button.
- 4** Click the [Begin/end path recording] button on Scenario Maker's [Execute] tab. Path recording starts.




- 5** Open the [Truck] tab on the Teleop screen to remotely drive ASCENT. Drive the planned path and stop at the end.
- 6** Click the [Begin/end path recording] button again.
Path recording ends.
- 7** In the Path Name dialog that appears, enter the Path Name and click the [Save] button.



The path information is saved with the specified name. This name is the Reference Path used for setting the path as a path motion.

- 8** Add the motion on the [Scenario] tab.
- 9** Select “path” from the list of motions.
The settings screen appears.

- 10** Select the path created earlier as the [Reference Path].



- 11** To change the start/end point of a path from the Reference Path, click [select from map] for [Start] or [End], then click the new location of the start or end point on the map.
- 12** To change ASCENT’s heading when it stops, click the [select from map] button for [Stopped Heading].

When you specify [Stopped Heading], ASCENT moves to the end point when the scenario is executed, then turns and stops with the specified heading.

- 13** The arrow appears when you move the mouse on the map, so when the arrow points in the direction you want to stop, click the mouse.



- 14** Click the [OK] button.

When [Stopped Heading] is specified, a rotate-to-point motion is automatically added after the path motion to change the heading.

path motion properties

| Item (units) | Description |
|----------------------------------|---|
| Reference Path | Set a reference path. Click the [Edit] button to edit the selected path. |
| Speed (m/sec) | Select the path movement speed. <ul style="list-style-type: none"> • 0.1 m/sec • 0.2 m/sec • 0.3 m/sec (about 1.2 km/h) |
| Start (m) End (m) | Specify coordinates to change the start/end points of the reference path. Click the [select from map] button and click a point on the map to automatically enter its coordinates. Click the [Reset] button to reset the settings and revert to the start/end points of the reference path. |
| Goal Discrimination Distance (m) | Enter the discrimination distance of the end point. |
| Obstacle Detection | Enable/disable obstacle detection. |
| Stopped Heading (m) | Specify the heading when stopped. Click the [select from map] button and click on the map to set the heading. |
| Turning Speed (deg/sec) | Set the turning speed for Stopped Heading motion. |
| Offset (deg) | Specify the angle for fine tuning the Stopped Heading. Specify a positive value to turn counterclockwise, or a negative value to turn clockwise. |

■ Specify a destination point and move in a straight line

A “move-to-point” motion can also be used to move ASCENT. The move-to-point motion moves the ASCENT in a straight line to the specified point.

move-to-point property

Reference Point Select from Map

X m

Y m

Movement Speed 0.2 m/sec

Turning Speed 20 deg/sec

Goal Discrimination Distance 0.1 m

To use a move-to-point motion, click the [Select from Map] button and click the destination point on the map. Click to set the [X] and [Y] coordinates of the destination.

move-to-point motion properties

| Item (units) | Description |
|---------------------------------------|--|
| Reference Point • X (m) • Y (m) | ASCENT moves to the point specified by the X-Y coordinates. You can specify a point on the map by clicking the [Select from Map] button. |
| Movement Speed (m/sec) | Specify the movement speed. • 0.1 m/sec • 0.2 m/sec • 0.3 m/sec |
| Turning Speed (deg/sec) | Specify the turning speed. • 10 deg/sec • 20 deg/sec • 30 deg/sec |
| Goal Discrimination Distance (m) | Enter the discrimination distance of the end point. |

9.4.4 Adjusting ASCENT's heading

ASCENT can be turned to change its heading after moving.

The rotate-to-point and rotate-to-heading motions can be used to change the heading.

The align motion can also be used to turn ASCENT to face a staircase or wall.

■ rotate-to-point motion

Specify a target point and turn to face that point.

To use a “rotate-to-point” motion, click the [Select from Map] button and drag the mouse over the map to specify the target point.

A rotate-to-point motion is automatically inserted when [Stopped Heading] is specified for a path motion.

| Item (units) | Description |
|--|--|
| Reference Point <ul style="list-style-type: none"> • X (m) • Y (m) | ASCENT moves to the point specified by the X-Y coordinates. You can specify a point on the map by clicking the [Select from Map] button. |
| Turning Speed (deg/sec) | Specify the turning speed. <ul style="list-style-type: none"> • 10 deg/sec • 20 deg/sec • 30 deg/sec |
| Offset (deg) | Specify the angle for fine tuning the Stopped Heading. Specify a positive value to turn counterclockwise, or a negative value to turn clockwise. |

■ rotate-to-heading motion

Rotates ASCENT to a specified heading.

To use a “rotate-to-heading” motion, click the [Select from Map] button and drag the mouse on the map to display an arrow. Adjust the arrow to point to the desired heading for ASCENT, then release the mouse button.

| Item (units) | Description |
|-------------------------|---|
| Heading (deg) | Specifies the angle after turning. You can specify the angle on the map by clicking the [Select from Map] button. |
| Turning Speed (deg/sec) | Specify the turning speed. <ul style="list-style-type: none"> • 10 deg/sec • 20 deg/sec • 30 deg/sec |

■ align motion

Rotate ASCENT relative to a wall or staircase before a subsequent motion. Use when needed to face stairs and walls.

In the area specified in [Search Range], search for a flat surface such as a wall or a linear structure such as a stair step, and face it.

The height of the target structure should be at least 800 mm. If the target structure is too low, it cannot be detected.

After defining an align motion, try executing it several times to confirm the correct result.

If it does not face correctly, adjust the search range.

Target structures are easiest to find when 400 to 500 mm in front of ASCENT. If the distance between ASCENT and the target is too far or too near when executing the align motion, change the end point of the previous motion to adjust the distance to the structure.


align motion properties

| Item (units) | Description |
|---|--|
| Turning Speed (deg/sec) | Select the turning speed. <ul style="list-style-type: none"> • 10 deg/sec • 20 deg/sec • 30 deg/sec |
| Facing Target | Select the type of target to be faced. <ul style="list-style-type: none"> • line: A linear structure like a step or stair on a staircase • plane: A flat structure like a wall |
| Search Range X (m) <ul style="list-style-type: none"> • Min • Max | This is the range to search for the object on the X-Y-Z axes relative to ASCENT's 3D LiDAR as the origin. |
| Search Range Y (m) <ul style="list-style-type: none"> • Min • Max | |
| Search Range Z (m) <ul style="list-style-type: none"> • Min • Max | |
| Maximum Relative Angle (deg) | Set the angle limit for the object and ASCENT. |

9.4.5 Editing a path


You can edit a created path.


- 1 On the [Object] tab of Scenario Maker, click [Edit Path].




The [Edit Path] screen appears.

The [Edit Path] screen can also be displayed by clicking the [Edit] button to the right of [Reference Path] on the path motion property screen.



2 Select the target map with [Select Map], and select the path to edit with [Select path to edit].

The selected path is displayed on the map by a red line and arrows.




3 Edit the path.

You can perform the following operations.


Drag an arrow to change the path

Hover the mouse cursor over an arrow to display a red circle at the base of the arrow. Drag the circle to change the path.




Change the path by dragging the line connecting the arrows

Moving the mouse cursor over the line connecting the arrows changes that segment to a thick line. Dragging the line adds a new arrow and changes the path.




Delete an arrow

Display a menu by hovering the mouse over an arrow and right-clicking with the red circle displayed. Select [Delete] to delete the arrow. The front and back arrows are reconnected with a straight line.



You can specify the range of an arrow by dragging it with the mouse while right-clicking. You can select [Delete] to delete an arrow at once.



The following commands can be selected from the right-click menu.

| | |
|---------------------------|---|
| forward direction | Point the arrow in the direction of travel. An arrow pointing in the direction of travel does not change. |
| backward direction | Change the arrow to head opposite to the direction of travel. |
| change the last direction | You can select this for the arrow at the end of the path. It changes the arrow's heading at the end of the path. Select the command and drag the arrow to select a new direction. |

4 Click the [Save] button on the [Edit Path] screen.

The path is overwritten and saved.

■ Copying the original path to create a new path

If you do not want to overwrite the original path, copy the path to create a new path, then edit the new path.

1 Click the [Copy] button on the [Edit Path] screen.

2 Enter the name of the new path and click the [OK] button.

At this time, if you select [Reverse Path], you can create a path that heads opposite to the original path.

3 Edit the path.

Edit in the same way as the above procedure.

9.4.6 Manipulator operation


Move the manipulator to a specified position.

Use the arm-joint motion for manipulator operation.

Move the manipulator to the target position by teleoperation, and record the angle at that time with [Acquiring Current Angle] of the arm-joint motion.

1 Click the [+] button to add a motion.

2 Select “arm-joint” from the list.
The motion property screen appears.



3 Open the [Manip.] tab on the Teleop screen and move the manipulator to the target position.
(See “14.8 Manipulator Operation” (page 14-21))

4 Return to Scenario Maker and click the [Acquiring Current Angle] button.
The angle is set.

5 Click the [OK] button.

arm-joint motion properties

| Item (units) | Description |
|-----------------------------|--|
| Reference number | Specify the number to be used for referencing from another motion. To reference the angles of an existing motion, specify the reference number set in that motion. |
| Acquiring Current Angle | Acquire the current angles of the manipulator and set them as the axis angle values. |
| Stowed Attitude | Set the stowed (retracted) attitude angles. |
| Attitude 1 | Set the Attitude 1 angles (manipulator extended forward). |
| Speed (deg/sec) | Select the movement speed when changing the attitude. <ul style="list-style-type: none"> • Automatic (default: 15 deg/sec) • 1 to 15 deg/sec |
| S1 axis angle (deg) | Set the angle of the S1 axis. |
| S2 axis angle (deg) | Set the angle of the S2 axis. |
| E1 axis angle (deg) | Set the angle of the E1 axis. |
| E2 axis angle (deg) | Set the angle of the E2 axis. |
| W1 axis angle (deg) | Set the angle of the W1 axis. |
| W2 axis angle (deg) | Set the angle of the W2 axis. |
| Transiting Standby Attitude | When turned on, the manipulator transits through the standby attitude (whereby the manipulator does not hit ASCENT's antenna, etc.) during attitude changes. |
| Run Asynchronously | When turned on, the next motion starts without waiting for the attitude change to finish. |

■ About [Run Asynchronously]

When [Run Asynchronously] is turned on, the next motion starts without waiting for the manipulator to move to the target attitude. When off, the manipulator moves to the target attitude before starting the next motion.

You can also use a "wait" motion to wait for the manipulator to complete its operation.


■ Retracting the manipulator to its driving attitude (stowed attitude)

Before moving ASCENT after operating the manipulator, return the manipulator to its driving attitude.

CAUTION

- **The manipulator must be stowed before moving.**
If you drive without stowing the manipulator, it could hit and injure someone, or hit something and damage it.
Also, vibration may cause the manipulator to malfunction.

To return the manipulator to its driving attitude, add an arm-joint motion and click the [Stowed Attitude] button, then click the [OK] button.



The screenshot shows the 'arm-joint property' dialog box. At the top, there is a 'Reference number' dropdown menu set to '2'. Below it is an 'Acquiring Current Angle' button. Two buttons, 'Stowed Attitude' and 'Attitude 1', are visible, with 'Stowed Attitude' highlighted by a red rectangular box. The 'Speed' is set to 'Auto' with a unit of 'deg/sec'. Below are several axis angle inputs: 'S1 Axis Angle' (0 deg), 'S2 Axis Angle' (-86 deg), 'E1 Axis Angle' (176 deg), 'E2 Axis Angle' (0 deg), 'W1 Axis Angle' (0 deg), and 'W2 Axis Angle' (0 deg). At the bottom, there are two checkboxes: 'Transiting Standby Attitude' (checked) and 'Run Asynchronously' (unchecked). 'Cancel' and 'OK' buttons are at the very bottom.

■ Referencing the angles set in another arm-joint motion

The angles set in one arm-joint motion can be referenced from another arm-joint motion. In that case, select the [Reference number] of the arm-joint motion you want to refer to as the [Reference number] of the referencing arm-joint motion.

■ Specifying manipulator movement as offsets from the current attitude

Use an “arm-delta” motion.

Specify the amount of movement from the current manipulator attitude. This is specified by movement values on the x-y-z axes, or rotation values of roll, pitch and yaw.


1 Click the [+] button to add a motion.

2 Select “arm-delta” from the list.

The motion property screen appears.

3 Select [Hand Coordinate] or [Base Coordinate] for the [Coordinate System].

Hand coordinates apply to the manipulator’s hand. The direction the hand faces is the Z-axis. Base coordinates apply to the manipulator arm’s mounting base. The front-back direction of ASCENT is the X-axis.



4 Specify the amount of movement by position deviation or attitude deviation.

Position deviation moves the manipulator’s hand the specified distance. Attitude deviation rotates the manipulator’s hand by the specified angle.

5 Click the [OK] button.

arm-delta motion properties

| Item (units) | Description |
|--------------------------------|--|
| Translation Speed (mm/sec) | Specifies the translation speed. <ul style="list-style-type: none"> • Automatic (default value: 100 mm/sec) • 1 to 100 mm/sec |
| Position Deviation x (mm) | Specifies the translation distance on the X-axis. |
| Position Deviation y (mm) | Specifies the translation distance on the Y-axis. |
| Position Deviation z (mm) | Specifies the translation distance on the Z-axis. |
| Turning Speed (deg/sec) | Specify the turning speed. <ul style="list-style-type: none"> • Automatic (default: 15 deg/sec) • 1 to 15 deg/sec |
| Attitude Deviation roll (deg) | Specifies the roll movement angle. |
| Attitude Deviation pitch (deg) | Specifies the pitch movement angle. |
| Attitude Deviation yaw (deg) | Specifies the yaw movement angle. |
| Turn Center Offset (mm) | Shifts the center point for turning motions. |
| Coordinate System | Specifies the coordinate system to be the basis for movement. <ul style="list-style-type: none"> • Hand Coordinate • Base Coordinate |
| Run Asynchronously | When turned on, the next motion starts without waiting for the attitude change to finish. |

9.4.7 Opening and closing the manipulator hand

NOTE

- **Do not use manipulator to grab sharp objects, objects hotter than 100°C or colder than 0°C, or chemicals that erode rubber.**
Otherwise, the rubber at the manipulator's fingertips will be damaged.

The behavior of the manipulator hand in a scenario is not suitable for precise operations such as grasping objects or pressing buttons.

Use a “hand” motion to operate the manipulator hand. The hand motion specifies whether to open or close the hand.

Since the manipulator hand is normally open, first specify a motion to close the hand, then specify a motion to open it.


hand motion properties

| Item (units) | Description |
|---------------------------|---|
| Opening/Closing Direction | Select the hand action. <ul style="list-style-type: none"> • Close • Open |
| Run Asynchronously | When turned on, the next motion starts without waiting for the hand opening or closing to complete. |

9.4.8 Target imaging

Use the record-image motion to capture a still image of a target.

- 1** Click the **[+]** button to add a motion.
- 2** Select **“record-image”** from the list.
The motion property screen appears.



- 3** Click the **[Object Selection]** button, then click the target icon on the map.
The target ID and target name are displayed.
- 4** Select the imaging camera with **[Camera]**.
[Surveillance Camera], [360° optical camera], [Left Thermal Imaging Camera], or [Right Thermal Imaging Camera] can be selected as the imaging camera.
If you select [Surveillance Camera], you can set the [Surveillance Camera Settings].
- 5** Set the imaging mode in **[Surveillance Camera Settings]**.
Set when [Surveillance Camera] is selected.
The [Surveillance Camera Settings] can be determined by taking a test shot on the [Predefined Motions (Navi)] tab on the Teleop screen.
- 6** Click **[OK]**.

record-image motion properties


| Item | Description |
|--|--|
| Target ID | Select the target to be imaged. Click [Object Selection], then click the target icon on the map. |
| Target Name | Displays the name of the selected target. |
| Camera | Select the camera to use for imaging. <ul style="list-style-type: none"> • Surveillance Camera • 360° Optical Camera • Right Thermal Imaging Camera • Left Thermal Imaging Camera |
| Image Format | Select an image format. <ul style="list-style-type: none"> • JPEG • BMP |
| Surveillance Camera Settings Imaging mode | If you select the surveillance camera, select the imaging mode. <ul style="list-style-type: none"> • Auto: The exposure is determined automatically. • Dark area: Select exposure for dark areas. • Bright area: Select exposure for bright areas. • Auto Exposure: Determines exposure by measuring luminance in the metering area specified in Auto Exposure Zone Setting. |
| Lighting | When on, the light turns on when imaging. |
| Auto Exposure Zone Setting | Specifies the metering area when Auto Exposure imaging mode is selected in Surveillance Camera Settings. Click the [Get Area] button to capture the metering area settings on the Teleop screen. |

■ Checking inspection results

Images taken during scenario execution can be checked on the [Inspection Summaries] or [Inspection History] screen in the cloud.

9.4.9 Pinpoint temperature measurement

Use a “record-thermal” motion to measure pinpoint temperature at a target location.



On the record-thermal motion properties screen, click the [Object Selection] button, then click the heat source icon on the map.

For details on heat source object settings, see “7.12 Measuring the Pinpoint Temperature of a Heat Source Object” (page 7-86).

record-thermal motion properties

| Item | Description |
|-------------|--|
| Target ID | Select the heat source for temperature measurement. Click the [Object Selection] button, then click the heat source icon on the map. |
| Target Name | Displays the name of the selected target. |

■ Checking inspection results

Images taken during scenario execution can be checked on the [Inspection Summaries] or [Inspection History] screen in the cloud.

9.4.10 Gas concentration measurement

Use a “record-gas” motion to measure gas concentration around a target.

On the record-gas motion properties screen, click the [Object Selection] button, then click the target icon on the map.

record-gas motion properties

| Item | Description |
|-------------|---|
| Target ID | Select the measurement target. Click [Object Selection], then click the target icon on the map. |
| Target Name | Displays the name of the selected target. |

■ Checking inspection results


To see the measurement results after executing a scenario, select the relevant target on the [Inspection History] screen of the cloud, and open the [Detail] tab.

| Item | Value |
|-----------------------|----------------|
| Navcon Status | 5 |
| Gas: LEL | 0 |
| Gas: Monoxide | 0 |
| Gas: Hydrogen Sulfide | 0 |
| Gas: Oxygen | 21 |
| Gas: Temperature | 22 |
| Gas: Error | 0 |
| Device ID | 2 |
| Device Name | fisheve camera |

2022/05/23 16:05

9.4.11 Target audio recording

Use a “record-audio” motion to record sound around a target. Select the Target ID on the property screen.



On the record-audio motion properties screen, click the [Object Selection] button, then click the target icon on the map.

record-audio motion properties

| Item (units) | Description |
|----------------------|---|
| Target ID | Select the target to record. Click [Object Selection], then click the target icon on the map. |
| Target Name | Displays the name of the selected target. |
| Recording Time (sec) | Sets the recording time. <ul style="list-style-type: none"> • 1 to 50 sec |
| Volume (%) | Specifies the volume. <ul style="list-style-type: none"> • 1 to 100% |

■ Checking inspection results

Inspection results can be checked on the [Inspection Summaries] or [Inspection History] screen in the cloud.

9.4.12 LED lighting

Use an “led” motion to turn on/off the LED.

The image shows a dialog box titled "led property". It contains two main fields: "Pattern" and "Luminance". The "Pattern" field is a dropdown menu currently showing "Extinguish (off)". The "Luminance" field is a text input with "100" and a percentage sign "%". Below these fields are two buttons: "Cancel" and "OK".

For the led motion, you can specify the following lighting patterns.

- Extinguished
- Lit
- Blinks once
- Blinks twice

When executing a lit or blinking LED motion, the LED will light or blink until the Off “led” motion is executed.

led motion properties

| Item (units) | Description |
|---------------|--|
| Pattern | Select the on/off pattern. <ul style="list-style-type: none"> • Extinguish (off) • Lit (on) • Blink once • Blink twice |
| Luminance (%) | Specifies the brightness of the LED. <ul style="list-style-type: none"> • 0 to 100 % |

9.4.13 Ascending and descending stairs

Use “stairs” motions to ascend and descend stairs.

1 Click the [+] **button to add a motion.**

2 Select “stairs” from the list.

The motion property screen appears.

3 Click the [Object Selection] button, then click the stairs icon on the map.

4 Select [Climb] or [Descend].

5 Click the [OK] button.

Stairs motion properties

| Item | Description |
|-------------|---|
| Stairs Name | Select a name for the stairs. Click [Object Selection], then click the stairs icon on the map. |
| Direction | Specify the direction of travel on the stairs. <ul style="list-style-type: none"> • Climb • Descend |

9.4.14 Crossing over a step

Use an “obstacle” motion to cross over a step.

1 Click the [+] button to add a motion.

2 Select “obstacle” from the list.
The motion property screen appears.

3 Click the [Object Selection] button, then click the step icon on the map.
Numerical values registered to the object are set on the property screen.

4 If the [Mounted Height] and [Lowered Height] are opposite to the direction of travel, click the [Swap] button.

5 Click the [OK] button.
You can also enter the step heights and depth directly.

obstacle motion properties


| Item (units) | Description |
|---------------------|--|
| Object Selection | Select the Step object. Click the button and select the step icon on the map to set the property values for the step object. |
| Mounted Height (mm) | Specifies the height on the front side in the direction of travel. |
| Lowered Height (mm) | Specifies the height on the back side in the direction of travel. |
| Depth (mm) | Specifies the depth of the step. |

9.4.15 Change the sub track angle

Change the angles of the sub tracks according to the level difference or slope of the floor. Use a “subtrack” motion to change the angles of the sub tracks.

1 Click the [+] button to add a motion.

2 Select “subtrack” from the list.
The motion property screen appears.



3 Enter the [Sub Track Target Angle].
By default, the front angle is 110 degrees and the back angle is 90 degrees. Use these values when driving.

subtrack motion properties

| Item (units) | Description |
|------------------------|--|
| Reference number | Specify the number to be used for referencing from another motion. To reference the angles of an existing motion, specify the reference number set in that motion. |
| Sub Track Target Angle | Specifies the angles for the front left (FL), front right (FR), back left (BL), and back right (BR) sub tracks. |
| FL (deg) | |
| FR (deg) | |
| BL (deg) | |
| BR (deg) | |
| Operating Speed | Specifies the angular operating speed of the front left (FL), front right (FR), back left (BL), and back right (BR) sub tracks. |
| FL (deg/sec) | |
| FR (deg/sec) | |
| BL (deg/sec) | |
| BR (deg/sec) | |

■ Referencing the angles set in another subtrack motion

You can reference the angles set in one subtrack motion for use in another subtrack motion. In this case, for the [Reference number] of the new subtrack motion, select the [Reference number] of the source subtrack motion you want to refer to.


9.4.16 Audio output

You can play an audio file that has been previously saved in ASCENT. Use a “play-audio” motion for audio output.

1 Add the motion at the position where you want to play the audio file.

2 Select “play-audio” from the list.

The motion property screen appears.



3 Specify the sound source number and volume.

4 Select [Repeat] to play the audio file repeatedly.

If [Repeat] is off, the next motion will start when the audio file finishes playing.

If [Repeat] is on, the audio file plays repeatedly until a “stop-audio” motion is executed. To sound an alarm during an operation, add a play-audio motion before the operation starts, and a stop-audio motion after the operation ends.

5 When [Repeat] is on, add a motion at the position where you want to end playback.

6 Select “stop-audio” from the list.

No property screen is displayed for the stop-audio motion because there are no settings.


play-audio motion properties

| Item (units) | Description |
|---------------------|---|
| Audio Source Number | Specify 1. There is no source other than 1. |
| Audio Volume (%) | Specifies the volume. • 0 to 100% |
| Repeat | When turned on, the audio source will play repeatedly. |
| Run Asynchronously | When turned on, the next motion starts during audio output. |

9.4.17 Timing adjustment

Use a “wait” motion to adjust when the next motion executes.

This motion waits for the specified number of seconds, or for the manipulator or sub track operation started in the previous motion to complete its operation.



wait motion properties

| Item (units) | Description |
|---|---|
| Wait Time (sec) | Specifies the wait time. |
| Wait for completion of asynchronous operation of manipulator and sub tracks | When on, waits for the manipulator or sub tracks running asynchronously in the previous motion to complete. |

9.4.18 About asynchronous execution

The [Run Asynchronously] option is available for subtrack, arm-joint, arm-delta, hand, and play-audio motions. Select the [Run Asynchronously] option to start the next motion without waiting for the current motion to complete.

If you turn on [Run Asynchronously] for each motion, a scenario error will occur if certain motions come next. The following motion combinations cause a scenario error when [Run Asynchronously] is turned on.

■ subtrack motion

If the subsequent motion is one the following, an error will occur.

- subtrack
- stairs
- charging-station
- obstacle
- record-audio

■ arm-joint and arm-delta motions

If the subsequent motion is one the following, an error will occur.

- arm-joint
- arm-delta
- stairs
- charging-station
- obstacle
- record-audio

■ hand motion

If the subsequent motion is one the following, an error will occur.

- hand
- stairs
- charging-station
- obstacle
- record-audio

■ play-audio motion


Any motion can be specified.

9.5 Saving a Scenario

Save the created scenario in the cloud.

The scenario is saved in association with the plant name. Scenarios are not saved in the Teleop Terminal.

- 1** Click [Save Scenario] on the [Project] tab.
- 2** Select [Overwrite Scenario] or [Register as New Scenario] and click the [OK] button.
- 3** Click [Yes] when the message is displayed.
- 4** If creating a new scenario, enter its name and click the [OK] button.



The screenshot shows a dialog box titled "Scenario Upload". It contains the following elements:

- A header bar with the text "Scenario Upload".
- A label "Enter the scenario name".
- A label "Scenario ID" followed by the value "175".
- A label "Scenario Name" followed by a text input field containing the text "scenario_175".
- Two buttons at the bottom right: "x Cancel" and "OK" with a green checkmark icon.

9.6 Executing a Scenario

Execute a scenario while editing. It is possible to execute only a specified line, or from a specified line to the end.


To execute a scenario, first load it into ASCENT.

1 Click **[Scenario Load]** on the **[Execute]** tab of **Scenario Maker**.

2 Click **[Yes]** when the message is displayed.

The scenario loads into ASCENT.

The scenario status changes from **[Waiting for scenario to load]** → **[Sending scenario]** → **[Loading scenario]** → **[Waiting for start]**.



If ASCENT's location as displayed on Scenario Maker's map is different from its actual location, specify the current location on the map.

3 Click **[Robot Positions]** on the **[Execute]** tab and move the mouse on the map to ASCENT's actual location. Drag to display an arrow, align the arrow with ASCENT's heading, and release the mouse button.

ASCENT's icon on the screen moves and reorients on the map based its 3D LiDAR data.

4 On the **[Scenario]** tab, select the line at which to start executing.

Execute one line of the scenario

5 Click [Executed selected lines].

6 Click [Yes] when the message is displayed.

The motion of the selected line executes. If the motion executed normally, the scenario status will be "Waiting for start".

To execute from the selected line to the end

7 Click [Execute to end].

8 Click [Yes] when the message is displayed.

The motions from the selected line to the last line are executed. If executed normally, the scenario status will be "Waiting for start".

To stop executing the scenario, such as when a motion fails to execute normally, click [Stop].


Chapter 10 Registering a Schedule

Register the date, time and frequency for executing a scenario in the cloud.
Adding or changing schedules requires administrator user privileges.

10.1 To Add a New Schedule

Log in to the cloud and register the schedule.


- 1 Enter the cloud URL in your Web browser.**
The login screen appears.



The image shows the login screen for the Robot Monitoring System. It features a central white box with the title "Robot Monitoring System" at the top. Below the title, it says "Sign in to start your session". There are two input fields: "User ID" with a person icon and "Password" with a lock icon. Below these fields are two buttons: "Change Your Password" in blue text and "Sign In" in a blue box. The background is a light gray.

- 2 Enter the administrator user ID and password, and click the [Sign In] button.**
For user ID and password details, see "13.1 Logging Into the Cloud" (page 13-1).

- 3 Select [Schedules] from the menu.**
The [Schedule List] screen appears.
For screen details, see "10.5 [Schedule List] Screen" (page 10-6).




The image shows the EXROVR Schedule List screen. On the left is a dark sidebar menu with the EXROVR logo at the top and various navigation items: Plants, Alerts, Robots, Schedules, Scenarios, Inspection Summaries, Inspection History, Contract Information, Users, Teleop Terminals, Charging Stations, Signed in as admin-mhi, Settings, and Sign out. The main content area is titled "Schedule List" and contains a search bar with filters for Plant (MHI), Scenario ([All Scenarios]), and Next Execution (DATE(FROM), TIME(FROM), ~, DATE(TO), TIME(TO)). Below the search bar is a legend with "Running" (blue dot), "On standby" (gray dot), and "Error Occurred" (red dot). A table with columns for En..., Plant, Schedule Name, Scenario, Robot, Next Execution, Cycle, and Expiration is shown, but it contains no data and displays "No matching result".

4 Click the [Add] button.

The [Schedule Registration] screen appears.

5 Select the [Plant] in which to execute the scenario.

A list of scenarios registered for the selected plant is displayed on the right side of the screen.



6 Enter the [Schedule Name].

7 Select the scenario to be executed in the scenario list.

Click on the scenario name column to pop up its map and patrol route.

8 Select the ASCENT to be used in [Robot].

9 Set the [Start Date].

Click the [Start Date] and [Start Time] fields, and specify the execution starting date and time.

10 Set the [Cycle].

Select the unit (year, month, week, day, hour) in the first list.

- [Year], [Week], [Day], [Time]: Enter the cycle (frequency) numerically.
- [Month]: In addition to specifying a numerical value for once every few months, you can also specify the 10th of every month, the third Friday of every month, and the like.
- [Week]: Specify the execution day of the week.

11 Specify when to end the scheduled executions with [End].

- [No Expiration]: No expiration date is set.
- [Expiration Date]: The schedule will not be executed after the specified date.
- [Execution Count]: The schedule will no longer execute after the specified number of executions.

12 Select [Plant] or [UTC] as the time zone.

13 Click the [OK] button.

The schedule is registered.

The scenario automatically executes at the execution start date and time.

10.2 To Change a Schedule

Change a registered schedule.

- 1** Log in to the cloud as an administrator user.
- 2** Select [Schedules] from the cloud menu.
The [Schedule List] screen appears.
- 3** Specify the search conditions and click the [Search] button.
You can specify the plant name, scenario name, and next execution date and time as search conditions.
Schedules that match your search conditions are displayed in a list.

3

4

| En... | Plant | Schedule Name | Scenario | Robot | Next Execution | Cycle | Expiration | |
|-------------------------------------|-------|--------------------|--------------------|------------|------------------|---------|------------|--|
| <input checked="" type="checkbox"/> | DE | scenario_exec_test | Daily scenario | ER20GV-001 | 2022/06/01 09:22 | 1hours | -- | <input type="checkbox"/> Delete <input type="checkbox"/> Edit |
| <input checked="" type="checkbox"/> | DE | arc-test | Regular Inspection | exrov_1 | 2022/06/01 09:50 | 1hours | -- | <input type="checkbox"/> Delete <input type="checkbox"/> Edit |
| <input checked="" type="checkbox"/> | DE | scenario_exec_test | Daily scenario | ER20GV-001 | -- | Oneshot | -- | <input type="checkbox"/> Delete <input type="checkbox"/> Edit |
| <input type="checkbox"/> | DE | arc-test | Regular Inspection | exrov_1 | -- | 1days | -- | <input type="checkbox"/> Delete <input type="checkbox"/> Edit |
| <input checked="" type="checkbox"/> | DE | scenario_exec_test | Daily scenario | exrov_1 | -- | 1days | -- | <input type="checkbox"/> Delete <input type="checkbox"/> Edit |

- 4** Click the [Edit] button for the schedule you want to change.
The [Schedule Registration] screen appears.
- 5** Change the setting items and click the [OK] button.
For details on the setting items, refer to the previous page.

10.4 To View a Schedule (general users)

General users can only view schedules. They cannot be registered or changed.

- 1** Log in to the cloud as a general user.
- 2** Select [Schedules] from the cloud menu.
- 3** Specify the search conditions and click the [Search] button.

You can specify the plant name, scenario name, and next execution date and time as search conditions.

Schedules that match your search conditions are displayed in a list.

3


The screenshot shows the 'Schedule List' interface. At the top, there are search filters for Plant (DE棟), Scenario ([All Scenarios]), and Next Execution (DATE(FROM), TIME(FROM), DATE(TO), TIME(TO)). A search button is visible. Below the filters, the results are displayed in a table with columns: En..., Plant, Schedule Name, Scenario, Robot, Next Execution, Cycle, and Expiration. The table shows 14 results, with a legend indicating Running (blue dot), On standby (grey dot), and Error Occurred (red dot).


| En... | Plant | Schedule Name | Scenario | Robot | Next Execution | Cycle | Expiration |
|-------------------------------------|-------|--------------------|--------------------|------------|------------------|---------|------------------|
| <input checked="" type="checkbox"/> | DE | scenario_exec_test | Regular Inspection | ER20GV-001 | 2022/06/01 09:22 | 1hours | - |
| <input checked="" type="checkbox"/> | DE | arc-test | Daily scenario | exrow_1 | 2022/06/01 09:50 | 1hours | - |
| <input checked="" type="checkbox"/> | DE | scenario_exec_test | Regular Inspection | ER20GV-001 | - | Oneshot | - |
| <input type="checkbox"/> | DE | arc-test | Daily scenario | exrow_1 | - | 1days | - |
| <input checked="" type="checkbox"/> | DE | scenario_exec_test | Regular Inspection | ER20GV-001 | - | 1days | - |
| <input checked="" type="checkbox"/> | DE | arc-test | Daily scenario | exrow_1 | - | 1days | 2022/01/14 23:59 |
| <input checked="" type="checkbox"/> | DE | scenario_exec_test | Regular Inspection | ER20GV-001 | - | Oneshot | - |
| <input checked="" type="checkbox"/> | DE | arc-test | Daily scenario | exrow_1 | - | 1days | 2022/01/14 23:59 |
| <input checked="" type="checkbox"/> | DE | scenario_exec_test | Regular Inspection | ER20GV-001 | - | Oneshot | - |
| <input checked="" type="checkbox"/> | DE | arc-test | Daily scenario | exrow_1 | - | 1days | - |


■ Schedule list

The following information is displayed in the list.

- **Enabled:** A valid schedule is checked. If you uncheck it, it will be disabled.
- **Status:** Indicates the execution status of the schedule.

: Running

: Waiting

: An error is occurring (will be cleared when the next schedule starts)

- Plant name
- Schedule name
- Scenario name
- Robot name
- Next execution date and time
- Execution cycle
- Completion date and time

[Delete] button: Deletes the schedule. Not displayed for general users.

[Edit] button: Edits the schedule. Not displayed for general users.

MEMO

Chapter 11 Auto Patrol

A scenario with a registered schedule will automatically start a patrol at the scheduled start time. This chapter describes auto patrol and how to check the status during auto patrol.

11.1 Scheduled Auto Patrol

At the scheduled operation start time, ASCENT will automatically start patrol.

At the start time, ASCENT first reboots its devices and loads the scenario. Therefore, it takes about five minutes for ASCENT to actually start moving.

The Status LED on ASCENT's main unit changes from yellow (charging) to blinking yellow (exit), and then to blue (autonomous) when undocking is completed.

You can check the status of ASCENT during scenario execution on the Teleop screen or on the Dashboard.


If the internal pressure is insufficient (3 kPa or less) or the battery voltage is insufficient (25 V or less) at the start of auto patrol, auto patrol will not proceed.

11.2 Real-Time Monitoring on the Dashboard

ASCENT can be checked in real time on the dashboard. The dashboard is displayed in a Web browser (Chrome recommended) on your PC or tablet.

Follow the steps below to display the dashboard.


- 1 Log in to the cloud.**
Both administrator users and general users can perform these operations.
- 2 Select [Robots] from the menu.**
The [Robots] screen appears.
- 3 Specify the plant name and robot name, and click the [Search] button.**
ASCENT's that match your search criteria will be displayed in a list.



- 4 Click the [Dashboard] button for the ASCENT you want to check.**
The dashboard is displayed.

■ Dashboard screen

The Dashboard screen configuration is shown below.



① Robot

Displays the robot name.

② Current date and time

Displays the current date and time. The left is the date and time of the time zone set for the PC or tablet running the Web browser, and the right is the UTC date and time.

③ Error status

The color indicates ASCENT's error status.

- Green: Normal
- Yellow: Warning
- Red: Anomaly

Click to display the error status of each module. To check the error/warning details of a module, display the Teleop screen and check the error code of the applicable module in the [Status] panel.

The displayed modules are as follows.

| Display | Description |
|--------------|--|
| Navcon | Navigation controller |
| Syscon | System controller board |
| Robot | Robot |
| Teleop | Teleoperation sensor |
| LiDAR | Autonomous control sensor |
| Media | Surveillance cameras, 360° optical camera, thermal imaging cameras, microphones, speaker |
| Subtrack | Sub track |
| IMU | IMU sensor |
| Main Track | Main track |
| Charger | Charging unit |
| Arm | Manipulator |
| Gas Detector | Gas detector |

④ **ASCENT status**

Displays the status of ASCENT.

- Starting up
- Standing by
- Teleoperation
- Running Autonomously
- Charging
- Entering Chg. St. (docking)
- Leaving Chg. St. (undocking)
- Self-diagnosis
- Powering Down
- ERROR (An error is occurring)
- Offline

⑤ **Status last update at:**

Indicates the date and time when the status was last updated.

⑥ **Voltage**

Displays the battery voltage.

⑦ **Gas concentration**

Displays information from ASCENT's gas detectors.

Oxygen: Displays the oxygen concentration.

Carbon Monoxide: Displays the carbon monoxide concentration.

Combustible Gas: Displays combustible gas concentration.

Hydrogen Sulfide: Displays the hydrogen sulfide concentration.

Temperature: Displays the external temperature.

Gas Detector History: Displays the changes of numerical values of the gas detector in a graph.

⑧ **Latest Inspection Image**

Displays the latest image taken by ASCENT.

⑨ **Robot Location**

Displays a map of the running scenario, with an arrow showing the current location of ASCENT on the map.

⑩ **Periodic Image**

Displays the 360° optical camera images that ASCENT periodically uploads to the cloud.

MEMO

Chapter 12 Checking Inspection Results

The results of automatic patrols are saved in the cloud and can be checked on the management screen. The following confirmation methods are available:

- Check each executed scenario ([Inspection Summary] screen)
- Check each target ([Inspection History] screen)

12.1 Checking Scenario Execution Results (Inspection Summary)

12.1.1 Check execution results on the [Inspection Summary] screen

You can check the result of executing a scenario on the [Inspection Summary] screen in the cloud.

1 Log in to the cloud.

2 Select [Inspection Summaries] from the menu.

The [Inspection Summaries] screen appears.

For screen details, see “12.1.2 [Inspection Summaries] screen” (page 12-3).

3 Select a plant from the [Plant] list

4 Set the search conditions and click the [Search] button.

You can specify the following conditions:


- Scenario name
- Schedule name
- Cycle

The patrol results that match the search conditions are displayed in order from the most recent.

The screenshot shows the 'Inspection Summaries' interface. At the top, there are three dropdown menus for 'Plant' (DE), 'Scenario' (demo001), and 'Schedule' ([All Schedules]). Below these are two input fields for 'Cycle' (DATE(FROM) and DATE(TO)). A blue 'Search' button is on the right. Below the search area, it says 'Num. results: 1'. A table displays the results with columns: Plant, Scenario, Robot, Schedule, Execution Time, and Status. The first row shows DE, demo001, Rovr A, [empty], 2022/02/16 10:57, and Normal. A 'Detail' button is at the end of the row. Numbered callouts point to: 3 (Plant dropdown), 4 (Search button), and 5 (Detail button).

| Plant | Scenario | Robot | Schedule | Execution Time | Status | |
|-------|----------|--------|----------|------------------|--------|--------|
| DE | demo001 | Rovr A | | 2022/02/16 10:57 | Normal | Detail |

- 5 Click the [Detail] button in the row of the patrol results you want to display. The [Inspection Summary] screen appears.



The Inspection Summary shows the patrol information, a map, and the images and sounds acquired during the patrol.


The map shows the patrol route and the imaging locations.

Click an image to enlarge it.

For audio recordings, a play button and control bar are displayed.

12.1.2 [Inspection Summaries] screen

This section describes the contents displayed on the [Inspection Summaries] screen. The execution results of a scenario are displayed in a list.



■ Search area

If you specify the search conditions and click the [Search] button, the inspection summaries that match the conditions will be displayed in the search results.

You can specify the following search conditions:

- Plant name
- Scenario name
- Schedule name
- Cycle

■ Inspection summaries

- Plant name
- Scenario name
- Robot name
- Execution time
- Status: Indicates whether the inspection results are normal or abnormal.

[Detail] button: Displays the details of the patrol results on the [Inspection Summary] screen. You can also check the images and sounds.

12.2 Checking Inspection Results of Each Target (Inspection History)

12.2.1 Check the inspection results on the [Inspection History] screen

On the [Inspection History] screen in the cloud, you can check past inspection results for each target.

1 Log in to the cloud.

2 Select [Inspection History] from the menu.

The [Inspection History] screen appears.

For screen details, see “12.2.2 [Inspection History] screen” (page 12-5).

3 Select the plant from the [Plant] list.

4 Specify the search conditions for the patrol results and click the [Search] button.

You can specify the following search conditions:

- Scenario name
- Cycle

You can also specify the following conditions by clicking the ▼ button to the right of the [Search] button.

- Target name
- Data type

The inspection results that match the search conditions are displayed for each target.

5 Click the line of the inspection results you want to check.

A list of acquired images and sounds is displayed on the right side of the screen.

The screenshot shows the 'Inspection History' interface. At the top, there are search filters for Plant (DE), Scenario ([All Scenarios]), and Cycle (DATE(FROM), TIME(FROM), ~, 2022/05/23, 00:00). A blue 'Search' button is on the right. Below the filters, a table lists inspection results with columns for Plant, Scenario, Acquisition Time, Data Type, Target, and Anomaly. The third row is selected. To the right of the table, there is a 'Preview' section showing a large image of a target and a grid of smaller images below it. Numbered callouts are: 3 points to the Plant dropdown, 4 points to the Search button, 5 points to the selected row in the table, and 6 points to the Preview section.

| Plant | Scenario | Acquisition Time | Data Type | Target | Anomaly |
|-------|----------|------------------|-----------|-----------|---------|
| DE | 0217yrsp | 2022/04/28 14:11 | Image | target001 | None |
| DE | 0217yrsp | 2022/04/28 14:05 | Image | target001 | None |
| DE | 0217yrsp | 2022/04/28 14:05 | Image | target001 | None |
| DE | 0217yrsp | 2022/04/28 14:05 | Image | target001 | None |
| DE | 0217yrsp | 2022/04/28 14:02 | Image | target001 | None |
| DE | 0217yrsp | 2022/04/28 14:02 | Image | target001 | None |
| DE | 0217yrsp | 2022/04/28 14:02 | Image | target001 | None |
| DE | 1階部分のみ 2 | 2022/04/21 14:41 | Image | target001 | None |
| DE | 1階部分のみ 2 | 2022/04/21 14:41 | Image | target001 | None |
| DE | 1階部分のみ 2 | 2022/04/21 14:41 | Image | target001 | None |

Click an image to enlarge it.
For audio recordings, a play button and control bar are displayed.

6 To check the detailed information at the time of inspection, click the [Detail] tab.
[Detail] tab

| | |
|----------------|------------------|
| Preview | Detail |
| Execution Time | 2022/05/20 14:27 |
| Plant ID | 27 |
| Scenario ID | 48 |
| Command No. | 200 |
| Command Error | 0 |
| IMSI | 440103236499490 |
| Data Type | Image |
| Target ID | 100051 |
| Robot ID | 62 |

12.2.2 [Inspection History] screen

The history of inspection results is displayed for each target. For the selected targets, you can see the past inspection results for each.

Search area

Inspection History

Plant: DE Scenario: [All Scenarios] Cycle: DATE(FROM) TIME(FROM) ~ 2022/05/23 00:00 [Search]

Show 10 results [Trash] Num. results: 970

| Plant | Scenario | Acquisition Time | Data Type | Target | Anomaly | |
|-------------------------------------|----------|------------------|------------------|--------|-----------|------|
| <input type="checkbox"/> | DE | 0217yrsp | 2022/04/28 14:11 | Image | target001 | None |
| <input checked="" type="checkbox"/> | DE | 0217yrsp | 2022/04/28 14:05 | Image | target001 | None |
| <input type="checkbox"/> | DE | 0217yrsp | 2022/04/28 14:05 | Image | target001 | None |
| <input type="checkbox"/> | DE | 0217yrsp | 2022/04/28 14:05 | Image | target001 | None |
| <input type="checkbox"/> | DE | 0217yrsp | 2022/04/28 14:02 | Image | target001 | None |
| <input type="checkbox"/> | DE | 0217yrsp | 2022/04/28 14:02 | Image | target001 | None |
| <input type="checkbox"/> | DE | 0217yrsp | 2022/04/28 14:02 | Image | target001 | None |
| <input type="checkbox"/> | DE | 1階部分のみ 2 | 2022/04/21 14:41 | Image | target001 | None |
| <input type="checkbox"/> | DE | 1階部分のみ 2 | 2022/04/21 14:41 | Image | target001 | None |
| <input type="checkbox"/> | DE | 1階部分のみ 2 | 2022/04/21 14:41 | Image | target001 | None |

Inspection History list

Detail
Preview

■ Search area

If you specify the search conditions and click the [Search] button, the inspection summaries that match the conditions will be displayed in the search results. Click ▼ to see additional search conditions.

You can specify the following search conditions:

- Plant name
- Scenario name
- Cycle
- Target name
- Data type (image/audio)

■ Inspection history list

[Trash] button: Puts the inspection history selected in the checkbox into the Inspection History Trash.

- Checkbox: Select the history to delete.
- Plant name
- Scenario name
- Acquisition time
- Data type
- Target name
- Anomaly:

Select each line in the history to see its image in the preview field on the right. For audio, the play button and control bar are displayed.

■ [Preview]

A preview image of the inspection history selected in the list is displayed. Click the image to enlarge it. Images taken in the past are also displayed.

For audio, the play button and control bar will be displayed so you can play the audio.

■ [Detail]

Detailed information on the inspection history is displayed.

You can also check the measured values of the gas detectors [here](#).

12.2.3 Display inspection history from the target list

You can also view a list of targets to see the inspection history for each target.

- 1 Log in to the cloud.
- 2 Display [Plants] from the menu.
- 3 Click the number in the target number column of the plant.

Number of targets

| Name | A... | Last inspection | Num. schedules | Num. targets | Num. scenarios | |
|----------|------|-----------------|----------------|--------------|----------------|----------------------|
| ▼ MHI | ● | None | 0 | 0 | 0 | Edit |
| ▼ Kobe | ● | None | 0 | 0 | 0 | Edit |
| DE | ● | 5days ago | 14 | 44 | 48 | Edit |
| ME | ● | 2022/04/07 | 6 | 21 | 10 | Edit |
| Takasago | ● | None | 0 | 2 | 0 | Edit |
| Yohohama | ● | None | 0 | 1 | 0 | Edit |

The [Targets] screen appears.

- 4 Click the [Inspection History] button of the target for which you want to display the history. The [Inspection History] screen appears. For screen details, see “12.2.2 [Inspection History] screen” (page 12-5).

Inspection history

| Target ID | Target Name | Plant | Registered | Last Updated | |
|-----------|-------------|-------|------------------|------------------|---|
| 188 | hot02 | DE | 2021/03/10 14:23 | 2021/09/28 11:29 | Edit Inspection History |
| 194 | target99 | DE | 2021/04/15 14:22 | 2021/04/15 14:22 | Edit Inspection History |
| 195 | g100 | DE | 2021/04/15 15:20 | 2021/04/15 15:20 | Edit Inspection History |
| 206 | taget001 | DE | 2021/08/23 16:12 | 2021/08/23 16:12 | Edit Inspection History |
| 207 | hot | DE | 2021/08/24 15:48 | 2021/08/24 15:48 | Edit Inspection History |
| 218 | IF tank | DE | 2021/09/28 11:29 | 2021/09/28 11:29 | Edit Inspection History |
| 219 | tank1 | DE | 2021/09/28 15:38 | 2021/09/28 15:38 | Edit Inspection History |
| 220 | tank | DE | 2021/10/05 16:57 | 2021/10/05 16:57 | Edit Inspection History |
| 221 | test | DE | 2021/10/18 12:01 | 2021/10/18 12:01 | Edit Inspection History |
| 222 | test2 | DE | 2021/10/18 12:02 | 2021/10/18 12:02 | Edit Inspection History |

MEMO

Chapter 13 Cloud Management

This chapter describes cloud features not covered in previous chapters.


13.1 Logging Into the Cloud

This section describes how to log in to the cloud.

Use a Web browser to access the cloud website. We recommend using Chrome for the Web browser.

1 Enter the cloud URL (<https://ex-rovr.com>) in the PC's Web browser.

The login screen appears.



Robot Monitoring System

Sign in to start your session

User ID

Password

[Change Your Password](#) [Sign In](#)

2 Enter your User ID (email address) and password.

| | |
|----------|--|
| User ID | Use the ID and password provided upon delivery when you first log in. |
| Password | User IDs can be added. After adding, each person can log in with their user ID and password. |

For user ID details, see “13.4 User Registration” (page 13-9).

3 Click the [Sign In] button.

The cloud management screen appears.

In the cloud, select an item from the menu on the left side of the screen.

Menu

The screenshot displays the EXROVR cloud management interface. On the left, a dark sidebar menu is highlighted with an orange box and labeled "Menu". The menu items include: Plants, Alerts, Robots, Schedules, Scenarios, Inspection Summaries, Inspection History, Contract Information, Users, Teleop Terminals, Charging Stations, Signed in as admin-mhi, Settings, and Sign out. The main content area is titled "Plants" and shows a table with 12 results. The table has columns for Name, Alerts (AL...), Last Inspection, Num. schedules, Num. targets, and Num. scenarios. Each row includes an "Edit" button. A map on the right shows the locations of the plants in Europe and Asia.

| Name | AL... | Last Inspection | Num. schedules | Num. targets | Num. scenarios | |
|----------------|--------------|-----------------|----------------|--------------|----------------|----------------------|
| ▼ MHI | ● None | | 0 | 0 | 0 | Edit |
| ▶ Kobe | ● None | | 0 | 0 | 0 | Edit |
| ▶ Futami | ● None | | 0 | 2 | 0 | Edit |
| ▶ Takasago | ● None | | 0 | 1 | 0 | Edit |
| ▶ NM | ● None | | 0 | 0 | 1 | Edit |
| ▶ MM | ● None | | 0 | 1 | 0 | Edit |
| ▶ KS | ● 2021.05.25 | | 1 | 3 | 3 | Edit |
| ▶ Musashino | ● None | | 0 | 0 | 0 | Edit |
| ▶ UMAD | ● None | | 0 | 5 | 2 | Edit |
| ▶ crestec-test | ● None | | 0 | 1 | 0 | Edit |

■ Logging out

Click [Sign out] from the menu.

13.1.1 Cloud Menu

The cloud menu contains the following menu items.

| Menu item | Description | Page |
|--|--|-------|
| Plants | Displays a list of registered plants. | 13-7 |
| Alerts | Displays a list of alerts. | 13-22 |
| Robots | Displays a list of registered ASCENTs. | 13-15 |
| Schedules | Displays a list of scenario execution schedules. | 10-6 |
| Scenarios | Displays a list of registered scenarios. | 13-24 |
| Inspection Summaries | Displays the execution results of scheduled scenarios. | 12-1 |
| Inspection History | Displays target inspection history. | 12-4 |
| Contract Information | Displays contract information. | 13-25 |
| Users (Administrator users only) | Manages user information. | 13-12 |
| Teleop Terminals (Administrator users only) | Displays a list of Teleop terminals. | 13-26 |
| Charging Stations | Displays a list of Charging Stations. | 13-27 |
| Signed in as | Displays the logged-in user's name. | – |
| Settings | Sets the display language. Select Japanese or English. | – |
| Sign out | Logs out of the cloud. | – |


13.2 Plant User Management Overview

A plant is a building such as a factory or building within a factory that ASCENT patrols. Upon delivery, one plant is registered per company. The factory and buildings to be patrolled are registered under this plant.

Each user and ASCENT is affiliated with the plant.

Users include administrators and general users. Administrator users can perform all operations of the software such as creating maps and scenarios, and registering schedules. General users can only view schedules and inspection results. Users affiliated with a parent plant can also work with its child plants.

An ASCENT can patrol within its affiliated plant. An ASCENT can be affiliated with only one plant.



EX ROVR is delivered with one plant registered per company, and one affiliated administrator user account affiliated with the purchased ASCENT. Additional plants and users can be registered to suit operational requirements.

13.3 Plant Registration

The buildings (factory, outbuildings, etc.) that ASCENT patrols are registered as a plant. A plant can be registered as a child of the parent plant registered at the time of delivery. Additional plants can be created as children of added child plants and managed hierarchically. Each ASCENT can be registered with only one plant.

13.3.1 Adding a new plant

1 Log in to the cloud.

2 Select [Plants] from the menu.

The [Plants] screen appears.

For screen details, see “13.3.3 [Plants] screen” (page 13-7).

The screenshot displays the EX ROVR Plants management interface. The main content area shows a table of plants with the following data:

| Name | Al... | Last Inspection | Num. schedules | Num. targets | Num. scenarios | |
|--------------|-------|-----------------|----------------|--------------|----------------|----------------------|
| MHI | ● | None | 0 | 0 | 0 | Edit |
| ▶ Kobe | ● | None | 0 | 0 | 0 | Edit |
| Futami | ● | None | 0 | 2 | 0 | Edit |
| Takasago | ● | None | 0 | 1 | 0 | Edit |
| NM | ● | None | 0 | 0 | 1 | Edit |
| MM | ● | None | 0 | 1 | 0 | Edit |
| KS | ● | 2021/05/25 | 1 | 3 | 3 | Edit |
| Musashino | ● | None | 0 | 0 | 0 | Edit |
| UMAD | ● | None | 0 | 5 | 2 | Edit |
| crestec-test | ● | None | 0 | 1 | 0 | Edit |

The interface also includes a sidebar with navigation options (Plants, Alerts, Robots, Schedules, Scenarios, Inspection Summaries, Inspection History, Contract Information, Users, Telesop Terminals, Charging Stations) and a user profile section (Signed in as admin-mhi, Settings, Sign out). A map on the right shows the locations of the plants.

3 Click the [Add] button.

The [Plant Registration] screen appears.

The screenshot displays the EX ROVR Plant Registration form. The form includes the following fields and options:

- Name:** Plant Name (text input)
- Parent Plant:** MHI (dropdown menu)
- Location:** Latitude (text input), Longitude (text input), and a Clear button.
- Time Difference From UTC (Hours):** 0 (text input) and a Verify Time Difference button.
- Map:** A world map showing the location of the plant.
- Buttons:** Cancel and OK buttons at the bottom right.

4 Set the plant information.


| Item | Description |
|-------------------------|---|
| Name | Enter the plant name. |
| Parent Plant | Select from the list the parent plant of the one being created. |
| Location (optional) | Click on the map where the plant is located. Click to set the latitude and longitude in the box. |
| The Difference From UTC | Enter the time difference from UTC. Click the [Verify Time Difference] button to display a map showing the time difference. |

5 Click the [OK] button.
The plant is registered.

13.3.2 Editing plant information

You can edit information such as the plant name and parent of the registered plant.

- 1 Log in to the cloud.**
- 2 Select [Plants] from the menu.**
The [Plants] screen appears.
- 3 Click the [Edit] button of the plant you want to edit.**



4 Edit the plant information on the [Plant Registration] screen.

5 Click the [OK] button.

13.3.3 [Plants] screen

This section describes the configuration of the [Plants] screen.

A list of registered plants is displayed. The plant locations are also shown on a map.

Administrator users can add and edit plants.

General users can only view plant information.

The screenshot shows the [Plants] screen with a table of plants and a sidebar with a map and robot list.

| Name | AL... | Last inspection | Num. schedules | Num. targets | Num. scenarios | |
|----------------|-------|-----------------|----------------|--------------|----------------|------|
| ▼ MHI | ● | None | 0 | 0 | 0 | Edit |
| ▶ Kobe | ● | None | 0 | 0 | 0 | Edit |
| ▶ Futami | ● | None | 0 | 2 | 0 | Edit |
| ▶ Takasago | ● | None | 0 | 1 | 0 | Edit |
| ▶ NM | ● | None | 0 | 0 | 1 | Edit |
| ▶ MM | ● | None | 0 | 1 | 0 | Edit |
| ▶ KS | ● | 2021/05/25 | 1 | 3 | 3 | Edit |
| ▶ Musashino | ● | None | 0 | 0 | 0 | Edit |
| ▶ UMAD | ● | None | 0 | 5 | 2 | Edit |
| ▶ crestec-test | ● | None | 0 | 1 | 0 | Edit |

The sidebar on the right shows a map of Europe with a green dot for MHI. Below the map, the following information is displayed:

```

MHI
Name: MHI
Parent Plant:
Time Difference From UTC (Hours): 09:00
Num. robots: 1
Num. alerts: 0

Robots
TestRobot Edit

```

■ [Add] button

Add a new plant.

Only administrator users are displayed.

■ [Show only Plants with Alert] button

Only plants where an alert has been generated are displayed in the list. Pressing this button changes it to the [Display All Plants] button.

■ Plants

A list of registered plants is displayed. If ▶ is displayed to the left of a plant name, you can click ▶ to display the child plants in the hierarchy.

Selecting a plant in the list displays a map of the plant and a list of the robots registered in the plant at the right side of the screen.

The following information is displayed in the list.

- Plant name
- Alert: Indicates the status of the plant's error by color. The color indicates the most severe error occurring in the plant.

●: Alert

●: Warning

●: Info

Click ○ to display a list of alerts for that plant.

- Last inspection: Displays the plant's last inspection date/time. Click to display the Inspection Summaries for that plant. (See "12.1.1 Check execution results on the [Inspection Summary] screen" (page 12-1))
- Num. schedules: Displays the number of schedules registered for the plant. Click to display the schedule list. (See "Chapter 10 Registering a Schedule" (page 10-1))
- Num. targets: Displays the number of targets registered in the plant. Click to display the list of targets. (See "12.2.3 Display inspection history from the target list" (page 12-7))
- Num. scenarios: Displays a list of the scenarios registered for the plant.

[Edit] button: Edits the plant information. Only administrator users are displayed.

13.4 User Registration

13.4.1 Administrator and general users

There are two types of users: administrator and general.

Only an administrator user can register another user.

The main privileges of the administrator and general users are as follows:

| Software | Function | Administrator user | General user |
|----------------|--------------------------------|--------------------|------------------|
| Teleop screen | Teleoperation of ASCENT | ○ | — |
| Scenario Maker | Map creation | ○ | — |
| | Scenario creation | ○ | — |
| Cloud system | Schedule Registration | ○ | △ (viewing only) |
| | User Management | ○ | — |
| | Plant management | ○ | △ (viewing only) |
| | Verification of patrol results | ○ | △ (viewing only) |
| Dashboard | Check ASCENT status | ○ | ○ |

13.4.2 Adding a new user

Create an account for the new user and register it with the plant. Each user can only register for one plant. When the plants are hierarchized, users registered in parent plants can also operate in the child plants.

1 Log in to the cloud.

2 Select [Users] from the menu.

The [User Management] screen appears.

For screen details, see “13.4.4 [User Management] screen” (page 13-12).

The screenshot shows the 'User Management' interface. At the top, there is a search bar with 'Plant Name' (dropdown menu showing '[All Plants]') and 'User Name' (input field). Below the search bar, there are checkboxes for 'User Type' with 'User' and 'Administrator' selected. A blue 'Search' button is on the right. Below the search bar, there are '+ Add' and '- Delete' buttons. The main area displays a table with 12 results. The table has columns: Full Name, Affiliated Plant, Email Address, User Type, Last Sign in, and action buttons (Delete and Edit). The table contains the following data:

| Full Name | Affiliated Plant | Email Address | User Type | Last Sign in |
|----------------|------------------|----------------------------|---------------|------------------|
| admin-mhi | MHI | admin-mhi@ex-rovr.com | Administrator | 2022/06/06 11:38 |
| teleop | MHI | teleop@ex-rovr.com | Administrator | 2021/11/16 15:55 |
| viewer-mhi | MHI | viewer-mhi@ex-rovr.com | User | 2022/06/06 11:28 |
| admin-kobe | kobe | admin-kobe@ex-rovr.com | Administrator | 2021/09/16 17:51 |
| viewer-kobe | kobe | viewer-kobe@ex-rovr.com | User | |
| admin-takasago | takasago | admin-takasago@ex-rovr.com | Administrator | 2022/01/21 18:56 |
| viewer-me | ME | viewer-me@ex-rovr.com | User | |

At the bottom right of the table, there are navigation buttons: '<<', '<', '1', '2', '>', '>>'.

3 Click the [Add] button.

The [User Registration] screen appears.

The screenshot shows a 'User Registration' form with the following fields and controls:

- Email Address* (text input)
- Full Name* (text input)
- Password* (text input)
- Password (Confirm)* (text input)
- Plant* (dropdown menu with '[Select]' selected)
- Language* (dropdown menu with '[Select]' selected)
- User Type* (radio buttons for Administrator and User, with User selected)
- Cancel and OK buttons at the bottom right.

4 Set the user's information.

| Item | Description |
|--------------------|---|
| Email Address | Enter their email address. The specified address will be the user ID at login. |
| Full Name | Enter the name of the account user. |
| Password | Initial password of the user. Passwords may contain single-byte alphanumerics, symbols, and blank characters. |
| Password (Confirm) | Re-enter the password to confirm. |
| Plant | Select the plant with which the user is affiliated. |
| Language | Select a language. |
| User Type | Select [Administrator] or [User]. |


5 Click the [OK] button.

13.4.3 Changing user information

To edit user information such as passwords:

- 1** Log in to the cloud.
- 2** Select [User Management] from the menu.
The [User Management] screen appears.
- 3** Click the [Edit] button of the user whose information you want to edit.

[Edit] button



The screenshot shows the 'User Management' interface. At the top, there are search filters for 'Plant Name' (set to 'All Plants') and 'User Name' (set to 'USER NAME'). Below the filters, there are checkboxes for 'User Type' with 'User' and 'Administrator' selected. A search button is on the right. Below the filters, there are '+ Add' and 'x Delete' buttons, and 'Num. results: 12'. The main part of the interface is a table with the following columns: Full Name, Affiliated Plant, Email Address, User Type, Last Sign in, and action buttons (Delete and Edit). The first row of the table is highlighted, and an orange arrow points to the 'Edit' button in that row.

| | Full Name | Affiliated Plant | Email Address | User Type | Last Sign in | |
|--------------------------|----------------|------------------|----------------------------|---------------|------------------|--|
| <input type="checkbox"/> | admin-mhi | MHI | admin-mhi@ex-rovr.com | Administrator | 2022/06/06 11:38 | <input type="checkbox"/> <input type="button" value="Delete"/> <input type="button" value="Edit"/> |
| <input type="checkbox"/> | teleop | MHI | teleop@ex-rovr.com | Administrator | 2021/11/16 15:55 | <input type="checkbox"/> <input type="button" value="Delete"/> <input type="button" value="Edit"/> |
| <input type="checkbox"/> | viewer-mhi | MHI | viewer-mhi@ex-rovr.com | User | 2022/06/06 11:28 | <input type="checkbox"/> <input type="button" value="Delete"/> <input type="button" value="Edit"/> |
| <input type="checkbox"/> | admin-kobe | kobe | admin-kobe@ex-rovr.com | Administrator | 2021/09/16 17:51 | <input type="checkbox"/> <input type="button" value="Delete"/> <input type="button" value="Edit"/> |
| <input type="checkbox"/> | viewer-kobe | kobe | viewer-kobe@ex-rovr.com | User | | <input type="checkbox"/> <input type="button" value="Delete"/> <input type="button" value="Edit"/> |
| <input type="checkbox"/> | admin-takasago | takasago | admin-takasago@ex-rovr.com | Administrator | 2022/01/21 18:56 | <input type="checkbox"/> <input type="button" value="Delete"/> <input type="button" value="Edit"/> |
| <input type="checkbox"/> | viewer-me | ME | viewer-me@ex-rovr.com | User | | <input type="checkbox"/> <input type="button" value="Delete"/> <input type="button" value="Edit"/> |

- 4** Edit the user's information on the [User Registration] screen.
- 5** Click the [OK] button.


■ Deleting users

To delete a registered user, click the [Delete] button for the user you want to delete. To delete multiple users, select the users' checkboxes and click the [Delete] button. When the confirmation message is displayed, click the [OK] button.

13.4.4 [User Management] screen

Displays registered users and adds, deletes, and edits users.

The [User Management] screen can be displayed only by administrator users. It cannot be displayed by general users.



■ Search area

You can specify search conditions and click the [Search] button to display only the users who match those conditions in the search results.

- Plant Name
- User Name
- User Type (general/administrator)

■ [Add] button

Adds a new user.

■ [Delete] button

Deletes the user(s) with their checkbox(es) selected in the User List.

■ User List

The following information is displayed in the list.

- Checkbox: Select the user for deletion.
- Full Name
- Affiliated Plant
- Email Address
- User Type (general/administrator)
- Last Sign in

[Delete] button: Deletes users.

[Edit] button: Edits the user's information.

13.5 Changing ASCENT's Affiliated Plant

13.5.1 Changing the affiliated plant

You can change which plant ASCENT is affiliated with.

If you want to patrol a newly created plant, change ASCENT's plant affiliation.

To run a scenario, ASCENT must be affiliated with the same plant as the scenario.

1 Log in to the cloud.


2 Select [Robots] from the menu.

The [Robots] screen appears.

For screen details, see "13.5.2 [Robots] screen" (page 13-15).


3 Under [Plant], select the plant where ASCENT is registered, and click the [Search] button.

ASCENTs that match your search conditions will appear in the list. You can also narrow the search by robot name.



4 Click the [Edit] button.


The [Robot Registration] screen appears.



- 5 Select the plant to change to in [Plant].
- 6 If necessary, edit the name of ASCENT in [Robot Name].
- 7 Click the [OK] button.

13.5.2 [Robots] screen

This section describes the configuration of the [Robots] screen. It displays a list of ASCENTs registered in the selected plant. Each ASCENT is displayed on the [Robots] screen.



■ Search area







Select the search conditions and click the [Search] button to display ASCENTs that match those conditions in the search results. You can specify the following search conditions:

- Plant name
- Robot name

■ Robots

Lists the robots that match the search conditions.

- Alert: Indicates ASCENT operating status by color.

| Color | State |
|---|----------------------|
|  | Running Autonomously |
|  | Paused |
|  | Under teleoperation |
|  | Error Occurred |
|  | On standby |
|  | Offline |

- Robot name
- Plant name
- IMSI: Displays ASCENT's SIM identification number.
- Serial No.: Displays ASCENT's serial number.

[Dashboard] button: Launches the dashboard and displays the operating status of the selected robot. (See "11.2 Real-Time Monitoring on the Dashboard" (page 11-2))

[Edit] button: Edit the information of the selected ASCENT. Only the plant name and robot name can be changed.

[Self-diagnosis] button: Performs ASCENT's self-diagnosis.

13.6 Issuing Alerts

13.6.1 Setting alerts

You can set conditions for alerts to be issued, such as gas concentration.

You can check issued alerts on the [Alerts] or [Plants] screens in the cloud.

■ About alert conditions


The scope of alert conditions may apply to a specific target or to an entire plant. When a target is the scope of application, the judgment is made when an action such as capturing an image is performed at the target. When the plant is the scope of application, the inside of the plant is constantly monitored during inspection.

Some targets require normal/abnormal threshold settings for monitoring, and others are judged automatically.

| Target to monitor | Scope of coverage | Method |
|--------------------------------|-------------------|-----------|
| Oxygen concentration | Target, Plant | Threshold |
| Hydrogen sulfide concentration | Target, Plant | Threshold |
| Carbon monoxide concentration | Target, Plant | Threshold |
| Combustible gas concentration | Target, Plant | Threshold |
| Temperature | Target, Plant | Threshold |
| Pinpoint Temperature | Target | Threshold |
| Rust (automatic) | Target | Auto |
| Leakage (automatic) | Target | Auto |
| Abnormal noise (automatic) | Target | Auto |
| Thermal image (automatic) | Target | Auto |
| White smoke (automatic) | Target | Auto |


Follow the steps below to set the alert issuance conditions.

- 1 Log in to the cloud.**
- 2 Select [Alerts] from the menu.**
The [Alerts] screen appears.



For screen details, see “13.6.3 [Alerts] screen” (page 13-22).

- 3 Click the [Alert Conditions] button.**
The [Alert Conditions] screen appears.
- 4 Click the [Add] button.**
The [Edit Alert Condition] screen appears.



- 5 Select [Plant] or [Target] in [Scope], and select the name of the plant or target.**

6 Select a target in [Target to monitor].

- Oxygen concentration
- Hydrogen sulfide concentration
- Carbon monoxide concentration
- Combustible gas concentration
- Temperature
- Pinpoint temperature
- Rust (automatic)
- Leakage (automatic)
- Abnormal noise (automatic)
- Thermal image (automatic)
- White smoke (automatic)

Selectable regardless of whether [Target] or [Scenario] is selected

Only selectable when [Target] is selected

7 When the selected [Target to monitor] is one of the following, set the normal/abnormal judgment threshold values.

- Oxygen concentration
- Hydrogen sulfide concentration
- Carbon monoxide concentration
- Combustible gas concentration
- Temperature
- Pinpoint Temperature

8 Select the status of the alarm to be issued (Alert, Warning, Info) for [Status].**9 Enter the title of the alert for [Title].****10 Click [OK].**

13.6.2 Checking alerts

You can check issued alerts on the [Alerts] or [Plants] screens in the cloud.

■ Check on the [Plants] screen

You can check the alert status by the color in the [Alerts] column of the plant list.

- Red: Alert
- Yellow: Warning
- Green: Info

Click ● in the [Alerts] column to display the [Alerts] screen.

You can view only the plants that are issuing alerts by clicking [Show only Plants with Alert].

■ Check the [Alerts] screen

- 1 Log in to the cloud.**
- 2 Select [Alerts] from the menu.**
The [Alerts] screen appears.
- 3 Select the plant from the [Plant] list.**
- 4 Select the alert status (Alert, Warning, Info) to display.**
- 5 Set the search conditions for the patrol results to be displayed.**
 - Title (text included in the title)
 - Target name
 - Registered date time
 - Solved date time

- 6** Click the [Search] button.
Messages that match your search conditions are displayed.

The screenshot displays the Alerts management interface. At the top, there is a search filter section. The Status filter is set to 'Info', 'Warning', and 'Alert'. The Title field is empty. The Plant dropdown is set to 'DE'. The Target dropdown is set to '[All Targets]'. Below the filter section, there are date range filters for 'Registered' and 'Solved' alerts. A blue 'Search' button is located on the right side of the filter section. Below the filter section, there is a table of alerts. The table has columns for 'Title', 'Plant', 'Target', 'Latest Value', and 'Last updated'. The table shows several alerts for 'Oxygen', 'Temperature', and 'CO level'. A red 'Marked as Solved' button is visible above the table. Numbered callouts 3, 4, 5, and 6 point to the Search button, the filter fields, the Plant dropdown, and the Search button respectively.

| | Title | Plant | Target | Latest Value | Last updated |
|--------------------------|-------------|-------|-------------|--------------|------------------|
| <input type="checkbox"/> | Oxygen | DE | level gauge | 21vo% | 2022/05/31 19:09 |
| <input type="checkbox"/> | Oxygen | DE | level gauge | 21vo% | 2022/05/31 19:09 |
| <input type="checkbox"/> | Temperature | DE | Fuel Tank | 0ppm | 2022/05/31 19:09 |
| <input type="checkbox"/> | CO level | DE | 2F B block | 0ppm | 2022/05/31 19:09 |
| <input type="checkbox"/> | CO level | DE | Fuel Tank | 0ppm | 2022/05/31 19:08 |
| <input type="checkbox"/> | Oxygen | DE | level gauge | 21vo% | 2022/05/31 19:08 |
| <input type="checkbox"/> | Temperature | DE | 1F A block | 0ppm | 2022/05/31 19:08 |

■ Marking an alert/warning as solved

Check the contents of the message and clear the alert/warning if the problem has been addressed. When marked as solved, the message remains on the [Alerts] screen, but it will not be reflected in the [Alerts] field on the [Plants] screen.

To clear, select the applicable message on the [Alerts] screen and click the [Marked as Solved] button.

13.6.3 [Alerts] screen

Displays a list of alerts that have occurred.

Search area

The screenshot shows the Alerts screen interface. At the top, there is a search area with filters for Status (Info, Warning, Alert), Title, Plant, and Target. Below the filters are sections for Registered and Solved alerts, each with date and time selection options and a Search button. The main area displays a table of alerts with columns for Title, Plant, Target, Latest Value, and Last updated. The table contains several rows of alert data, including Oxygen, Temperature, and CO level alerts for various plants and targets.

Alerts

■ Search area

If you specify the search conditions and click the [Search] button, alerts that match the conditions will be displayed in the search results.

You can specify the following search conditions:

- Status (Info/Warning/Alert)
- Title
- Plant name
- Target name
- Registered date time
- Solved date time

■ [Marked as Solved] button

Clears the alert selected in the alert list.

Cleared alerts will appear in the alert list, but will not be reflected in the plant status.

■ [Delete] button

Clears the alert selected in the alert list.

■ [Alert Conditions] button

Set the conditions for generating alerts.

For details, see “13.6.1 Setting alerts” (page 13-17).

■ Alerts

The following information is displayed in the list.


- **Checkbox:** Select the alert you want to mark as solved or delete.
- **Status:** The status of the alert is indicated by color.
 - (Green): Info
 - (Yellow): Warning
 - (Red): Alert
- **Title**
- **Plant name**
- **Target name**
- **Registered:** Displays the date and time when the alert was registered.
- **Solved:** Displays the date and time when the alert was cleared.

13.7 Other Management Screens

13.7.1 [Scenarios] screen

Displays a list of registered scenarios.

Displayed by selecting [Scenarios] from the menu.



■ Search area

If you specify the search conditions and click the [Search] button, alerts that match the conditions will be displayed in the search results.

You can specify the following search conditions:

- Plant name
- Included targets
- Scenario name
- Comment

■ Scenario list

- Plant name
- Scenario name
- Registered date time
- Updated date time
- Last execution date time
- Comment

13.7.2 [Contract Information] screen

Displays the EX ROVR contract plan, etc.

Displayed by selecting [Contract Information] from the menu.

☰ Contract Information

| Item | Information |
|-----------------|-----------------------------|
| Company Name | Mitsubishi Heavy Industries |
| Plan | Default |
| Num. Robots | 8 |
| Num. Plants | 12 |
| Starting Date | 2020/11/05 00:00 |
| Expiration Date | 2023/04/01 08:59 |

The following information is displayed.

- Company name
- Plan
- Number of robots
- Number of plants
- Starting date (displayed only for administrator users)
- Completion date (displayed only for administrator users)

13.7.3 [Teleop Terminals] screen (displayed only for administrator users)

Displays a list of Teleop terminals.

Displayed by selecting [Teleop Terminals] from the menu.

Only administrator users can view it.

The screenshot shows the 'Teleop Terminals' interface. At the top, there is a search form with a 'Model' dropdown menu set to '[All Models]'. Below this, there are input fields for 'Registered' (DATE(FROM), TIME(FROM), DATE(TO), TIME(TO)) and 'Name'. A blue 'Search' button is located to the right of the 'Name' field. Below the search form, it indicates 'Num. results: 2'. A table displays the following data:

| Name | Model | Company | IMSI | Serial No. | Registered | Updated | |
|------------|--------|-----------------------------|-----------------|------------|------------------|------------------|----------------------|
| ER20TT-001 | ER20TT | Mitsubishi Heavy Industries | 440103212904071 | ER20TT-001 | 2022/03/28 10:08 | 2022/03/28 10:08 | Edit |
| ER20TT-00A | ER20TT | Mitsubishi Heavy Industries | 440103217503335 | ER20TT-00A | 2022/03/28 10:13 | 2022/03/28 10:13 | Edit |

■ [Search] button

You can search by specifying the model name, registration date and time, and terminal name.

■ List of Teleop terminals

The following information is displayed in the list.

- Teleop terminal name
- Model name
- Company name
- IMSI
- Serial number
- Registered date time
- Update date time

Click the [Edit] button to edit the terminal name.

13.7.4 [Charging Stations] screen (displayed only for administrator users)

Displays a list of Charging Stations.

Displayed by selecting [Charging Stations] from the menu.

Only administrator users can view it.

Charge Stations

Model: [All Models]

Registered: DATE(FROM) TIME(FROM) ~ DATE(TO) TIME(TO) Name: [Search]

Num. results: 2

| Name | Model | Company | Serial No. | Registered | Updated | |
|------------|--------|-----------------------------|------------|------------------|------------------|----------------------|
| ER20CS-001 | ER20CS | Mitsubishi Heavy Industries | ER20CS-001 | 2022/03/28 10:09 | 2022/03/28 10:09 | Edit |
| ER20CS-00A | ER20CS | Mitsubishi Heavy Industries | ER20CS-00A | 2022/03/28 10:11 | 2022/03/28 10:11 | Edit |

■ [Search] button

You can search by specifying the model name, registration date and time, and Charging Station name.

■ Charging Station

The following information is displayed in the list.

- Station name
- Model name
- Company name
- Serial number
- Registered date time
- Update date time

Click the [Edit] button to edit the Charging Station name.

MEMO

Chapter 14 Basic ASCENT Operation

This chapter describes the basic ASCENT operating procedures using a Teleop terminal. ASCENT teleoperations are required to create scenarios and maps. If you are new to ASCENT, read this chapter to train and familiarize yourself with its basic operations.

ASCENT should be accompanied by an attendant during training. The attendant reports the movement and orientation of ASCENT and surrounding conditions to the teleoperator. The teleoperator should practice correct operation by referring to the attendant's reports. The attendant should confirm the precautions noted in "4.2 ASCENT Teleoperator And Attendants" (page 4-4) while accompanying ASCENT.

Teleoperation of ASCENT for cases other than map/scenario creation should be performed by personnel with sufficient training and a certain level of skill in teleoperation.

WARNING

- **Avoid teleoperation where radio connections are difficult or unstable.**

ASCENT may behave unexpectedly or be unable to stop by teleoperation.

- **Avoid teleoperation when visibility is poor.**


There is risk of collision or slipping.

If visibility is poor due to insufficient light, such as in the rain, turn on surrounding lights so that the surroundings are clearly visible before teleoperating.

14.1 Exiting from the Charging Station (Undocking)

Ensure that ASCENT is in the Charging Station and that the status LED is lit yellow (charged).

- 1 Open the [Predefined Motions (Navi)] tab on the Teleop screen.



- 2 Select [Exit Charging Station] on the [Predefined Motions] panel.

- 3 Click [Execute].

The exit (undocking) process starts.

ASCENT starts moving after performing initialization and self-diagnostics.


ASCENT stops when it exits the Charging Station, and the status LED blinks green (teleoperation mode).

14.2 Moving ASCENT

To move ASCENT, open the [Truck] tab on the Teleop screen.

To prevent ASCENT moving by mistake, you need to operate the joystick and buttons at the same time when using the gamepad.

To move ASCENT, press and hold the A button (or X or Y button) while operating the left joystick. The button determines the speed, and the left joystick determines the direction of movement.



ASCENT stops when you release either the button or the joystick.

14.3 Checking Camera Images


Images from the cameras installed on ASCENT are displayed on the Teleop screen. Use the camera images to check ASCENT’s surrounding conditions during teleoperation.

Truck camera

Images from the cameras installed on ASCENT’s front and rear appear in the [Truck Camera (Front)] and [Truck Camera (Rear)] panels.

Surveillance camera

The image from the surveillance camera on ASCENT’s manipulator is displayed in the [Surveillance Camera] panel on the Teleop screen. You can move the manipulator to view surrounding monitoring targets. For information on operating the manipulator, see “14.8 Manipulator Operation” (page 14-21).



14.4 Entering the Charging Station (Docking)


Use the Teleop screen to dock ASCENT in the Charging Station.

- 1** Open the [Truck] tab on the Teleop screen.
- 2** Move ASCENT to the front of the Charging Station, aiming at the dotted line on the Charging Station's docking/undocking (entry/exit) guide plate. (Figure A)
- 3** Continue to advance, and stop when ASCENT is entirely over the guide plate. (Figure B)
- 4** Rotate ASCENT 180° to face away from the Charging Station. (Figure C)
To rotate, press and hold the A button on the gamepad and tilt the left joystick to the left or right. When stopped in the correct position, ASCENT's laser is reflected in the Charging Station's stopper.

An attendant should ensure that ASCENT is stopped centered over the dotted line on the docking/undocking guide plate.


NOTE

- **Enter along the dotted line of the guide plate.**
If the entry angle is incorrect, ASCENT may crash into the Charging Station.



- 5** Open the [Predefined Motions (Navi)] tab on the Teleop screen.

6 On the [Predefined Motions] panel, select [Enter Charging Station] and click [Execute].



ASCENT will automatically enter the Charging Station.


14.5 Crossing a Step

ASCENT can cross over steps up to 15 cm high.

To cross a step, drive while raising and lowering the sub tracks according to the step.

14.5.1 To Raise and lower the sub tracks


With the [Truck] tab open on the Teleop screen, raise and lower the front sub tracks (L1 and L2 buttons) and rear sub tracks (R1 and R2 buttons) on the gamepad.




14.5.2 Driving over a step

To drive over a step, align ASCENT to face it.

ASCENT's teleoperator uses the guidelines in the truck camera image to check alignment with the step. An attendant should visually confirm ASCENT's status.




Also, while driving, check the pitch of ASCENT and the sub tracks on the Attitude panel on the Teleop screen. If the main body of ASCENT pitches too far forward or back, it could topple over. Adjust the the front and rear sub track angles to avoid excessive pitch.




 **WARNING**

- **ASCENT must be aligned to face the step.**
If ASCENT attempts climbs the step diagonally, it may lose its balance and topple over.


1 Face ASCENT toward the step.




- 2 Lower the front sub tracks to 45°, and slightly lower the rear sub tracks.**
The back of the main body should be slightly raised.




- 3 Advance with that attitude.**
The front sub tracks grab the step to climb.
As it proceeds, the main body pitches backwards, so lower the rear sub tracks little by little to keep the main body close to level.
The attendant should confirm that ASCENT has climbed onto the step, and inform the teleoperator.




- 4 As the main body of ASCENT advances forward, continue to lower the rear sub tracks so that the pitch of the main body remains near level.**



- 5** When the main body is fully on the step, lower the front sub tracks to -30° .




- 6** Advance until the front sub tracks touch the floor and the rear sub tracks get onto the step, then raise the rear sub tracks to 45° .




- 7** Advance further.

As the rear sub tracks grab the step, gradually descend.

Gradually raise the front sub tracks so that the main body does not pitch forward too much.




- 8 After completely descending from the step, raise the front and rear sub tracks to return to the driving attitude.




14.6 Ascending and Descending Stairs

To go up and down stairs, raise and lower the sub tracks as you proceed, just like for the step. For information on raising and lowering the sub tracks, see “14.5.1 To Raise and lower the sub tracks” (page 14-7).

To drive on stairs, ASCENT must begin by facing them. ASCENT’s teleoperator uses the guidelines in the truck camera image to check alignment with the step. An attendant should visually confirm ASCENT’s status.



Also, while driving, check the pitch of ASCENT and the sub tracks on the Attitude panel on the Teleop screen. If the main body of ASCENT pitches too far forward or back, it could topple over. Adjust the angles of the front and rear sub tracks while checking the pitch attitude.




An attendant should continually check the attitude of ASCENT while ascending and descending, and inform the operator of the situation.

WARNING


- **ASCENT must be aligned to face the stairs.**
If ASCENT attempts to climb stairs diagonally, it may lose its balance and topple over.

14.6.1 Climbing stairs


- 1 Align ASCENT to face the stairs.




- 2 Set the front sub tracks to 45° and the rear sub tracks to 0°.




- 3 Advance until the front sub tracks mount the first stair step.



- 4 Continue to advance.
ASCENT's tracks grab the stairs as it advances.




The attendant should ensure that ASCENT is straight on the stairs.




5 Advance until ASCENT is fully on the stairs.

The teleoperator should ensure that the rear sub tracks have moved off the floor by checking the image from the rear truck camera.


The attendant should again ensure that ASCENT is heading straight forward on the stairs.



6 Climb the stairs as-is without changing the angles of the sub tracks.



7 Climb to the top.




8 When ASCENT's front sub tracks have cleared the top stair, lower the front sub tracks.


The attendant should ensure that the front sub tracks have cleared the top stair, and tell the teleoperator.

If the attitude of the main body pitches backward when the front sub tracks are lowered, the front sub tracks have not cleared the top stair yet, so advance ASCENT further forward.

The attendant should ensure that the front sub tracks touch the floor. Once the front sub tracks touch the floor, do not lower them any further.




- 9** Next, lower the rear sub tracks a little to lift the back of the ASCENT main unit.




- 10** Continue to advance slowly.

When ASCENT's center of gravity is on the landing, raise both sub tracks and advance ASCENT further.

The attendant should ensure that the ASCENT's center of gravity is on the landing.



- 11** When ASCENT is completely on the upper floor, raise the front and rear sub tracks to return to the driving attitude.




14.6.2 Descend the stairs

When descending stairs, moving ASCENT's center of gravity becomes important. If the center of gravity is high away from the stairs, ASCENT may lose its balance and slide down.


1 Align ASCENT to face the stairs.

The teleoperator should ensure proper alignment using the guidelines in the image from the front truck camera.

The attendant should ensure proper ASCENT alignment from behind.




2 Set the front and rear sub tracks to 0°.




3 Lower the front sub tracks slightly.

The front of the main body rises slightly.




4 Advance until the front sub tracks overhang the stairs and the main body becomes level.



5 Set the front and rear sub tracks to -20°.

The front of the main body will be slightly lower.

If the front sub tracks are not in contact with the stairs, lower them until they are. The attendant should check the angle of the front sub tracks and report to the teleoperator if the sub tracks are not in contact with the stairs.



! WARNING


- If the front sub tracks are not in contact with the stairs, ASCENT may lose balance and slip when it moves forward.

6 Continue to advance slowly.

As ASCENT descends the stairs, its main body tilts forward and the center of gravity rides on the front sub tracks.

In the truck camera image, the field of view drops sharply.

The attendant should ensure that the center of gravity is on the front sub tracks, and inform the teleoperator.




! WARNING

- Lowering the sub tracks in this state may cause loss of balance and slipping.


7 Raise the rear sub tracks gradually to 0°.

If the main body moves when the rear sub tracks are raised, lower them back and advance a little, then raise them again.


The attendant should again ensure that ASCENT is heading straight forward on the stairs.




8 Raise the front sub tracks to 0°.




9 Continue to advance.




10 When the front sub tracks touch the floor, raise the front and rear sub tracks a little. The attendant should inform the teleoperator when the front sub tracks touch the floor.




11 Advance while raising the front and rear sub tracks little by little.



12 Raise the front and rear sub tracks to 30°.



13 Continue to advance, and when ASCENT is completely down, return to the driving attitude.




14.7 Changing Sub Track Angles

The four sub tracks can be changed all at once or separately.


For details on moving the front and rear sub tracks up and down, see “14.5.1 To Raise and lower the sub tracks” (page 14-7).

■ Changing the angle of the front, back, left and right sub tracks all at once



1 Press the D-pad keys in any direction.

The screen for selecting sub track attitude is displayed.




2 Use the D-pad keys to select the attitude to which you want to change.

- Attitude 1: 90°
- Attitude 2: 110°
- Attitude 3: 0°
- Attitude 4: 45°

3 Press the B button (attitude execution).

■ Moving the front, back, left and right sub tracks up and down independently



1 Press and hold the **BACK** button (Function) while pressing the **X** button (Synchronous/Independent) .
Operation changes to the independent mode.

2 Move the right joystick back and forth while selecting the sub track to move with the **L1, L2, R1, or R2** buttons.

| | |
|----|-----------------------|
| L1 | Right rear sub track |
| L2 | Left rear sub track |
| R1 | Right front sub track |
| R2 | Left front sub track |

3 When the operation is finished, press and hold the **BACK** button (Function) while pressing the **X** button (Synchronous/Independent) as in step 1.
The operating mode returns to synchronous sub track operation.


14.8 Manipulator Operation

Click the [Manip.] tab to operate the manipulator from the Teleop screen.

14.8.1 Extending the manipulator


You can extend the manipulator and point it forward, left, or right.

- 1 Open the [Manip.] tab on the Teleop screen.
- 2 Click [Attitude Change] on the [ManiInfo] panel.



- 3 Click [[B] Confirm].
The Attitude Change screen appears.

4 Click Attitude 1 to Attitude 3 so that the manipulator is directed to the target location.



5 Click [[B] Confirm].

6 Click [Yes] when the message is displayed.
The manipulator angle changes.

14.8.2 Adjusting manipulator orientation

You can move the fingertips of the manipulator up, down, left, and right, or back and forth.

- 1 Select [Gamepad Operation] on the [ManiInfo] panel, and click [[B] Confirm].

The screenshot shows the 'ManiInfo' panel with the following data:

| -180.0 | | +180.0 | |
|----------|--------|-------------|--------|
| S1[deg]: | 90.00 | X[mm]: | 75.00 |
| S2[deg]: | -30.00 | Y[mm]: | 281.57 |
| E1[deg]: | 85.00 | Z[mm]: | 946.27 |
| E2[deg]: | -0.00 | Roll[deg]: | -90.00 |
| W1[deg]: | 35.00 | Pitch[deg]: | 90.00 |
| W2[deg]: | -0.00 | Yaw[deg]: | 0.00 |

Buttons: Attitude Change, Gamepad Operation (highlighted), [B] Confirm

- 2 Adjust the orientation of the manipulator with the gamepad.

Press and hold the A button to reposition the fingertips while maintaining the attitude (posture) of the hand (position manipulation).

Press and hold the Y button to rotate the fingertips while maintaining the position of the hand (attitude manipulation).

| Manipulator Movement | Gamepad Operation |
|---|--|
| Move the tip back and forth, and left and right | A button (position manipulation) + left joystick front, back, left, and right |
| Move the tip up and down | A button (position manipulation) + R2 button (up) or R1 button (down) |
| Point the tip to the left or right | Y button (attitude manipulation) + left joystick left and right |
| Point the tip up or down | Y button (attitude manipulation) + left joystick up and down |
| Rotate the tip | Y button (attitude manipulation) + L2 button (left rotation) or R2 button (right rotation) |

14.8.4 Manipulating the hand

NOTE

- **Do not use manipulator to grab sharp objects, objects hotter than 100°C or colder than 0°C, or chemicals that erode rubber.**
Otherwise, the rubber at the manipulator's fingertips will be damaged.

Hold down any of the A, B, or Y buttons and press the right side of the D-pad to close the hand. Press the left side of the D-pad to open the hand.

14.8.5 Returning to the stowed attitude (moving attitude)


When you finish operating the manipulator and want to move ASCENT, return the manipulator to the stowed attitude.

CAUTION

- **The manipulator must be stowed before moving.**
If ASCENT is moved without stowing the manipulator, it could hit someone or something and cause injury or damage.
Also, vibration may cause the manipulator to malfunction.

1 Click [Attitude Change] on the [ManiInfo] panel, and click [[B] Confirm].
The Attitude Change screen appears.

2 Select [Stowed Attitude], and click [[B] Confirm].




3 Click [Yes] when the message is displayed.

14.9 Other Operations

14.9.1 Speaker output of audio data


The prerecorded sound source is output from the speaker. Use to emit sound for alerting.

- 1 Open the [Predefined Motions (Navi)] tab.
- 2 Select [Speaker Command] on the [Predefined Motions] panel and click [Execute].



The settings screen appears.

- 3 Select the audio data number and volume.



- 4 Click the [Playback] button.
Playback of the sound source starts.

5 To stop playback, click the [Stop] button.

If you want to perform other operations while the sound plays, press the X button to close the [Speaker Playback] screen and choose another tab.

You can set the audio data number and volume in the properties of “play-audio” motion when creating a scenario.

14.10 Displaying the Gamepad Operation Guide

Press the gamepad’s help button to display the Gamepad Operation Guide on the Teleop screen.



MEMO


Chapter 15 Troubleshooting

15.1 Troubles During Teleoperation

If a problem occurs with ASCENT during teleoperation, an error message appears on the Teleop screen. The error message displays the most severe error that has occurred.

To check the details, click [Error Code] on the [Status] panel on the Teleop screen.

Clicking [Error Clear] clears the displayed error.



On the [Status] panel, the incident class is displayed under [Error Code], and the error code is displayed for each class.

The incident classes are shown below.

| Incident Class | Incident Error Description |
|----------------|---|
| Navi | Scenario execution (autonomous control) anomaly |
| Auto | Required autonomous control information anomaly |
| Media | Camera, microphone, or speaker anomaly |
| Robo | An anomaly occurred during ASCENT processing, or the stop button was pressed |
| Syscon | System controller board power supply or related anomaly |
| Main | Main track drive system anomaly, or CAN communication error with servo |
| Sub | Sub track drive system anomaly, or CAN communication error with servo |
| IMU | IMU sensor anomaly, or communication error with IMU sensor |
| Charge | Charging device anomaly, or communication error with power reception unit |
| Gas | Gas detector anomaly, or communication error with gas detector |
| Mani | Manipulator controller or drive system anomaly, or CAN communication error with servo |


There are three types of error codes, depending on their severity.

| Error Code | Anomaly Class | ASCENT Status |
|------------|------------------------|---|
| 200-255 | Fatal anomaly | Control stopped. If stopped on stairs or slopes, there is risk of slipping. The sub tracks may move by themselves. |
| 100-199 | Uncontrollable anomaly | Operation stops, but control continues. If stopped on stairs or slopes, it stays in that position. The sub tracks stop at the set angle. |
| 0-100 | Warning | Operation continues. |

For more information on error codes, see “15.5.1 Error code list” (page 15-8).

15.2 Troubles Using Scenario Maker

If there is an error in the scenario in Scenario Maker, “Scenario data error” is displayed for the Scenario Status, and hovering the mouse over the Scenario Status displays an error message.




15.2.1 Scenario errors

| Message | Contents |
|---|---|
| (Motion name) + Problem with asynchronous specification | The specification of the asynchronous motion is incorrect. |
| (Motion name) + An anomaly was found in the motion name | An undefined motion is specified in the scenario. |
| (Motion name) + An anomaly was found in the motion parameters | There is an anomalous motion parameter value. |
| (Motion name) + Not enough motion parameters | Insufficient number of motion parameters. |
| (Path name) + path motion before map loading | A path motion was specified before loading a map. Specify a load-map motion before the path motion. |
| The scenario is empty | The scenario is empty. Specify a valid scenario. |
| (Map name) + An anomaly was found in map data | An anomaly was found in the data. |
| (Path name) + An anomaly was found in path data | An anomaly was found in the data. |

15.3 Troubles During Auto Patrol

If an error occurs in ASCENT during auto patrol, the robot status on the dashboard is displayed in red. Click the Robot Status to view the status of each module, and which module has the error.

Robot Status



For error details, launch the Teleop terminal and check the [Error Code] on the [Status] panel of the Teleop screen.

You can also check ASCENT's status in the [Alerts] section of the [Robots] screen in the cloud.

15.4 Specific Cases

15.4.1 During scenario execution

■ A different route is taken when executing a path motion

ASCENT may be unable to recognize its location correctly.

Do the following:

- 1 Stop ASCENT using the Teleop terminal.
- 2 On Scenario Maker's [Execute] tab, click [Robot Positions] then click ASCENT's current location on the map.
- 3 On the [Scenario] tab, select the appropriate path motion.
- 4 On the [Execute] tab, click [Execute to end] or [Executed selected lines] to resume the scenario.

If it reoccurs, change the path or recreate the map.

■ When a path motion is executed, obstacle detection causes ASCENT to stop where there are no obstacles

ASCENT may consider itself an obstacle.

Ensure the sub track angle is 110 degrees. Also check for any obstructions around the LiDAR.

15.4.2 During teleoperation

■ The manipulator camera image on the Teleop screen is interrupted

Communication may have been lost and could not recover.

Double-click on the panel of the manipulator camera image. Communication should be restored.

■ Teleop not working even with ASCENT powered on


Too much time required to become ready for manipulator teleoperation with the gamepad or to create a scenario in Scenario Maker.

- Battery charge may be insufficient. Wait until charging is completed.
- If it does not work after waiting, turn the Teleop terminal's power off and then on again. If it still does not work, move the ASCENT to a non-hazardous area and power it off and on again.
- If communication conditions are poor, move to a better wireless location and try teleoperating again.


■ Gamepad operation behaves differently from that described in the instruction manual

The operation mode of the gamepad may have been changed. Check the following two places on the gamepad.

- Is the MODE indicator light on the gamepad lit?
If it is lit, press the MODE button to turn off.



- Is the changeover switch on the back of the gamepad on the D side?
If it is on the D side, switch it to the X side.



15.4.3 When docking (Entry) and undocking (Exit)

■ ASCENT does not reverse to dock (Entry)

- Docking was attempted by a method other than [Charging Station Entry] on the [Predefined Motions (Navi)] tab of the Teleop screen. To dock normally, use [Charging Station Entry] on the [Predefined Motions (Navi)] tab.

■ ASCENT repeatedly goes in and out of the Charging Station when docking (Entry)

There are the following possibilities: Check and eliminate the cause.

- The Charging Station's MODE switch is set to PURGE.
- The glass surface of the Charging Station or ASCENT is dirty. Clean them.
- ASCENT has stopped in a place where it cannot dock.
- Lifting is occurring when stopped
- There is dirt or foreign matter on ASCENT's running surfaces.
- The rollers on the Charging Station floor do not rotate normally.

■ The cylinder does not come out when ASCENT has stopped

There are the following possibilities: Check and eliminate the cause.

- The air source is not supplying pressure.
- The supply pressure setting is incorrect. Docking may not be possible due to insufficient cylinder pressure.
- Air may be leaking due to damage to the hose or air delivery device. If you find any damage, contact your maintenance company.

15.5 Error List

15.5.1 Error code list

The error codes displayed in the [Status] panel of the Teleop screen are described for each incident class.

■ Navigation control errors (incident class: Navi)

| Error Code | Cause | Recovery Method | |
|------------|---|---|---|
| 31 | Attempted to change the scenario during operation | <ul style="list-style-type: none"> The operation will continue with the warning. | |
| 41 | Confirming temperature (exit) | | |
| 42 | Checking temperature (stairs): Stand by while main track motor temperature is 80°C or higher | | |
| 43 | Rebooting LiDAR | | |
| 51 | Stopped due to obstacle | | |
| 101 | System Controller Error Detected (syscon output error 100 or higher) | <ul style="list-style-type: none"> Click [Error Clear]. If it reoccurs, move to a non-hazardous area and turn power off and on again. If it recurs, write down the error number and contact the maintenance company. | |
| 111 | Manipulator Controller Error Detected (manicon output error 100 or more) | | |
| 121 | System Controller Communication Error (communication response anomaly, receive timeout) | | |
| 122 | Manipulator Controller Communication Error (receive timeout) | | |
| 123 | Syscon Controller Area Network Communication Error (receive timeout, CAN receive data anomaly) | | |
| 124 | Discontinuity in System Controller Thermometer (output error 21 · 23 · 25 · 27 · 29 · 31 · 33 · 35) | | |
| 125 | Autonomous Control Sensor Error (101, 102, 103) | | |
| 126 | System Controller IMU Warning | | |
| 131 | Obstacle Detection (a certain period of time has passed since obstacle detected during path motion) | | <ul style="list-style-type: none"> Remove the obstacle. Set the sub track angles to 110 degrees. If the route is narrow, turn off the Obstacle Detection function. |

| Error Code | Cause | Recovery Method |
|------------|--|---|
| 132 | Own Position Estimate Failure (load_map, path, etc.) | <ul style="list-style-type: none"> • Reconfirm the location of the robot and its location on the map. • Move the robot to the correct location on Scenario Maker. • Recreate the map. |
| 133 | Robot Attitude Error (pitch \geq 60 deg or roll \geq 15 deg) | <ul style="list-style-type: none"> • Click [Error Clear]. • Check whether the robot is on top of something and remove the cause. |
| 134 | Path Error | <ul style="list-style-type: none"> • Click [Error Clear]. • The robot is too far from its target path. Remove the cause. |
| 135 | Scenario Error (scenario file read failure, asynchronous operation is continuous) | <ul style="list-style-type: none"> • Click [Error Clear]. • Check the contents of the scenario specified by Scenario Maker, and identify the motion that caused the problem. |
| 136 | Cannot operate in the current driving mode (motion during Charging Station Exit) | |
| 137 | Step Detection Error (obstacle motion) | <ul style="list-style-type: none"> • Click [Error Clear]. • Check for a problem with the obstacle motion settings, such as set values different from the actual step. |
| 138 | Marker Detection Error | <ul style="list-style-type: none"> • Click [Error Clear]. • Ensure that no marker is obscured and is not too high. • Check the relative positions of the robot and the markers to see if they are too far apart. |
| 139 | Align Motion Error | <ul style="list-style-type: none"> • Click [Error Clear]. • Review the align motion setting values. |
| 141 | Entry/exit self-diagnostics: Battery voltage below 25V threshold | <ul style="list-style-type: none"> • The battery is low. Click [Error Clear] and return the robot by teleoperation to the Charging Station to recharge. |
| 142 | Entry/exit self-diagnostics: System controller temperature measurement anomaly (20/22/24/26/28/30/32/34) | <ul style="list-style-type: none"> • Robot temperature is rising. Wait until the temperature drops. |
| 144 | Entry/exit self-diagnostics: Gas detection error (Warning occurs) | <ul style="list-style-type: none"> • Click [Error Clear]. • If it reoccurs, move to a non-hazardous area and turn power off and on again. • If it recurs, write down the error number and contact the maintenance company. |
| 151 | Stairs self-diagnostics: Below battery voltage threshold | <ul style="list-style-type: none"> • The battery is low. Click [Error Clear] and return the robot by teleoperation to the Charging Station to recharge. |
| 152 | Stairs self-diagnostics: Warning 42 has elapsed for 10 seconds | <ul style="list-style-type: none"> • Robot temperature is rising. Wait until the temperature drops. |

| Error Code | Cause | Recovery Method |
|------------|---|--|
| 160 | Stairs Operation error (stairs motion ended abnormally) | <ul style="list-style-type: none"> • Click [Error Clear] to switch to Teleop mode. • Ensure that the dimensions of the stairs are set properly and that the markers are within the robot's detection range. • Ensure that the landing shape is correct and that climbing and descending are correctly set. • Resume the scenario and see how it behaves. |

■ **Autonomous control sensor errors (incident class: Auto)**

| Error Code | Cause | Recovery Method |
|------------|-------|---|
| 101 | LIDAR | <ul style="list-style-type: none"> • Click [Error Clear]. • Dock the robot and execute the scenario again from the schedule. • If it reoccurs, move to a non-hazardous area and turn power off and on again. • If it recurs, write down the error number and contact the maintenance company. |
| 102 | ODOM | |
| 103 | IMU | |

■ **Environment sensor errors (incident class: Media)**

| Error Code | Cause | Recovery Method |
|------------|----------------------------------|---|
| 1 | Microphone Device error | <ul style="list-style-type: none"> • The operation will continue with the warning. |
| 2 | Speaker Device error | |
| 3 | Microphone/Speaker failure | |
| 4 | Surveillance Camera error | |
| 5 | 360° optical Camera error | |
| 6 | Left Thermal Image Camera error | |
| 7 | Right Thermal Image Camera error | |
| 8 | Communication error | |

■ Robot errors (incident class: Robo)

| Error Code | Cause | Recovery Method | |
|------------|--|--|--|
| 10 | Low Battery | <ul style="list-style-type: none"> The operation will continue with the warning. | |
| 75 | Battery Charging Not Possible, Charging Initiation Failed | | |
| 76 | Battery Charging Not Possible, Charging Error Detected | | |
| 77 | Battery Charging Not Possible, docking error during charging | | |
| 101 | Stop Notification Received | <ul style="list-style-type: none"> Click [Error Clear]. | |
| 102 | Manipulator Emergency Stop Notification Received: Stop | <ul style="list-style-type: none"> Click [Error Clear]. Refer to the cause column to determine the cause. Try again. If it reoccurs, turn the power off and then on again in a non-hazardous area. If it recurs, write down the error number and contact the maintenance company. | |
| 120 | Charging Station Entry Not Possible, Sub Track Operation Timeout | | |
| 121 | Charging Station Entry Not Possible, Charging Station Distance Anomaly | | |
| 122 | Charging Station Entry Not Possible, Too Many Retries | | |
| 130 | Charging Station Exit Not Possible, Union Limit Switch Timeout | | |
| 131 | Charging Station Exit Not Possible, Rear Proximity Sensor Distance Error | | |
| 142 | Battery Charging Not Possible, Docking error during charging | | |
| 250 | Emergency Stop Detected (Black Button), Notification Received | | |
| | | | <ul style="list-style-type: none"> Click [Error Clear]. |

■ System controller (power supply/temperature) errors (incident class: Syscon)

| Error Code | Cause | Recovery Method | |
|------------|---|---|--|
| 20 | Internal Measurement Thermistor #1: Abnormal Temperature Range | <ul style="list-style-type: none"> The operation will continue with the warning. | |
| 21 | Internal Measurement Thermistor #1: Disconnected | | |
| 22 | Internal Measurement Thermistor #2: Abnormal Temperature Range | | |
| 23 | Internal Measurement Thermistor #2: Disconnected | | |
| 24 | Internal Measurement Thermistor #3: Abnormal Temperature Range | | |
| 25 | Internal Measurement Thermistor #3: Disconnected | | |
| 26 | Internal Measurement Thermistor #4: Abnormal Temperature Range | | |
| 27 | Internal Measurement Thermistor #4: Disconnected | | |
| 28 | Internal Measurement Thermistor #5: Abnormal Temperature Range | | |
| 29 | Internal Measurement Thermistor #5: Disconnected | | |
| 30 | Internal Measurement Thermistor #6: Abnormal Temperature Range | | |
| 31 | Internal Measurement Thermistor #6: Disconnected | | |
| 32 | Internal Measurement Thermistor #7: Abnormal Temperature Range | | |
| 33 | Internal Measurement Thermistor #7: Disconnected | | |
| 34 | Internal Measurement Thermistor #8: Abnormal Temperature Range | | |
| 35 | Internal Measurement Thermistor #8: Disconnected | | |
| 70 | System Controller Power Status Error | | |
| 71 | Branch Board Power Status Error | | |
| 98 | Robot Internal Pressure Monitor Warning: Constant Monitoring | | |
| 99 | Robot Internal Pressure Difference Monitor Warning: Constant Monitoring | | |

| Error Code | Cause | Recovery Method |
|------------|--|---|
| 150 | Back Sonar Anomaly: Measured Value Exceeds Threshold Value (Disconnection) | <ul style="list-style-type: none"> Click [Error Clear]. Refer to the cause column to determine the cause. |
| 251 | EEPROM Error (Parameter Storage) | <ul style="list-style-type: none"> Try again. |
| 253 | Controller Area Network Communication Error MAIN | <ul style="list-style-type: none"> If it reoccurs, turn the power off and then on again in a non-hazardous area. If it recurs, write down the error number and contact the maintenance company. |

■ Main track errors (incident class: Main)

| Error Code | Cause | Recovery Method |
|------------|--|--|
| 91 | Right Main Track Servo Warning (Warning_bit = ON) | <ul style="list-style-type: none"> The operation will continue with the warning. |
| 94 | Left Main Track Servo Warning (Warning_bit = ON) | <ul style="list-style-type: none"> Click [Error Clear]. Check the appearance of the main tracks for any anomalies. |
| 160 | Right Main Track Motor Temperature (Disconnection/Temperature Anomaly) | <ul style="list-style-type: none"> Teleoperate with the gamepad. |
| 161 | Left Main Track Motor Temperature (Disconnection/Temperature Anomaly) | <ul style="list-style-type: none"> If it reoccurs, turn the power off and then on again in a non-hazardous area. |
| 221 | Right Main Track Servo Error | <ul style="list-style-type: none"> If it recurs, write down the error number and contact the maintenance company. |
| 224 | Left Main Track Servo Error | |
| 231 | Right Main Track communication error | |
| 234 | Left Main Track communication error | |

■ Sub track errors (incident class: Sub)

| Error Code | Cause | Recovery Method |
|------------|---|--|
| 90 | Right Front Sub Track Servo Warning (Warning_bit = ON) | <ul style="list-style-type: none"> The operation will continue with the warning. |
| 92 | Right Rear Sub Track Servo Warning (Warning_bit = ON) | |
| 93 | Left Front Sub Track Servo Warning (Warning_bit = ON) | |
| 95 | Left Rear Sub Track Servo Warning (Warning_bit = ON) | |
| 170 | The difference from the potentiometer input value of the right front servo is abnormal. | <ul style="list-style-type: none"> Click [Error Clear]. Check the appearance of the sub track for any anomalies. Teleoperate with the gamepad. If it reoccurs, turn the power off and then on again in a non-hazardous area. If it recurs, write down the error number and contact the maintenance company. |
| 172 | The difference from the potentiometer input value of the right rear servo is abnormal. | |
| 173 | The difference from the potentiometer input value of the left front servo is abnormal. | |
| 175 | The difference from the potentiometer input value of the left rear servo is abnormal. | |
| 220 | Right Front Sub Track Servo Error | |
| 222 | Right Rear Sub Track Servo Error | |
| 223 | Left Front Sub Track Servo Error | |
| 225 | Left Rear Sub Track Servo Error | |
| 230 | Right Front Sub Track communication error | |
| 232 | Right Rear Sub Track communication error | |
| 233 | Left Front Sub Track communication error | |
| 235 | Left Rear Sub Track communication error | |

■ IMU errors (incident class: IMU)

| Error Code | Cause | Recovery Method |
|------------|--------------------------------|---|
| 50 | IMU RS232C communication error | <ul style="list-style-type: none"> The operation will continue with the warning. |
| 51 | IMU Device error | |

■ Charging device errors (incident class: Charge)

| Error Code | Cause | Recovery Method |
|------------|--|--|
| 80 | Power reception unit: RS-485 communication error | <ul style="list-style-type: none"> The operation will continue with the warning. |
| 83 | Power reception unit: Heatsink 100°C or higher (Error: 7) | |
| 84 | Receive Unit, Over-Voltage (Error: 14) | |
| 85 | Receive Unit, Over-Current (Error: 1) | |
| 86 | Receive Unit, IrDA I/F Communication Error (Error: 12) | |
| 87 | Receive Unit, Power Transmission Side Error (Error: 15) | |
| 89 | Power reception unit: Current Error (error: 16) | |
| 181 | Power reception unit: Non-volatile memory operation (Error: 31) | <ul style="list-style-type: none"> Click [Error Clear]. Check the appearance of the power reception unit for any abnormalities. Re-enter. If it recurs, write down the error number and contact the maintenance company. |
| 182 | Power reception unit: Current Detection Circuit Error (Error: 6) | |
| 188 | Power reception unit: Charging Voltage 5V or Less (Error: 18) | |
| 245 | Battery voltage: Out of Threshold Range Error | <ul style="list-style-type: none"> Click [Error Clear]. If it reoccurs, turn the power off and then on again in a non-hazardous area. If it recurs, write down the error number and contact the maintenance company. |
| 246 | Battery current: Out of Threshold Range Error | |

■ Gas detector errors (incident class: Gas)

| Error Code | Cause | Recovery Method |
|------------|--|---|
| 60 | Gas Detection Sensor: Communication Timeout (cycle: 7.5s) | <ul style="list-style-type: none"> The operation will continue with the warning. |
| 61 | Gas Detection Sensor: Overrange | |
| 62 | Gas Detection Sensor, Sensor Error | |
| 63 | Gas Detection Sensor: Main Unit Error Occurred (Error: 77) | |
| 64 | Gas Detection Sensor: Sensor Anomaly (Error: 99) | |

■ Manipulator controller errors (incident class: Mani)

| Error Code | Cause | Recovery Method | |
|------------|---|---|---|
| 2 | Mismatch between format and command | <ul style="list-style-type: none"> The operation will continue with the warning. | |
| 3 | Command received cannot be handled in current mode | | |
| 4 | Invalid Command | | |
| 8 | S1 axis overspeed | | |
| 9 | S2 axis overspeed | | |
| 10 | E1 axis overspeed | | |
| 11 | E2 axis overspeed | | |
| 12 | W1 axis overspeed | | |
| 13 | W2 axis overspeed | | |
| 15 | Tip position overspeed | | |
| 16 | Tip attitude overspeed | | |
| 17 | S1 axis target over angle | | |
| 18 | S2 axis target over angle | | |
| 19 | E1 axis target over angle | | |
| 20 | E2 axis target over angle | | |
| 21 | W1 axis target over angle | | |
| 22 | W2 axis target over angle | | |
| 36 | The target value is in an uncontrollable zone (insufficient arm length) | | <ul style="list-style-type: none"> Click [Error Clear]. Move the manipulator in the stowage direction by teleoperating each axis. |
| 37 | Specified parameter value exceeds specifiable range | | |
| 66 | Socket generation failed | | |
| 67 | Socket and address binding failed | | |
| 68 | Listening failed | | |
| 69 | Acceptance failed | | |
| 70 | Socket transmission failed | | |
| 72 | Too many clients are connected | | |
| 73 | Parameter operating speed exceeds speed limit | | |
| 74 | Thermistor temperature warning | | |
| 102 | S1 axis over angle | | |
| 103 | S2 axis over angle | | |
| 104 | E1 axis over angle | | |
| 105 | E2 axis over angle | | |
| 106 | W1 axis over angle | | |
| 107 | W2 axis over angle | | |
| 109 | Cannot enter RMRC control at the current position | | |

| Error Code | Cause | Recovery Method | |
|------------|--|---|---|
| 110 | Automatically stopped when monitoring time exceeded | <ul style="list-style-type: none"> • Click [Error Clear]. • Enter and exit the Charging Station. The manipulator will be reset. • If it recurs, write down the error number and contact the maintenance company. | |
| 111 | Target value not reached | | |
| 112 | S1 axis synchronization error in each axis control | | |
| 113 | S2 axis synchronization error in each axis control | | |
| 114 | E1 axis synchronization error in each axis control | | |
| 115 | E2 axis synchronization error in each axis control | | |
| 116 | W1 axis synchronization error in each axis control | | |
| 117 | W2 axis synchronization error in each axis control | | |
| 119 | X-axis synchronization error in RMRC control | | |
| 120 | Y-axis synchronization error in RMRC control | | |
| 121 | Z-axis synchronization error in RMRC control | | |
| 123 | Abnormal fingertip attitude deviation in RMRC control | | |
| 125 | Operation cannot be started or continued at the arm singular point | | <ul style="list-style-type: none"> • Click [Error Clear]. • Move the manipulator in the stowage direction by teleoperating each axis. |
| 126 | Operation cannot be started or continued at the arm singular point | | |


| Error Code | Cause | Recovery Method |
|------------|--|---|
| 127 | Motor 1 axis: Potentiometer Error (absolute angle detection error) | <ul style="list-style-type: none"> • Click [Error Clear]. • Enter and exit the Charging Station. The manipulator will be reset. • If it recurs, write down the error number and contact the maintenance company. |
| 128 | Motor 2 axis: Potentiometer Error (absolute angle detection error) | |
| 129 | Motor 3 axis: Potentiometer Error (absolute angle detection error) | |
| 130 | Motor 4 axis: Potentiometer Error (absolute angle detection error) | |
| 131 | Motor 5 axis: Potentiometer Error (absolute angle detection error) | |
| 132 | Motor 6 axis: Potentiometer Error (absolute angle detection error) | |
| 133 | Motor 7 axis: Potentiometer Error (absolute angle detection error) | |
| 134 | Motor 8 axis: Potentiometer Error (absolute angle detection error) | |
| 144 | Controller status error | |
| 145 | T1 axis status error | |
| 146 | T2 axis status error | |
| 147 | T3 axis status error | |
| 148 | T4 axis status error | |
| 149 | T5 axis status error | |
| 150 | T6 axis status error | |
| 151 | T7 axis status error | |
| 152 | T8 axis status error | |
| 155 | Origin setting error | |
| 156 | Control mode change error | |
| 157 | Command transmission error | |
| 158 | Set the origin | |
| 159 | Power ON error | |
| 160 | Power OFF error | |
| 161 | Data reception error | |
| 201 | Control not started: Uncontrolled state due to STO disconnection | <ul style="list-style-type: none"> • ASCENT's Emergency Stop button (black button) was pressed. Click [Error Clear]. |
| 202 | Emergency stop button pressed = STO cutoff state | |

| Error Code | Cause | Recovery Method |
|------------|-----------------------------|---|
| 222 | T1 axis communication error | <ul style="list-style-type: none"> • Click [Error Clear]. • Enter and exit the Charging Station. The manipulator will be reset. • If it recurs, write down the error number and contact the maintenance company. |
| 223 | T2 axis communication error | |
| 224 | T3 axis communication error | |
| 225 | T4 axis communication error | |
| 226 | T5 axis communication error | |
| 227 | T6 axis communication error | |
| 228 | T7 axis communication error | |
| 229 | T8 axis communication error | |
| 230 | Mode management error | |

MEMO

Chapter 16 Appendix

16.1 Cloud Screen Transition Diagram



* Only administrator users can view

MEMO



Mitsubishi Heavy Industries, Ltd.

1-1, Wadasaki-cho 1-chome, Hyogo-ku, Kobe, Hyogo, 652-8585, Japan
B-mars@nu.mhi.com

www.mhi.com